
FLUKE.

ScopeMeter® Test Tool 190 Series II Fluke 190-062, -102, -104, -202, -204, -502, -504

Users Manual

May 2011, Rev.2, 1/14 © 2011-2014 Fluke Corporation. All rights reserved. Specifications are subject to change without notice. All product names are trademarks of their respective companies.





hpp00.eps

LIMITED WARRANTY & LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is three years for the test tool and one year for its accessories. The warranty period begins on the date of shipment. Parts, product repairs and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries or to any product which, in Fluke's opinion, has been misused, altered, neglected or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center or send the product, with a description of the difficulty, postage and insurance prepaid (FOB Destination), to the nearest Fluke authorized service center. Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that the failure was caused by misuse, alteration, accident or abnormal condition of operation or handling, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, WHETHER ARISING FROM BREACH OF WARRANTY OR BASED ON CONTRACT, TORT, RELIANCE OR ANY OTHER THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.



Table of Contents

Chapter	Title	Page
Chap	ter 1	1-11
1	Using the Scope and Meter Powering the Test Tool Resetting the Test Tool Navigating a Menu Hiding Key Labels and Menus Key Illumination Input Connections Making Input Connections Adjusting the Probe Type Settings Selecting an Input Channel Displaying an Unknown Signal with Connect-and-View™ Making Automatic Scope Measurements Freezing the Screen Using Average, Persistence and Glitch Capture	1-11 1-12 1-13 1-14 1-15 1-16 1-18 1-19 1-20 1-22

i



ScopeMeter® Test Tool 190 Series II

2

Users Manual

Using Average for Smoothing Waveforms	1-23
Smart average	1-23
Using Persistence, Envelope and Dot-Join to Display Waveforms	1-24
Displaying Glitches	
Suppressing High Frequency Noise	
Acquiring Waveforms	
Setting the Acquisition Speed and Waveform Memory Depth	1-27
Selecting AC-Coupling	1-27
Reversing the Polarity of the Displayed Waveform	
Variable Input Sensitivity	
Working with Noisy Waveforms	
Using Mathematics Functions +, -, x, XY-mode	1-30
Using Mathematics Function Spectrum (FFT)	
Comparing Waveforms	
Pass - Fail Testing	1-35
Analyzing Waveforms	1-35
Making Automatic Meter Measurements (for models 190-xx4)	1-36
Selecting a Meter Measurement	1-36
Making Relative Meter Measurements	
Making Multimeter Measurements (for models 190-xx2)	1-39
Making Meter Connections	1-39
Measuring Resistance Values	1-39
Making a Current Measurement	1-40
Selecting Auto/Manual Ranges	1-42
Making Relative Meter Measurements	1-43
Using The Recorder Functions	2-41
Opening the Recorder Main Menu	
Plotting Measurements Over Time (TrendPlot™)	
Starting a TrendPlot Function	
5	

ii

Contents (continued)

	Displaying Recorded Data	2-44
	Changing the Recorder Options	2-44
	Turning Off the TrendPlot Display	2-44
	Recording Scope Waveforms In Deep Memory (Scope Record)	2-45
	Starting a Scope Record Function	2-45
	Displaying Recorded Data	2-46
	Using Scope Record in Single Sweep Mode	2-46
	Using Triggering to Start or Stop Scope Record	2-47
	Analyzing a TrendPlot or Scope Record	2-48
3	Using Replay, Zoom and Cursors	3-49
	Replaying the 100 Most Recent Scope Screens	
	Replaying Step-by-Step	
	Replaying Continuously	3-51
	Turning Off the Replay Function	
	Capturing 100 Intermittents Automatically	3-51
	Zooming in on a Waveform	3-52
	Turning Off the Zoom Function	3-52
	Making Cursor Measurements	3-53
	Using Horizontal Cursors on a Waveform	
	Using Vertical Cursors on a Waveform	3-54
	Using Cursors on a Mathematical Result (+ - x) Waveform	3-55
	Using Cursors on Spectrum Measurements	
	Making Rise Time Measurements	3-56
4	Triggering on Waveforms	4-57
	Setting Trigger Level and Slope	4-58
	Using Trigger Delay or Pre-trigger	4-59
	Automatic Trigger Options	4-60
	Triggering on Edges	4-61

iii



ScopeMeter® Test Tool 190 Series IIUsers Manual

	Triggering on Noisy Waveforms	4-62
	Making a Single Acquisition	
	N-Cycle Triggering	4-63
	Triggering on External Waveforms (models 190-xx2)	4-64
	Triggering on Video Signals	4-65
	Triggering on Video Frames	4-66
	Triggering on Video Lines	4-66
	Triggering on Pulses	4-67
	Detecting Narrow Pulses	4-67
	Finding Missing Pulses	4-68
5	Using Memory and PC	5-71
	Using the USB Ports	
	Saving and Recalling	
	Saving Screens with Associated Setups	5-74
	Saving Screens in .bmp Format (Print Screen)	5-77
	Deleting Screens with Associated Setups	5-78
	Recalling Screens with Associated Setups	5-79
	Recalling a Setup Configuration	5-80
	Viewing Stored Screens	5-81
	Renaming Stored Screens and Setup Files	5-81
	Copying-Moving Stored Screens and Setup Files	
	Using FlukeView [®]	5-83
	Connecting to a Computer	5-83
	Using the Standard Accessories	6-81
	Using the Independently Floating Isolated Inputs	6-83
	Measuring Using Independently Floating Isolated Inputs	6-83
	Using the Tilt Stand	
	Kensington®-lock	6-87
	Fixing the Hangstrap	6-87

Contents (continued)

	Resetting the Test Tool	
	Suppressing Key Labels and Menu's	6-88
	Changing the Information Language	6-89
	Adjusting the Contrast and Brightness	6-89
	Changing Date and Time	6-90
	Saving Battery Life	6-91
	Setting the Power Down Timer	
	Setting the Display AUTO-off Timer	6-92
	Changing the Auto Set Options	6-93
7	Maintaining the Test Tool	7-95
	Cleaning the Test Tool	
	Storing the Test Tool	
	Charging the Batteries	
	Replacing the Battery Pack	7-97
	Calibrating the Voltage Probes	
	Displaying Version and Calibration Information	
	Displaying Battery Information	7-101
	Parts and Accessories	
	Replacement Parts	7-102
	Optional Accessories	
	Troubleshooting	7-108
	The Test Tool Shuts Down After a Short Time	7-108
	The Screen Remains Black	
	The Test Tool Cannot Be Turned Off	7-108
	FlukeView® Does Not Recognize The Test Tool	
	Battery Operated Fluke Accessories Do Not Function	
В	Specifications	8-111
	Introduction	

 ν



ScopeMeter® Test Tool 190 Series IIUsers Manual

Oscilloscope	8-112
Isolated Inputs A,B, C and D (Vertical)	8-112
Horizontal	8-112
Trigger and Delay	8-114
Automatic Connect-and-View Trigger	8-114
Edge Trigger	8-114
Isolated External Trigger (190-xx2)	8-114
Video Trigger	
Pulse Width Trigger	8-115
Continuous Auto Set	8-115
Automatic Capturing Scope Screens	8-115
Automatic Scope Measurements	8-116
General	8-116
DC Voltage (VDC)	8-116
AC Voltage (VAC)	8-116
AC+DC Voltage (True RMS)	8-117
Amperes (AMP)	8-118
Peak	8-118
Frequency (Hz)	8-118
Duty Cycle (DUTY)	8-118
Pulse Width (PULSE)	8-118
Vpwm	8-118
V/Hz	8-119
Power (A and B, C and D)	8-119
Phase (A and B, C and D)	8-119
Temperature (TEMP)	8-119
Decibel (dB)	8-119
Meter Measurements for Fluke 190-xx4	8-120
Meter Measurements for Fluke 190-xx2	8-120

vi



Contents (continued)

Meter Input (Banana Jacks)	8-120
Meter Functions	8-120
General	8-120
Ohms (Ω)	8-121
Continuity (CONT)	8-121
Diode	8-121
Temperature (TEMP)	8-121
DC Voltage (VDC)	8-121
AC Voltage (VAC)	8-121
AC+DC Voltage (True RMS)	8-122
Amperes (AMP)	8-122
Recorder	8-122
TrendPlot (Meter or Scope)	8-122
Scope Record	
Zoom, Replay and Cursors	8-123
Zoom	8-123
Replay	8-123
Cursor Measurements	8-123
Miscellaneous	8-124
Dįsplay	8-124
<u></u> Power	8-124
Probe Calibration	8-124
Internal Memory	8-125
External Memory	8-125
Mechanical	8-125
Interface Ports	8-125
Environmental	8-126
	8-126
∴ Safetv ∴ Safetv	8-127

vii



ScopeMeter® Test Tool 190 Series II

Users Manual

10:1 Probe VPS410	8-129
Accuracy	8-129
Electromagnetic Immunity	8-130

viii



Introduction

⚠ Warning

Read "Safety Information" before using this instrument.

The descriptions and instructions in this manual apply to all ScopeMeter® Test Tool 190 Series II versions (hereafter referred to as the instrument or as the test tool). The versions are listed below. The version 190-x04 appears in most illustrations.

Input C and Input D, and the Input C and Input D selection keys (and and) are only present on the versions 190-x04.

Version	Description
190-062	Two 60 MHz Scope Inputs (BNC), One Meter Input (banana jacks).
190-102	Two 100 MHz Scope Inputs (BNC), One Meter Input (banana jacks).
190-104	Four 100 MHz Scope Inputs (BNC)
190-202	Two 200 MHz Scope Inputs (BNC), One Meter Input (banana jacks).
190-204	Four 200 MHz Scope Inputs (BNC).
190-502	Two 500 MHz Scope Inputs (BNC), One Meter Input (banana jacks).
190-504	Four 500 MHz Scope Inputs (BNC).



Users Manual

Unpacking the Test Tool Kit

The items in Figure 1 are included in your test tool kit:

Note

When new, the rechargeable Li-ion battery is not fully charged. See Chapter 7.




Figure 1. Test Tool Kit

All Fluke 190 Series II versions include the following items:

#	Description
1	Test Tool including
	side strap
	 battery pack BP290 (models 190-xx2) or BP291 (models 190-xx4 and 190-5xx)
2	Hang Strap (see Chapter 6 for mounting instructions)
3	Power Adapter (country dependent, may vary from what is shown in Figure 1)
4	USB interface cable for PC connection (USB-A to mini-USB-B)
5	Safety Information sheet + CD ROM with Users Manual (multi-language) and FlukeView [®] ScopeMeter [®] Software for Windows demo package (with restricted functionality)
6	Shipment box (basic version only)

#	Description	
7	Voltage Probe Set (red)	
8	Voltage Probe Set (blue)	
9	Voltage Probe Set (gray), not for 190-xx2	
10	Voltage Probe Set (green), not for 190-xx2	
	Each set includes: a) Fluke 190-50x: 10:1 Voltage Probe, 500 MHz (red or blue or gray or green) Other models: 10:1 Voltage Probe, 300 MHz (red or blue or gray or green) b) Hook Clip for Probe Tip (black) c) Ground Lead with Mini Alligator Clip (black) d) Ground Spring for Probe Tip (black) e) Insulation Sleeve (black) f) Fluke 190-50x: 50 Ohm (1 W) Terminator	
11	Test Leads with test pins (one red, one black), for models 190-xx2 only.	



ScopeMeter® Test Tool 190 Series II

Users Manual

Fluke 190-xxx /S versions include also the following items (SCC290 kit):

#	Description
12	FlukeView [®] ScopeMeter [®] Software for Windows activation key (converts FlukeView [®] DEMO status into full operational status).
13	Hard Shell Carrying Case

Safety Information: Read First

Read all safety information before you use the product.

Specific warning and caution statements, where they apply, appear throughout the manual.

A "Warning" identifies conditions and actions that pose hazard(s) to the user.

A "Caution" identifies conditions and actions that may damage the product.



The following international symbols are used on the product and in this manual.

Λ	Risk of Danger. Important information. See Manual.	
	Double Insulated	
© ® us	Conforms to relevant North American Safety Standards.	
N10140	Conforms to relevant Australian standards.	
K	Conforms to relevant South Korean EMC Standards.	
MH2577	Battery Safety Approval	
Ţ	Earth Ground	
Li-ion	Recycling information.	
CE	Conforms to European Union directives	
	DC (Direct Current)	
≂	AC or DC (Alternating or Direct Current)	

_		
<u>A</u>	This product complies with the WEEE Directive (2002/96/EC) marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste. Product Category: With reference to the equipment types in the WEEE Directive Annex I, this product is classed as category 9 "Monitoring and Control Instrumentation" product. Do not dispose of this product as unsorted municipal waste. Go to Fluke's website for recycling information.	
CAT III	Measurement Category III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.	
CAT IV	Measurement Category IV is applicable to test and measuring circuits connected at the source of the building's low-voltage MAINS installation.	



⚠ Warning

To avoid electrical shock or fire:

- Use only the Fluke power supply, Model BC190 (Power Adapter).
- Before use, check that the selected/indicated range on the BC190 matches the local line power voltage and frequency.
- For the BC190/808 and BC190/820 universal Power Adapters only use line cords that comply with the local safety regulations.

Note:

To accommodate connection to various line power sockets, the BC190/808 and BC190/820 universal Power Adapters are equipped with a male plug that must be connected to a line cord appropriate for local use. Since the adapter is isolated, the line cord does not need to be equipped with a terminal for connection to protective ground. Since line cords with a protective grounding terminal are more commonly available you might consider using these anyhow.

⚠ Warning

To avoid electrical shock or fire if a product input is connected to more than 42 V peak (30 Vrms) or 60 V dc:

- Use only insulated voltage probes, test leads and adapters supplied with the product, or indicated by Fluke as suitable for the Fluke 190 Series II ScopeMeter® Test Tool series.
- Before use, inspect voltage probes, test leads and accessories for mechanical damage and replace when damaged.
- Remove all probes, test leads and accessories that are not in use.
- Always connect the power adapter first to the ac outlet before connecting it to the product.
- Do not touch voltages >30 V ac rms, 42 V ac peak, or 60 V dc.
- Do not connect the ground spring (figure 1, item d) to voltages higher than 42 V peak (30 Vrms) from earth ground.
- When using the ground reference lead with any of the probes, make sure that the black isolation sleeve (Figure 1, item. 10e) is over the probe tip.

- Do not apply more than the rated voltage, between the terminals or between each terminal and earth ground.
- Do not apply input voltages above the rating of the instrument. Use caution when using 1:1 test leads because the probe tip voltage will be directly transmitted to the product.
- Do not use exposed metal BNC or banana plug connectors. Fluke offers cables with plastic, safety designed BNC connectors suitable for the ScopeMeter[®] Test Tool product, see Chapter 7 'Optional accessories'.
- Do not insert metal objects into connectors.
- Use the product only as specified, or the protection supplied by the product can be compromised.
- Carefully read all instructions.
- Do not use the product if it operates incorrectly.
- Do not use the product or its accessories in case of any damage.
- Disable the product or its accessories in case of any damage.

- Keep fingers behind the finger guards on the probes.
- Use only correct measurement category (CAT), voltage, and current rated probes, test leads, and adapters for the measurement.
- Do not exceed the Measurement Category (CAT) rating of the lowest rated individual component of a product, probe, or accessory.
- Do not use the product around explosive gas, vapor, or in damp or wet environments.
- Measure a known voltage first to make sure that the product operates correctly.
- Examine the case before you use the product.
 Look for cracks or missing plastic. Carefully look at the insulation around the terminals.
- Do not work alone.
- Comply with local and national safety codes.
 Use personal protective equipment (approved rubber gloves, face protection, and flame resistant clothes) to prevent shock and arc blast injury where hazardous live conductors are exposed.
- The battery door must be closed and locked before you operate the product.



ScopeMeter® Test Tool 190 Series II

Users Manual

- Do not operate the product with covers removed or the case open. Hazardous voltage exposure is possible.
- Remove the input signals before you clean the product.
- Use only specified replacement parts.

Voltage ratings that are mentioned in the warnings are given as limits for "working voltage". They represent V ac rms (50-60 Hz) for ac sinewave applications and as V dc for dc applications.

Measurement Category IV refers to the overhead or underground utility service of an installation.

Measurement Category III refers to distribution level and fixed installation circuits inside a building.

Measurement Category II refers to local level, which is applicable for appliances and portable equipment.

The terms 'Isolated' or 'Electrically floating' are used in this manual to indicate a measurement in which the product input BNC is connected to a voltage different from earth ground.

The isolated input connectors have no exposed metal and are fully insulated to protect against electrical shock.

The BNC jacks can independently be connected to a voltage above earth ground for isolated (electrically floating) measurements and are rated up to 1000 Vrms CAT III and 600 Vrms CAT IV above earth ground.

If Safety Features are Impaired

Use of the product in a manner not specified may impair the protection provided by the equipment.

Do not use test leads if they are damaged. Examine the test leads for damaged insulation, exposed metal, or if the wear indicator shows.

Whenever it is likely that safety has been impaired, the product must be turned off and disconnected from the line power. The matter should then be referred to qualified personnel. Safety is likely to be impaired if, for example, the product fails to perform the intended measurements or shows visible damage.

Safe Use of Li-ion battery pack

The battery pack Fluke model BP290 (26 Wh)/BP291 (52 Wh) has been tested in accordance with the UN Manual of Tests and Criteria Part III Subsection 38.3 (ST/SG/AC.10/11/Rev.3) – more commonly known as the UN T1..T8 – tests, and have been found to comply with the stated criteria. The battery pack has been tested acc.

to EN/IEC62133. As a result they can be shipped unrestricted internationally by any means.

Recommendations to safe storage of battery pack.

- Do not store battery packs near heat or fire. Do not store in sunlight.
- Do not remove a battery pack from its original packaging until required for use.
- When possible, remove the battery pack from the equipment when not in use.
- Fully charge the battery pack before storing it for an extended period to avoid a defect.
- After extended periods of storage, it may be necessary to charge and discharge the battery packs several times to obtain maximum performance.
- Keep the battery pack out of the reach of children and animals.
- Seek medical advise if a battery or part of it has been swallowed.

Recommendations to safe use of the battery pack.

- The battery pack needs to be charged before use.
 Use only Fluke approved power adapters to charge the battery pack. Refer to Fluke's safety instructions and Users Manual for proper charging instructions.
- Do not leave a battery on prolonged charge when not in use.

- The battery pack gives the best performance when operated at normal room temperature 20 °C \pm 5 °C (68 °F \pm 9 °F).
- Do not put battery packs near heat or fire. Do not put in sunlight.
- Do not subject battery packs to severe impacts such as mechanical shock.
- Keep the battery pack clean and dry. Clean dirty connectors with a dry, clean cloth
- Do not use any charger other than that specifically provided for use with this equipment.
- Do not use any battery which is not designed or recommended by Fluke for use with the Product.
- Take careful notice of correct placement of the battery in the product or the External Battery Charger.
- Do not short-circuit a battery pack. Do not keep battery packs in a place where the terminals can be shorted by metal objects (e.g. coins, paperclips, pens or other).
- Never use a battery pack or charger showing visible damage.
- Batteries contain hazardous chemicals that can cause burns or explode. If exposure to chemicals occurs, clean with water and get medical aid. Repair the product before use if the battery leaks.



ScopeMeter® Test Tool 190 Series II

Users Manual

- Alteration of battery pack: there shall be no attempt to open, modify, reform or repair a battery pack, which appears to be malfunctioning, or which has been physically damaged.
- Do not disassemble or crush battery packs
- Use the battery only in the application for which it is intended.
- Retain the original product information for future reference.

Recommendations to safe transport of battery packs

- The battery pack must adequately be protected against short-circuit or damage during transport.
- Always consult the IATA guidelines describing safe air transport of Li-ion batteries. Refer also to the section in the beginning of this paragraph on safe use of the battery pack.
- Check-in luggage: battery packs are only allowed when installed in the Product.
- Hand carried luggage: a number of battery packs as required for normal and individual use is allowed.
- Always consult national/local guidelines that are applicable for shipment by mail or other transporters.
- A maximum of 3 battery packs may be shipped by mail. The package must be marked as follows:

PACKAGE CONTAINS LITHIUM-ION BATTERIES (NO LITHIUM METAL).

Recommendations to safe disposal of a battery pack.

- A failed battery pack shall be properly disposed of in accordance with local regulations.
- Dispose of properly: do not dispose of the battery as unsorted municipal waste. Go to Fluke's website for recycling information.
- Dispose in discharged condition and cover the battery terminals with isolation tape.



Chapter 1 Using the Scope and Meter

About this Chapter

This chapter provides a step-by-step introduction to the scope and meter functions of the test tool. The introduction does not cover all of the capabilities of the functions but gives basic examples to show how to use the menus and perform basic operations.

Powering the Test Tool

Follow the procedure (steps 1 through 3) in Figure 2 to power the test tool from a standard ac outlet.

See Chapter 6 for instructions on using battery power.



Turn the test tool on with the on/off key.

The test tool powers up in its last setup configuration.

The menus to adjust date, time and information language are switched on automatically when the test tool is powered on for the first time. See Figure 2.





Figure 2. Powering the Test Tool

Resetting the Test Tool

If you want to reset the test tool to the factory settings, do the following:



The test tool turns on, and you should hear a double beep, indicating the reset was successful.

4 Release the USER key.

Now look at the display; you will see a screen that looks like Figure 3.






Figure 3. The Screen After Reset

Navigating a Menu

The following example shows how to use the test tool's menus to select a function. Sequently follow steps 1 through 3 to open the scope menu and to choose an item.





Use the blue arrow keys to highlight the item.

3b


Press the blue ENTER key to accept the selection. The next option will be selected. After the last option the menu will be closed.

Note

To exit the menu at any moment press [F4] (CLOSE).

Hiding Key Labels and Menus

You can close a menu or hide key label at any time:



A displayed menu will be closed.

To display menus or key labels, press one of the yellow menu keys, e.g. the **scope** key.

You can close most menus using the F4 soft key CLOSE.

Key Illumination


Some keys are provided with an illumination LED. For an explanation of the LED function see the table below.

Display AUTO-Off timer '. Off: in all other situations On: Measurements are stopped, the screen is frozen. (HOLD) Off: Measurements are running. (RUN) On: The range key, the move up/down key, and the F1F4 key labels, apply to the illuminated channel key(s). Off: - Off: Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered	explanation of the LLB function does the table below.				
On: Measurements are stopped, the screen is frozen. (HOLD) Off: Measurements are running. (RUN) On: The range key, the move up/down key, and the F1F4 key labels, apply to the illuminated channel key(s). Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered			See Chapter 6 'Tips' section 'Setting the Display AUTO-Off timer '.		
is frozen. (HOLD) Off: Measurements are running. (RUN) On: The range key, the move up/down key, and the F1F4 key labels, apply to the illuminated channel key(s). Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered					
Off: Measurements are running. (RUN) On: The range key, the move up/down key, and the F1F4 key labels, apply to the illuminated channel key(s). Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered	HOLD RUN	On:	• • •		
On: The range key, the move up/down key, and the F1F4 key labels, apply to the illuminated channel key(s). Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered			is frozen. (HOLD)		
and the F1F4 key labels, apply to the illuminated channel key(s). C Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered		Off:	Measurements are running. (RUN)		
illuminated channel key(s). Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered	Λ	On:	The range key, the move up/down key,		
illuminated channel key(s). Off: - On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered	A		and the F1F4 key labels, apply to the		
Off: - MANUAL AUTO On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered	В				
On: Manual operating mode. Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM) On: Signal is triggered		0"	3 ()		
Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM)		Off:	-		
Off: Automatic operating mode, optimizes the waveform position, range, time base and triggering (Connect-and-View TM)	D				
the waveform position, range, time base and triggering (Connect-and-View TM)	MANUAL	On:	Manual operating mode.		
the waveform position, range, time base and triggering (Connect-and-View TM)		Off:	Automatic operating mode, optimizes		
View TM)	7,616		the waveform position, range, time		
View TM)			base and triggering (Connect-and-		
On: Signal is triggered			View TM)		
1 19164 1911 1 - 3 1133 - 1 - 1	TRIGGER	On:	Signal is triggered		
Off: Signal is not triggered		Off:	Signal is not triggered		
Flashing: waiting for a trigger at 'Single Shot'		Flas	hing: waiting for a trigger at 'Single Shot'		
or 'On Trigger' waveform update.					

Input Connections

Look at the top of the test tool. The test tool has four safety BNC jack signal inputs (models 190–xx4), or two safety BNC jack inputs and two safety 4-mm banana jack inputs (models 190-xx2). See Figure 5.

Isolated input architecture allows independent floating measurements with each input.






Figure 5. Measurement Connections

Making Input Connections

To make scope measurements connect the red voltage probe to input A, the blue voltage probe to input B, the grey voltage probe to input C and the green voltage probe to input D. Connect the short ground leads of **each** voltage probe to its **own** reference potential (See Figure 6).

For Meter measurements refer to the applicable section in this chapter.

▲ Warning

To avoid electrical shock use the insulation sleeve (Figure 1 item e)) if you use the probes without the hook clip or the ground spring.

Notes

- To maximally benefit from having independently isolated floating inputs and to avoid problems caused by improper use, read Chapter 6: "Tips".
- For an accurate indication of the measured signal, it is necessary to match the probe to the test tool's input channel. See section 'Calibrating the voltage Probes' in Chapter 7.





Figure 6. Scope Connections


Adjusting the Probe Type Settings

To obtain correct measurement results the test tool probe type settings must correspond to the connected probe types. To select the input A probe setting do the following:



Selecting an Input Channel

To select an input channel, do the following:



Tip

To set multiple channels to the same range (V/div) as, for example, input A, do the following:

- Select the input A measurement function, probe setting and input options for all involved channels
- press and hold
- press B and/or C and/or D
- release A

Notice that all pressed keys are illuminated now. The MOVE UP/DOWN key and the RANGE mV/V key applies to all involved input channels.

Displaying an Unknown Signal with Connect-and-View™

The Connect-and-View feature lets the test tool display complex, unknown signals automatically. This function optimizes the position, range, time base, and triggering and assures a stable display of virtually any waveform. If the signal changes, the setup is automatically adjusted to maintain the best display result. This feature is especially useful for quickly checking several signals.

To enable the Connect-and-View feature when the test tool is in MANUAL mode, do the following:

1 MANUAL AUTO

Perform an Auto Set. **AUTO** appears at the top right of the screen, the key illumination is off.

The bottom line shows the range, the time base, and the trigger information.

The waveform identifier (**A**) is visible on the right side of the screen, as shown in Figure 7. The input A zero icon ■ at the left side of the screen identifies the ground level of the waveform.

2 MANUAL AUTO

Press a second time to select the manual range again. MANUAL appears at the top right of the screen, the key illumination is on.





Figure 7. The Screen After an Auto Set


Use the light-gray **RANGE**, **TIME** and **MOVE** keys at the bottom of the keypad to change the view of the waveform manually.

Making Automatic Scope Measurements

The test tool offers a wide range of automatic scope measurements. In addition to the waveforms you can display four numeric readings: **Reading 1 ... 4**. These readings are selectable independently, and the measurements can be done on the input A, input B, input C or input D waveform.


To choose a frequency measurement for input A, do the following:





Observe that the top left of the screen displays the Hz measurement. (See Figure 8.)

To choose also a **Peak-Peak** measurement for Input B as second reading, do the following:



ScopeMeter® Test Tool 190 Series II

Users Manual




Figure 8 shows an example of the screen with two readings. The character size will be reduced when more than two readings are on.





Figure 8. Hz and V peak-peak as Scope Readings

Freezing the Screen


You can freeze the screen (all readings and waveforms) at any time.




Using Average, Persistence and Glitch Capture

Using Average for Smoothing Waveforms

To smooth the waveform, do the following:





You can use the average functions to suppress random or uncorrelated noise in the waveform without loss of bandwidth. Waveform samples with and without smoothing are shown in Figure 9.

Smart average

In the normal average mode occasional deviations in a waveform just distort the averaged wave shape, and do not show up on screen clearly. When a signal really changes, for instance when you probe around, it takes quite some time before the new wave shape is stable. With smart averaging you can quickly probe around, and incidental waveform changes like a line flyback in video show up on screen instantly.





Figure 9. Smoothing a Waveform

Using Persistence, Envelope and Dot-Join to Display Waveforms

You can use Persistence to observe dynamic signals. See Figure 10.



Using Average, Persistence and Glitch Capture

Select **Display: Dot-join: Off** to display measured samples only. Dot join off may be useful when measuring for example modulated signals or video signals.

Select **Display: Normal** to turn the envelope mode off and the dot-join function on.





Figure 10. Using Persistence to Observe Dynamic Signals

Displaying Glitches

To capture glitches on a waveform, do the following:




You can use this function to display events (glitches or other asynchronous waveforms) of 8 ns (8 nanoseconds, due to ADC's with 125 MS/s sampling speed) or wider, or you can display HF modulated waveforms.

When you select the 2 mV/div range Glitch Detect will automatically be turned Off. In the 2 mV/div range you can set Glitch Detect On manually.

Suppressing High Frequency Noise

Switching the glitch detection off (**Glitch**: **Off**) will suppress the high frequency noise on a waveform. Averaging will suppress the noise even more.




See also Using Average for Smoothing Waveforms on page 21.


Glitch capture and average do not affect bandwidth. Further noise suppression is possible with bandwidth limiting filters. See Working with Noisy Waveforms on page 27.

Acquiring Waveforms

Setting the Acquisition Speed and Waveform Memory Depth

To set the acquisition speed, do the following:






See also Table 2 in Chapter 8.

Selecting AC-Coupling

After a reset, the test tool is dc-coupled so that ac and dc voltages appear on the screen.

Use ac-coupling when you wish to observe a small ac signal that rides on a dc signal. To select ac-coupling, do the following:




Observe that the bottom left of the screen displays the ac-coupling icon: $\mathbf{\hat{H}}\mathbf{\hat{w}}$.

You can define how Auto Set affects this setting, see Chapter 6 'Changing the Auto Set Options'.

Reversing the Polarity of the Displayed Waveform

To invert, for example the input A waveform, do the following:



For example, a negative-going waveform is displayed as positive-going waveform which may provide a more meaningful view. An inverted display is identified by an inversed waveform identifier (1) at the right of the waveform, and in the status line below the waveform.


Users Manual

Variable Input Sensitivity

The variable input sensitivity allows you to adjust any input sensitivity continuously, for example to set the amplitude of a reference signal to exactly 6 divisions.


The input sensitivity of a range can be increased up to 2.5 times, for example between 10 mV/div and 4 mV/div in the 10 mV/div range.

To use the variable input sensitivity on for example input A, do the following:




An Auto Set will turn off the variable input sensitivity. You can now select the required input range. Keep in mind that the sensitivity will increase when you start adjusting the variable sensitivity (the displayed waveform amplitude will increase).





At the bottom left of the screen the text A Var is displayed.

Selecting Variable will turn off cursors and automatic input ranging.




Note

Variable input sensitivity is not available in the Mathematics functions (+ - x and Spectrum).

Working with Noisy Waveforms

To suppress high frequency noise on waveforms, you can limit the working bandwidth to 10 kHz or 20 MHz. This function smoothes the displayed waveform. For the same reason, it improves triggering on the waveform.

To choose the 10 kHz bandwidth on for example input A, do the following:



Tip

To suppress noise without loss of bandwidth, use the average function or turn off **Display Glitches**.


Using Mathematics Functions +, -, x, XY-mode


You can add (+), subtract (-), or multiply (x) two waveforms. The test tool will display the mathematical result waveform and the source waveforms.

The XY-mode provides a plot with one input on the vertical axis and the second input on the horizontal axis.

The Mathematics functions perform a point-to-point operation on the involved waveforms.

To use a Mathematics function, do the following:





The sensitivity range of the mathematical result is equal to the sensitivity range of the least sensitive input divided by the scale factor.

Using Mathematics Function Spectrum (FFT)


The Spectrum function shows the spectral content of the input A, B, C or D waveform in the input waveform color. It performs an FFT (Fast Fourier Transform) to transform the amplitude waveform from the time domain into the frequency domain.

To reduce the effect of side-lobes (leakage) it is recommended to use Auto windowing. This will automatically adapt the part of the waveform that is analyzed to a complete number of cycles

Selecting Hanning, Hamming or no windowing results in a faster update, but also in more leakage.


Ensure that the entire waveform amplitude remains on the screen.

To use the Spectrum function, do the following:



Using the Scope and Meter Acquiring Waveforms

1



You will see a screen that looks like Figure 11.

Observe that the top right of the screen displays SPECTRUM.

If it displays LOW AMPL a spectrum measurement cannot be done as the waveform amplitude is too low.

If it displays WRONG TB the time base setting does not enable the test tool to display an FFT result. It is either too slow, which can result in aliasing, or too fast, which results in less than one signal period on the screen.

7	F1	Perform a spectrum analysis on waveform A, B, C or D.
8	F2	Set the horizontal amplitude scale to linear or logarithmic.
9	F3	Set the vertical amplitude scale to linear or logarithmic.
10	F4	Turn the spectrum function off/on (toggle function).





Figure 11. Spectrum Measurement

Comparing Waveforms

You can display a fixed reference waveform with the actual waveform for comparison.

To create a reference waveform and to display it with the actual waveform, do the following:





Select **On** to display the reference waveform. This can be:

- the last used reference waveform (if not available no reference waveform will be shown).
- the envelope waveform if the persistence function Envelope is on.

Select **Recall...** to recall a saved waveform (or waveform envelope) from memory and use it as a reference waveform.

Select **New...** to open the **NEW REFERENCE** menu.



If you selected **New...** continue at step 5, else go to step 6.

5



Select the width of an additional envelope to be added to the momentary waveform.


6



Store the momentary waveform and display it permanently for reference. The display also shows the actual waveform.

To recall a saved waveform from memory and use it as a reference waveform, refer also to Chapter 5 Recalling Screens with Associated Setups.

Example of reference waveform with an additional envelope of ± 2 pixels:



black pixels: basic waveform gray pixels: \pm 2 pixels envelope

1 vertical pixel on the display is 0.04 x range/div 1 horizontal pixel on the display is 0.0333 x range/div.

Pass - Fail Testing

You can use a reference waveform as a test template for the actual waveform. If at least one sample of a waveform is outside the test template, the failed or passed scope screen will be stored. Up to 100 screens can be stored. If the memory is full, the first screen will be deleted in favor of the new screen to be stored.

The most appropriate reference waveform for the Pass-Fail test is a waveform envelope.

To use the Pass - Fail function using a waveform envelope, do the following:

1 Display a reference waveform as described in the previous section "Comparing Waveforms"

2

From the **Pass Fail Testing:** menu select

Store "Fail": each scope screen with samples outside the reference will be stored

Store "Pass": each scope screen with no samples outside the reference will be stored

Each time a scope screen is stored you will hear a beep. Chapter 3 provides information on how to analyze the stored screens.

32

Analyzing Waveforms

You can use the analysis functions **cursor**, **zoom** and **REPLAY** to perform detailed waveform analysis. These functions are described in Chapter 3: "*Using Cursors*, *Zoom and Replay*".





Making Automatic Meter Measurements (for models 190-xx4)

The test tool offers a wide range of automatic meter measurements. You can display four large numeric readings: **READING 1 ... 4**. These readings are selectable independently, and the measurements can be done on the input A, B, C or input D waveform. In METER mode the waveforms are not displayed. The 10 kHz HF rejection filter (see Working with Noisy Waveforms on page 27) is always on in the METER mode.

Selecting a Meter Measurement

To choose a current measurement for input A, do the following:





You will see a screen like in Figure 12.




Figure 12. Meter Screen

Users Manual

Making Relative Meter Measurements

A relative measurement displays the present measurement result relative to a defined reference value.

The following example shows how to perform a relative voltage measurement. First obtain a reference value:



Now the large reading is the actual input value minus the stored reference value. The actual input value is displayed below the large reading (ACTUAL: xxxx), see Figure 13.



Figure 13. Making a Relative Measurement

You can use this feature when, for example, you need to monitor input activity (voltage, temperature) in relation to a known good value.

Adjusting the reference value

To adjust the reference value, do the following:

5	F3	Display the Adjust Reference menu.
6	F1	Select the applicable relative measurement reading.
7		Select the digit you want to adjust.
8		Adjust the digit. Repeat step 7 and step 8 until finished.
9	ENTER	Enter the new reference value.

Making Multimeter Measurements (for models 190-xx2)

The screen displays the numeric readings of the measurements on the meter input.

Making Meter Connections

Use the two 4-mm safety red (\COM) banana jack inputs for the Meter functions. (See Figure 14.)





Figure 14. Meter Connections

ScopeMeter® Test Tool 190 Series II

Users Manual

Measuring Resistance Values

To measure a resistance, do the following:



The resistor value is displayed in ohms. Observe also that the bargraph is displayed. (See 15.)



Figure 15. Resistor Value Readings

Making a Current Measurement

You can measure current in both Scope mode and Meter mode. Scope mode has the advantage of waveforms being displayed while you perform measurements. Meter mode has the advantage of high measurement resolution.

The next example explains a typical current measurement in Meter mode.

Warning

Carefully read the instructions about the current probe you are using.

To set up the test tool, do the following:

Connect a current probe (e.g. Fluke i410, optional) between the 4-mm banana jack inputs and the conductor to be measured.

Ensure that the red and black connectors correspond to the red and black banana jack inputs. (See Figure 16.)

Display the METER key labels.






Figure 16. Measurement Setup






Now, you will see a screen like in Figure 17.



Figure 17. Ampere Measurement Readings


Selecting Auto/Manual Ranges

To activate manual ranging, do the following during any Meter measurement:



Observe how the bargraph sensitivity changes.

Use manual ranging to set a fixed bargraph sensitivity and decimal point.




When in auto ranging, the bargraph sensitivity and decimal point are automatically adjusted while checking different signals.

Making Relative Meter Measurements

A relative measurement displays the present measurement result relative to a defined reference value.

The following example shows how to perform a relative voltage measurement. First obtain a reference value:



Now the large reading is the actual input value minus the stored reference value. The bargraph indicates the actual input value. The actual input value and the reference value are displayed below the large reading (ACTUAL: xxxx REFERENCE: xxx), see Figure 18.




Figure 18. Making a Relative Measurement

You can use this feature when, for example, you need to monitor input activity (voltage, temperature) in relation to a known good value.

ScopeMeter® Test Tool 190 Series II

Users Manual

Adjusting the reference value

To adjust the reference value, do the following:

5	F3	Display the Adjust Reference menu.
6		Select the digit you want to adjust.
7		Adjust the digit. Repeat step 6 and step 7 until finished.
8	ENTER	Enter the new reference value.



Chapter 2 Using The Recorder Functions

About this Chapter

This chapter provides a step-by-step introduction to the recorder functions of the test tool. The introduction gives examples to show how to use the menus and perform basic operations.

Opening the Recorder Main Menu

First choose a measurement in scope or meter mode. Now you can choose the recorder functions from the recorder main menu. To open the main menu, do the following:

Open the recorder main menu. (See Figure 19).



Figure 19. Recorder Main Menu

Trendplot Meter is only present in models 190-xx2.



Users Manual

Plotting Measurements Over Time (TrendPlot™)

Use the TrendPlot function to plot a graph of Scope or Meter measurements (readings) as function of time.

Note

Because the navigations for the TrendPlot Scope and the TrendPlot Meter are identical, only Scope TrendPlot is explained in the next sections.

Starting a TrendPlot Function

To start a TrendPlot, do the following:

Make automatic Scope or Meter measurements, see Chapter 1. The readings will be plotted!
 Open the RECORDER main menu.
 Highlight Trend Plot.
 Start the TrendPlot recording.

The test tool continuously records the digital readings of the measurements and displays these as a graph. The TrendPlot graph rolls from right to left like a paper chart recorder.

Observe that the recorded time from start appears at the bottom of the screen. The present reading appears on top of the screen. (See Figure 20.)

Note

When simultaneously TrendPlotting two readings, the screen area is split into two sections of four divisions each. When simultaneously TrendPlotting three or four readings, the screen area is split into three or four sections of two divisions each.





Figure 20. TrendPlot Reading

When the test tool is in automatic mode, automatic vertical scaling is used to fit the TrendPlot graph on the screen.



Note

Scope TrendPlot is not possible on cursor related measurements. As an alternative you may use the PC software FlukeView® ScopeMeter®.

Displaying Recorded Data

When in normal view (NORMAL), only the twelve most recently recorded divisions are displayed on screen. All previous recordings are stored in memory.

VIEW ALL shows all data in memory:



Press repeatedly to toggle between normal view (NORMAL) and overview (VIEW ALL).

When the recorder memory is full, an automatic compression algorithm is used to compress all samples into half of the memory without loss of transients. The other half of the recorder memory is free again to continue recording.

Changing the Recorder Options

At the lower right of the display, the status line indicates a time. You can choose this time to represent either the start time of the recording ('Time of Day') or the time elapsed since the start of the recording ('From Start').

To change the time reference, proceed from step 6 as follows:



Turning Off the TrendPlot Display

9 F4 Exit the recorder function.

Recording Scope Waveforms In Deep Memory (Scope Record)

Recording Scope Waveforms In Deep Memory (Scope Record)

The **scope record** function is a roll mode that logs a long waveform of each active input. This function can be used to monitor waveforms like motion control signals or the power-on event of an Uninterruptable Power Supply (UPS). During recording, fast transients are captured. Because of the deep memory, recording can be done for more than one day. This function is similar to the roll mode in many DSO's but has deeper memory and better functionality.

Starting a Scope Record Function

To record for example the input A and input B waveform, do the following:



The waveform moves across the screen from right to left like on a normal chart recorder. (See Figure 21).




Figure 21. Recording Waveforms

Observe that the screen displays the following:

- Time from start at the top of the screen.
- The status at the bottom of the screen which includes the time/div setting as well as the total timespan that fits the memory.


Note

For accurate recordings it is advised to let the instrument first warm up for five minutes.

Displaying Recorded Data

In Normal view, the samples that roll off the screen are stored in deep memory. When the memory is full, recording continues by shifting the data in memory and deleting the first samples out of memory.

In View All mode, the complete memory contents are displayed on the screen.




You can analyze the recorded waveforms using the Cursors and Zoom functions. See Chapter 3: "Using Replay, Zoom and Cursors".

Using Scope Record in Single Sweep Mode

Use the recorder **Single Sweep** function to automatically stop recording when the deep memory is full.

Continue from step 3 of the previous section:



Using Triggering to Start or Stop Scope Record

To record an electrical event that causes a fault, it might be useful to start or stop recording on a trigger signal: **Start on trigger** to start recording; recording stops when the deep memory is full

Stop on trigger to stop recording.

Stop when untriggered to continue recording as long as a next trigger comes within 1 division in view all mode.


For the models 190-xx4 the signal on the BNC input that has been selected as trigger source must cause the trigger.

For the models 190-xx2 the signal applied to the banana jack inputs (**EXT TRIGGER (in)**). signal must cause the trigger. The trigger source is automatically set to **Ext.** (external).

To set up the test tool, continue from step 3 of the previous section:

4 Apply the signal to be recorded to the BNC input(s).

5 Stop recording to unlock the **OPTIONS...** softkey.



For external triggering (190-xx2) continue at step 9.

ScopeMeter® Test Tool 190 Series II

Users Manual

Select the desired trigger slope
(Slope:) and jump to Level:.

Select the 0.12V or 1.2V trigger level and accept all recorder options.

Apply a trigger signal to the red and black ext. trigger banana inputs.

During recording samples are continuously saved in deep memory. The last twelve recorded divisions are displayed on the screen. See Figure 22. Use View All to display the full memory contents.

Note

To learn more about the Single Shot trigger function, see Chapter 4 "Triggering on Waveforms".




Figure 22. Triggered Single Sweep Recording

Analyzing a TrendPlot or Scope Record

From a TrendPlot or Scope Record you can use the analysis functions CURSORS and ZOOM to perform detailed waveform analysis. These functions are described in Chapter 3: "Using Replay, Zoom and Cursors".

Chapter 3 Using Replay, Zoom and Cursors

About this Chapter

This chapter covers the capabilities of the analysis functions **Cursor**, **Zoom**, and **Replay**. These functions can be used with one or more of the primary functions Scope, TrendPlot or Scope Record.

It is possible to combine two or three analysis functions. A typical application using these functions follows:

- First replay the last screens to find the screen of special interest.
- Then **zoom** in on the signal event.
- Finally, make measurements using the cursors.

Replaying the 100 Most Recent Scope Screens


When you are in scope mode, the test tool automatically stores the 100 most recent screens. When you press the HOLD key or the REPLAY key, the memory contents are frozen. Use the functions in the REPLAY menu to "go back in time" by stepping through the stored screens to find the screen of your interest. This feature lets you capture and view signals even if you did not press HOLD.



ScopeMeter® Test Tool 190 Series II Users Manual

Replaying Step-by-Step

To step through the last scope screens, do the following:



Observe that the bottom of the waveform area displays the replay bar with a screen number and related time stamp:






Figure 23. Replaying a Waveform


The replay bar represents all 100 stored screens in memory. The icon represents the picture being displayed on the screen (in this example: SCREEN -51). If the bar is partly white, the memory is not completely filled with 100 screens.

From this point you can use the zoom and cursor functions to study the signal in more detail.

Replaying Continuously

You can also replay the stored screens continuously, like playing a video tape.


To replay continuously, do the following:



Wait until the screen with the signal event of interest appears.

3 Stop the continuous replay.

Turning Off the Replay Function



Capturing 100 Intermittents Automatically

When you use the test tool in triggered mode, 100 *triggered* screens are captured.


By combining the trigger possibilities with the capability of capturing 100 screens for later replay, you can leave the test tool unattended to capture intermittent signal anomalies. This way you could use Pulse Triggering to trigger and capture 100 intermittent glitches or you could capture 100 UPS startups.

For triggering, see Chapter 4: "Triggering on Waveforms".

Zooming in on a Waveform

To obtain a more detailed view of a waveform, you can zoom in on a waveform using the **zoom** function.

To zoom in on a waveform, do the following:



Tip

Even when the key labels are not displayed at the bottom of the screen, you can still use the arrow keys to zoom in and out. You can also use the s TIME ns key to zoom in and out.





Figure 24. Zooming in a Waveform

Observe that the bottom of the waveform area displays the zoom ratio, position bar, and time/div (see Figure 24). The zoom range depends on the amount of data samples stored in memory.

Turning Off the Zoom Function




Making Cursor Measurements

Cursors allow you to make precise digital measurements on waveforms. This can be done on live waveforms, recorded waveforms, and on saved waveforms.

Using Horizontal Cursors on a Waveform

To use the cursors for a voltage measurement, do the following:



Note

Even when the key labels are not displayed at the bottom of the screen, you still can use the arrow keys. This allows full control of both cursors while having full screen view.





Figure 25. Voltage Measurement with Cursors

The screen shows the voltage difference between the two cursors and the voltage at the cursors. (See Figure 25.)

Use horizontal cursors to measure the amplitude, high or low value, or overshoot of a waveform.

Using Vertical Cursors on a Waveform

To use the cursors for a time measurement (T, 1/T), for a mVs-mAs-mWs measurement, or for an RMS measurement of the waveform section between the cursors, do the following:






Figure 26. Time Measurement with Cursors

Move the right cursor to the desired position on the waveform.

The screen shows the time difference between the cursors and the voltage difference between the two markers. (See Figure 26.)

9 Select **OFF** to turn off the cursors.

Notes

- For mVs select probe type 'Voltage'.
- For mAs select probe type 'Current'.
- For mWs select mathematical function x, and probe type 'Voltage' for one channel and 'Current' for the other channel.


Using Cursors on a Mathematical Result (+ - x) Waveform

Cursor measurements on, for examle, a AxB waveform give a reading in Watts if input A measures (milli)Volts and input B measures (milli)Amperes.

For other cursor measurements on, for example, a A+B, A-B or AxB waveform no reading will be available if the input A and input B measurement unit are different.

Using Cursors on Spectrum Measurements

To do a cursor measurent on a spectrum, do the following:






ScopeMeter® Test Tool 190 Series II

Users Manual

Making Rise Time Measurements

To measure rise time, do the following:



The reading shows the risetime from 10%-90% of the waveform amplitude.




Figure 27. Risetime Measurement

Note

Direct access to Rise time or Fall time with cursors on is possible via the key sequence SCOPE, F2 – READING, and then selection of Rise or Fall time.

Chapter 4 Triggering on Waveforms

About this Chapter

This chapter provides an introduction to the trigger functions of the test tool. Triggering tells the test tool when to begin displaying the waveform. You can use fully automatic triggering, take control of one or more main trigger functions (semi-automatic triggering), or you can use dedicated trigger functions to capture special waveforms.

Following are some typical trigger applications:

 Use the Connect-and-View[™] function to have full automatic triggering and instant display of virtually any waveform.

- If the signal is unstable or has a very low frequency, you can control the trigger level, slope, and trigger delay for a better view of the signal. (See next section.)
- For dedicated applications, use one of the four manual trigger functions:
 - Edge triggering
 - Video triggering
 - Pulse Width triggering
 - External Triggering (models 190-xx2 only)



Setting Trigger Level and Slope

The Connect-and-View™ function enables hands-off triggering to display complex unknown signals.


When your test tool is in manual range, do the following:



Perform an auto set. **AUTO** appears at the top right of the screen.

Automatic triggering assures a stable display of virtually any signal.

From this point, you can take over the basic trigger controls such as level, slope and delay. To optimize trigger level and slope manually, do the following:






Figure 28. Screen with all Trigger Information

4

Adjust the trigger level.

Observe the trigger icon **I** that indicates the trigger position, trigger level, and slope.

At the bottom of the screen the trigger parameters are displayed (See Figure 28). For example, **Trig: AJ** means that input A is used as the trigger source with a positive slope.

When a valid trigger signal is found, the trigger key will be lit and the trigger parameters appear in black.

When no trigger is found, the trigger parameters appear in gray, ands the key light will be off.

Using Trigger Delay or Pre-trigger

You can begin to display the waveform some time before or after the trigger point has been detected. Initially, you have a half screen (6 divisions) of pre-trigger view (negative delay).

To set the trigger delay, do the following:

Hold down to adjust the trigger delay.

Observe that the trigger icon **I** on the screen moves to show the new trigger position. When the trigger position moves left off of the screen, the trigger icon changes into **I** to indicate that you have selected a trigger delay. Moving the trigger icon to the right on the display gives you a pre-trigger view. This allows you to see what happened before the trigger event, or what caused the trigger.

In case of a trigger delay, the status at the bottom of the screen will change. For example:

AS +4500.0ms

This means that input A is used as the trigger source with a positive slope. The 500.0 ms indicates the (positive) delay between trigger point and waveform display.

When a valid trigger signal is found, the trigger key will be lit and the trigger parameters appear in black.

When no trigger is found, the trigger parameters appear in gray, ands the key light will be off.




Figure 29. Trigger Delay or Pre-trigger View

Figure 29 shows an example of a trigger delay of 500 ms (top) and an example of pre-trigger view of 8 divisions (bottom).

Automatic Trigger Options

In the trigger menu, settings for automatic triggering can be changed as follows. (See also Chapter 1: "Displaying an Unknown Signal with Connect-and-View")



Note

The **TRIGGER** key labels can differ depending on the latest trigger function used.



If the frequency range of the automatic triggering is set to > 15 Hz, the Connect-and-View™ function responds more quickly. The response is quicker because the test tool is instructed not to analyze low frequency signal components. However, when you measure frequencies lower than 15 Hz, the test tool must be instructed to analyze low frequency components for automatic triggering:


4 Seenter m

Select > 1 Hz and return to the measurement screen.

Triggering on Edges

If the signal is unstable or has a very low frequency, use edge triggering to obtain full manual trigger control.

To trigger on rising edges of the input A waveform, do the following:



When **Free Run** is selected, the test tool updates the screen even if there are no triggers. A waveform always appears on the screen.

When **On Trigger** is selected, the test tool needs a trigger to display a waveform. Use this mode if you want to update the screen *only* when valid triggers occur.

When **Single Shot** is selected, the test tool waits for a trigger. After receiving a trigger, the waveform is displayed and the instrument is set to HOLD.

In most cases it is advised to use the Free Run mode:



Observe that the key labels at the bottom of the screen have adapted to allow further selection of specific edge trigger settings:



Triggering on Noisy Waveforms

To reduce jitter on the screen when triggering on noisy waveforms, you can use a trigger filter. Continue from step 3 of the previous example as follows:

Select On Trigger, jump to Trigger Filter.

Set Noise Reject or HF Reject to On. This is indicated by a taller trigger icon \(\int \).

When **Noise Reject** is on, an increased trigger gap will be applied.

When **HF Reject** is on, HF noise on the (internal) trigger signal will be suppressed.

Making a Single Acquisition

To catch single events, you can perform a **single shot** acquisition (one-time screen update). To set up the test tool for a single shot of the input A waveform, continue from step 3 (page 61) again:

4 Select Single Shot.

The word MANUAL appears at the top of the screen indicating that the test tool is waiting for a trigger. As soon as the test tool receives a trigger, the waveform is displayed and the instrument is set to hold. This is indicated by the word HOLD at top of the screen.

The test tool will now have a screen like Figure 30.

5 Arm the test tool for a new single shot.

Tip

The test tool stores all single shots in the replay memory. Use the Replay function to look at all the stored single shots (see Chapter 3).




Figure 30. Making a Single Shot Measurement

N-Cycle Triggering

N-Cycle triggering enables you to create a stable picture of for example n-cycle burst waveforms.


Each next trigger is generated after the waveform has crossed the trigger level N times in the direction that complies with the selected trigger slope.

To select N-Cycle triggering, continue from step 3 (page 61) again:



Observe that the key labels at the bottom of the screen have been changed to allow further selection of specific N-Cycle trigger settings:





Waveforms with N-Cycle triggering (N=2) and without N-Cycle triggering are shown in Figure 31.




Figure 31. N-Cycle triggering

Triggering on External Waveforms (models 190-xx2)

Use external triggering when you want to display waveforms on inputs A and B while triggering on a third signal. You can choose external triggering with automatic triggering or with edge triggering.

1 Supply a signal to the red and black 4-mm banana jack inputs.

In this example you continue from the Trigger on Edges example. To choose the external signal as trigger source, continue as follows:




Observe that the key labels at the bottom of the screen have been adapted to allow selection of two different external trigger levels: 0.12 V and 1.2 V:



From this point the trigger level is fixed and is compatible with logic signals.

Triggering on Video Signals

To trigger on a video signal, first select the standard of the video signal you are going to measure:







Figure 32. Measuring Interlaced Video Signals



Trigger level and slope are now fixed.

Observe that the key labels at the bottom of the screen have been changed to allow further selection of specific video trigger settings.

Users Manual

Triggering on Video Frames


Use **FIELD 1** or **FIELD 2** to trigger either on the first half of the frame (odd) or on the second half of the frame (even).To trigger on the second half of the frame, do the following:



The signal part of the even field is displayed on the screen.


Triggering on Video Lines

Use **ALL LINES** to trigger on all line synchronization pulses (horizontal synchronization).



The signal of one line is displayed on the screen. The screen is updated with the signal of the next line immediately after the test tool triggers on the horizontal synchronization pulse.

To view a specific video line in more detail, you can select the line number. For example, to measure on video line 123, continue from step 6 as follows:




The signal of line 123 is displayed on the screen. Observe that the status line now also shows the selected line number. The screen is continuously updated with the signal of line 123.


Triggering on Pulses

Use pulse width triggering to isolate and display specific pulses that you can qualify by time, such as glitches, missing pulses, bursts or signal dropouts.


Detecting Narrow Pulses

To set the test tool to trigger on narrow positive pulses shorter than 5 ms, do the following:





The test tool is now prepared to trigger on narrow pulses only. Observe that the trigger key labels at the bottom of the screen have been adapted to set the pulse conditions:



All narrow positive pulses shorter than 5 ms are now displayed on the screen. (See Figure 33).

Tip

The test tool stores all triggered screens in the replay memory. For example, if you setup your triggering for glitches, you can capture 100 glitches with time stamps. Use the REPLAY key to look at all the stored glitches.





Figure 33. Triggering on Narrow Glitches

Finding Missing Pulses


The next example covers finding missing pulses in a train of positive pulses. In this example it is assumed that the pulses have a 100 ms distance between the rising edges. If the time accidently increases to 200 ms, a pulse is missing. To set the test tool to trigger on such missing pulses, let it trigger on gaps bigger than about 110 ms.

Do the following:



Triggering on Waveforms Triggering on Pulses






The test tool is now prepared to trigger on pulses that are more than a selectable time in duration. Observe that the trigger menu at the bottom of the screen has been adapted to set the pulse condition:



To set the pulse width to 110 ms, continue as follows:






Figure 34. Triggering on Missing Pulses

Using Memory and PC

About this Chapter

This chapter provides a step-by-step introduction to the general functions of the test tool that can be used in the three main modes: Scope, Meter, or Recorder. You will find information on computer communication at the end of this chapter.

Using the USB Ports

The test tool is provided with two USB ports:

- a USB-host port to connect an external flash memory drive ('USB-stick') for data storage.
- a mini-USB-B port which allows you to connect the test tool to a PC for remote control and data transfer under PC-control, see Using FlukeView[®] on page 79.

The ports are fully isolated from the input channels and are covered with dust covers when not in use.




Figure 35. Test Tool USB Connections



Saving and Recalling

You can:

 Save screens and setups to internal memory, and recall them again from memory. The test tool has 30 'screen and setup' memories, 10 'record and setup' memories, and 9 screen image memories. See also

•

- Table 1.
- Save up to 256 screens and setups to a USB memory device, and recall them again from memory.
- Name saved screens and setups according to your own preferences.
- Recall screens and recordings to analyze the screen image at a later date.
- Recall a setup to continue a measurement with the recalled operating configuration.

Notes

Saved data is stored in non-volatile Flash memory.

Not saved instrument data is stored in RAM memory and will be kept at least 30 seconds when the battery is removed when no power is supplied via the BC190 power adapter.

Table 1. Test Tool Internal Memory

Mode	Memory locations			
	30x	10x	9x	
METER	Setup +	-	Screen image	
	1 screen			
SCOPE	Setup +	Setup +	Screen image	
	1 screen	100 replay		
		screens		
SCOPE REC	-	Setup +	Screen image	
		record data		
TRENDPLOT	-	Setup +	Screen image	
		trendplot data		

Notes:

 In persistence mode, the most recent waveform will be saved, not all waveforms that build the persistence display.

Using Memory and PCSaving and Recalling

 In the displayed file list of stored data the following symbols are used:



setup + 1 screen



setup + replay screens/record data



setup + trendplot data



screen image (imagexxx.bmp


 a screen image can be copied to a USB stick connected to the test tool. The USB stick connected to a PC allows you to insert the image for instance into a text document. The copying function is available under SAVE and F4 – File OPTIONS. A screen image can not be recalled on to the screen.

Saving Screens with Associated Setups

To save for example a screen+setup in Scope mode, do the following:




From this point the screen is frozen.






ScopeMeter® Test Tool 190 Series II

Users Manual





To resume your measurements press



All memories in use

If no free memory locations are available a message pops up that proposes to you to overwrite the oldest data set. Do one of the following:

If you don't want to overwrite the oldest data set,

press F3 , the delete one or more memory locations, and save again.

If you want to overwrite the oldest data set,

- press F4

Editing names


To name the screen+setup according to your own preferences, continue from step 4 as follows:

5	F1	Open the EDIT NAME menu.
6	F2	Skip to a new character position.
7	ENTER	Select another character and press ENTER to accept your choice.
		Repeat 6 and 7 until done.
8	F1	Accept the name and return to the SAVE AS menu.



Highlight OK SAVE to save the actual screen using the edited name.

To modify the default name generated by the test tool, continue from step 8 as follows:



Notes

The 'record+setup' memory locations store more than just what is visible on the screen. In TrendPlot or Scope Record mode the full recording is saved. In scope mode you can save all 100 replay screens in a single record+setup memory location. The table below shows what you can store for the various test tool modes.

To save a TrendPlot press STOP first.



Saving Screens in .bmp Format (Print Screen)

To save a screen in bitmap (.bmp) format, do the following:



The file is saved using a fixed name (IMAGE) and a serial number, for example IMAGE004.bmp.

If no free memory locations are available a message pops up that proposes to you to overwrite the oldest data set. Do one of the following:


If you don't want to overwrite the oldest data set,

- press ^{F3}, then delete one or more memory locations, and save again.
- If you want to overwrite the oldest data set,
- press F4.

76


Deleting Screens with Associated Setups

To delete a screen and associated setup, do the following:



Recalling Screens with Associated Setups

To recall a screen+setup, do the following:




Observe that the recalled waveform is displayed and that **HOLD** appears on the screen. From this point you can use cursors and zoom for analysis or you can print the recalled screen.

To recall a screen as a reference waveform to compare it to an actually measured waveform, see Chapter 1 'Comparing Waveforms'.

Recalling a Setup Configuration

To recall a setup configuration, do the following:




From this point you continue in the new operating configuration.



Viewing Stored Screens

To scroll through the memories while looking at the stored screens, do the following:



Note:

In the VIEW mode the replay screens of a saved 'record+setup' cannot be viewed! Only the screen at the instant of saving can be reviewed in this way. To see all replay screens recall them from memory using the RECALL option.

Renaming Stored Screens and Setup Files

To modify the name of stored files, do the following:

1	SAVE	Display the SAVE key labels.		
	SAVE	SAVE RECALL 遠 → INT FILE OPTIONS		
2	F4	Open the FILE OPTIONS menu.		
3	F1	Select the source, internal memory (INT) or a USB device.		
4		Highlight RENAME.		
5	ENTER	Accept your choice and jump to the filename field.		
6		Highlight the file to be renamed.		

Using Memory and PC Using FlukeView®


7	ENTER	Open the RENAME menu.
8	F2	Skip to a new character position.
9	ENTER	Select another character. Repeat 8 and 9 until done.
10	F1	Accept the name and return to the RENAME menu.

Copying-Moving Stored Screens and Setup Files

You can copy or move a file from internal memory to a USB device or from a USB device to internal memory.

To copy or to move a file, do the following:

1	SAVE	Display the SAVE key labels.			
	5/WZ	SAVE	RECALL	Ō → INT	FILE OPTIONS
2	F4	Open the FILE OPTIONS menu.			
3	F1	Select the source, internal memory (INT) or a USB device. The other memory will become the destination.			



Using FlukeView®

With the FlukeView[®] software you can upload waveform data and screen bitmaps to your PC or notebook computer for further processing.

USB drivers for the test tool and a FlukeView[®] Demo version with restricted functionality are available on the CD-ROM included in the shipment.



ScopeMeter® Test Tool 190 Series II

Users Manual

Connecting to a Computer

To connect the test tool to a PC or notebook computer and use the FlukeView software for Windows® (SW90W), do the following:

- Use a USB-A to mini-USB-B interface cable to connect a computer to the mini USB PORT of the test tool (See Figure 36).
- Install the test tool USB drivers, see Appendix A.
- Install the FlukeView[®] Demo version. For information about installing and using the FlukeView[®].
 ScopeMeter[®] software see the FlukeView[®] Users Manual on the CD ROM.




Figure 36. Connecting a Computer

Notes

- The optional kit SCC290 contains an activation code to convert the FlukeView® Demo version into a fully operational version.
- A complete FlukeView® version can be ordered using ordering code SW90W. For use with the Fluke Series II ScopeMeter®test tools FlukeView®ScopeMeter®release V5.1 or higher is required.
- The test tool input channels are electrically isolated from the USB port.
- Remote control and data transfer via mini-USB is not possible while saving or recalling data to or from the USBstick.

Chapter 6 Tips

About this Chapter

This chapter gives you information and tips on how you can make the best use of the test tool.

Using the Standard Accessories

The following illustrations show the use of the standard accessories such as voltage probes, test leads, and the various clips.



Users Manual




Figure 37. HF Voltage Probe Connection Using Ground Spring

Warning

To avoid electrical shock or fire, do not connect the ground spring to voltages higher than 30 Vrms from earth ground.




Figure 38. Electronic Connections for Measurements Using Hook Clips and Alligator Clip Grounding

⚠ Marning

To avoid electrical shock, re-apply the insulation sleeve (Figure 1, item e) over the probe tip when the hook clip is not used. This also avoids the risk of accidently interconnecting the reference contact of multiple probes when groundleads are connected or avoids short-circuiting any circuitry via the bare ground ring of the probe..

Using the Independently Floating Isolated Inputs

You can use the independently floating isolated inputs to measure signals that are independently floating from each other.

Independently floating isolated inputs offer additional safety and measurement capabilities compared to inputs with common references or grounds.

Measuring Using Independently Floating Isolated Inputs

The test tool has independently floating isolated inputs. Each input section (A, B, C, D – A, B, METER INPUT) has its own signal input and its own reference input. The reference input of each input section is electrically isolated from the reference inputs of the other input sections. The isolated input architecture makes the test tool about as versatile as having four independent instruments. The advantages of having independently floating isolated inputs are:

• It allows simultaneous measurement of independently floating signals.

- Additional safety. Since the commons are not directly connected, the chance of causing short circuit when measuring multiple signals is greatly reduced.
- Additional safety. When measuring in systems with multiple grounds, the ground currents induced are kept to a minimum.

Because the references are not connected together inside the test tool, each reference of the used inputs must be connected to a reference voltage.

Independently floating isolated inputs are still coupled by parasitic capacitance. This can occur between the input references and the environment, and between the input references mutually (see Figure 39). For this reason, you should connect the references to a system ground or another stable voltage. If the reference of an input is connected to a high speed and / or high voltage signal, you should be aware of parasitic capacitance. (See Figure 39, Figure 41, Figure 42 and Figure 43.)

Note

The input channels are electrically isolated from the USB port and from the power adapter input.




Figure 39. Parasitic capacitance between probes, instrument and environment

Note:

Parasitic capacitances such as shown in Figure 39, 41 and 43 can cause ringing on the signal. Ringing can be limited by adding a ferrite bead around the probe cable.

Warning

To avoid electrical shock, always use the insulation sleeve (Figure 1, item e) or the hook clip when using the probe reference (ground) lead. The voltage applied to the reference lead is also present on the ground ring near the probe tip as shown in Figure 40. The isolation sleeve avoids the risk of accidently interconnecting the reference contact of multiple probes when groundleads are connected or short-circuiting any circuitry via the bare ground ring..



Figure 40. Probe Tip




Figure 41. Parasitic capacitance between analog and digital reference




Figure 42. Correct connection of reference leads

Users Manual




Figure 43. Wrong connection of reference leads

Noise that is picked up by reference lead D can be transmitted by parasitic capacitance to the analog input amplifier.

Using the Tilt Stand

The test tool is equipped with a tilt stand, allowing viewing from an angle while placed on a table. The typical position is shown in Figure 44.




Figure 44. Using the Tilt Stand

Note

An optional Hanging Hook, ordering code HH290, can be attached to the rear of the test tool. The hook enables you to hang the test tool at a convenient viewing position, for example a cabinet door or a separation wall.

Kensington®-lock

The test tool is provided with a security slot compatible with a Kensington[®] lock, see Figure 44.

The Kensington Security Slot along with a locking cable provides physical security against thefts of opportunity. Locking cables can be obtained from, for example, laptop computer accessory dealers.

Fixing the Hangstrap

A hang strap is supplied with the test tool. The figure below shows how to attach the strap correctly to the test tool.




Figure 45. Fixing the Hangstrap

Resetting the Test Tool

If you want to reset the test tool to the factory settings, without clearing the memories, do the following:

Turn the test tool off. 2 Press and hold. 3 Press and release.

The test tool turns on, and you should hear a double beep, indicating the reset was successful.

Release. USER

Suppressing Key Labels and Menu's

You can close a menu or hide key label at any time:



Hide any key label, press again to display the key label again (toggle function).


A displayed menu will be closed.

To display menus or key labels, press one of the yellow menu keys, e.g. the **scope** key.

You can also close a menu using the F4 CLOSE.

Changing the Information Language

During operation of the test tool, messages may appear at the bottom of the screen. You can select the language in which these messages are displayed. In this example you can select English or French. To change the language from English to French, do the following:




Note

The languages available in your test tool may differ from this example.

Adjusting the Contrast and Brightness

To adjust the contrast and backlight brightness, do the following:



Note

The new contrast and brightness are stored until a new adjustment is made.


To save battery power, the test tool is in economic brightness mode when operated on the battery. The high brightness intensity increases when you connect the power adapter.

Note

Using dimmed light lengthens battery power operating time. See Chapter 8 'Specifications', section 'Miscellaneous'.

Changing Date and Time

The test tool has a date and time clock. For example, to change the date to 19 April, 2013, do the following:





You can change the time in a similar way by opening the **Time Adjust...** menu (steps 2 and 3.)

Saving Battery Life

When operated on the battery, the test tool conserves power by shutting itself down. If you have not pressed a key for at least 30 minutes, the test tool turns itself off automatically.

Automatic power shutdown will not occur if TrendPlot or Scope Record is on, but the backlight will dim. Recording will continue even if the battery is low, and retention of memories is not jeopardized.


To save battery life without automatic power shutdown you can use the display AUTO-off option. The display will be turned off after the selected time (30 seconds or 5 minutes).

Note

If the power adapter is connected, there is no automatic power shutdown, and the display AUTO-off function is inactive.

Setting the Power Down Timer


Initially the power shutdown time is 30 minutes. You can set the power shutdown time to 5 minutes as following:





Setting the Display AUTO-off Timer

Initially the display AUTO-off timer is disabled (no automatic display turn off). You can set the display AUTO-off timer to 30 seconds or to 5 minutes as following:




The display will be turned off after the selected time is elapsed.

To turn on the display again do one of the following:

- Press any key. The Display will be visible again and the Display Auto-Off timer starts again. The display will be turned off again when the time has elapsed.
- Connect the power adapter; the Auto-Off timer is inactive now.

Changing the Auto Set Options

With the next procedure you can choose how auto set behaves when you press the **AUTO-MANUAL** (auto set) key.



If the frequency range is set to > 15 Hz, the Connect-and-View function responds more quickly. The response is quicker because the test tool is instructed not to analyze low frequency signal components. However, when you measure frequencies lower than 15 Hz, the test tool must be instructed to analyze low frequency components for automatic triggering:



When you press the **AUTO-MANUAL** (auto set) key, the input coupling can either be set to dc or left unchanged:



When you press the AUTO-MANUAL (auto set) key glitch capture can either be set to On or left unchanged:



Note

The auto set option for the signal frequency is similar to the automatic trigger option for the signal frequency. (See Chapter 4: "Automatic Trigger Options"). However, the auto set option determines the behavior of the auto set function and shows only effect when you press the auto set key.

Chapter 7 Maintaining the Test Tool

About this Chapter

This chapter covers basic maintenance procedures that can be performed by the user. For complete service, disassembly, repair, and calibration information, see the Service Manual.

Warning

- Have an approved technician repair the product.
- Use only specified replacement parts.
- Before carrying out any maintenance, carefully read the safety information at the beginning of this manual.

Cleaning the Test Tool

Warning

Remove the input signals before you clean the test tool.

Clean the test tool with a damp cloth and a mild soap. Do not use abrasives, solvents, or alcohol. These may damage the text on the test tool.

Storing the Test Tool

If you are storing the test tool for an extended period of time, charge the Li-ion (Lithium-ion) batteries before storing.



Charging the Batteries

At delivery, the Li-ion batteries may be empty and must be charged for 5 hours (with the test tool turned off) to reach full charge.

When battery power is used, the battery indicator at the top of the screen informs you about the condition of the batteries. The battery symbols are:

\[\begin{align*} \

To charge the batteries and power the instrument, connect the power adapter as shown in Figure 46. To charge the batteries more quickly, turn off the test tool.

Caution

To avoid overheating of the batteries during charging, do not exceed the allowable ambient temperature given in the specifications.

Note

No damage will occur if the power adapter is connected for long periods, e.g., during the weekend. The instrument then automatically switches to trickle charging.




Figure 46. Charging the Batteries

Alternatively, you may choose to exchange the battery (Fluke accessory BP290 or BP291) with a fully charged one, and use the external battery charger EBC290 (optional Fluke accessory).

Replacing the Battery Pack

Warning

Use only the Fluke BP290 (not recommended for 190-xx4) or BP291 for replacement!

When no adapter power is supplied, data not yet saved in the test tool memory is maintained if the battery is replaced within 30 seconds. To avoid loss of data, do one of the following actions before removing the battery:

- Store the data in the test tool's non volatile flash memory, on a computer or a USB stick.
- Connect the power adapter.

To replace the battery pack, proceed as follows:

- 1. Remove all probes and/or test leads
- 2. Remove the standup or fold it to the test tool
- 3. Unlock the battery cover (Figure 47)
- 4. Lift the battery cover and remove it, (Figure 48)
- 5. Lift one side of the battery and remove it (Figure 49)
- 6. Install a battery and close the battery cover.




Figure 47. Unlocking the Battery Cover




Figure 48. Removing the Battery Cover





Figure 49. Removing the Battery

Calibrating the Voltage Probes

To fully meet user specifications, you need to adjust the voltage probes for optimal response. The calibration consists of a high frequency adjustment and a dc calibration for 10:1 probes and 100:1 probes. The probe calibration matches the probe to the input channel.

This example shows how to calibrate the 10:1 voltage probes:






Figure 50. Adjusting Voltage Probes


Note

it is necessary to connect both the hook clip and the zero reference contact.

A message appears asking you whether to start the 10:1 probe calibration.

6 F4 Start the probe calibration.

A message appears telling you how to connect the probe. Connect the red 10:1 voltage probe to input A and to the probe calibration reference signal as shown in Figure 50.



The test tool automatically calibrates itself to the probe. During calibration you should not touch the probe. A message indicates when the DC calibration has completed successfully.

9 F4 Return.


Repeat the procedure for the blue 10:1 voltage probe on input B, the gray 10:1 voltage probe on input C and the green 10:1 voltage probe on input D.

Note

When using 100:1 voltage probes, choose 100:1 attenuation to perform an adjustment.

Displaying Version and Calibration Information

You can display version number and calibration date:



The screen gives you information about the model number with software version, the serial number, the calibration number with latest calibration date, and installed (software) options.


The test tool specifications (see Chapter 8) are based on a 1 year calibration cycle.

Recalibration must be carried out by qualified personnel.

Displaying Battery Information

The battery information screen provides information about the battery status and battery serial number.

To display the screen proceed from step 2 in the previous section as follows:



'Level' indicates the available battery capacity as a percentage of the present maximum battery capacity.

'Time to Empty' indicates a calculated estimate for the remaining operating time.

Parts and Accessories

The following tables list the user-replaceable parts and specific optional accessories for the various test tool models. For more optional accessories,

To order replacement parts or additional accessories, contact

Replacement Parts

Item		Ordering Code
Power Adapter available models:		
Universal Europe 230 V, 50 and 60 Hz		BC190/801
North America 120 V, 50 and 60 Hz	(UL)	BC190/813
United Kingdom 240 V, 50 and 60 Hz	_	BC190/804
Japan 100 V, 50 and 60 Hz		BC190/806
Australia 240 V, 50 and 60 Hz		BC190/807
Universal 115 V/230 V, 50 and 60 Hz *	(ŲL)	BC190/808
* UL listing applies to BC190/808 and BC190/820 with UL listed line plug adapter for North America.		BC190/820
The 230 V rating of the BC190/808 and BC190/820 are not for use		
in North America.		
For other countries, a line plug adapter complying with the		
applicable National Requirements must be used.		
Test Leads with test pins (one red, one black)		TL175



Replacement Parts (continued)

Voltage Probe Set (Red or Blue or Gray or Green) The set includes the following items (not available separately): • 10:1 Voltage Probe, 500 MHz (red or blue)	VPS410-II-R (red) VPS410-II-B (blue) VPS410-II-G (gray)	
 Hook Clip for Probe Tip (black) Ground Lead with Mini Alligator Clip (black) Ground Spring for Probe Tip (black) Insulation Sleeve (black) 	VPS410-II-V (green)	
See Figure 1 on page 2 for item reference.		
See the VPS410-II instruction sheet for voltage/CAT ratings.		

Users Manual

Replacement Parts (continued)

Replacement Set for Voltage Probe VPS410 and VPS410-II The set includes the following items (not available separately): 1x Hook Clip for Probe Tip (black) 1x Ground Lead with Mini Alligator Clip (black) 2x Ground Spring for Probe Tip (black) 2x Insulation Sleeve for Probe Tip (black) See Figure 1 on page 2 for item reference. See the VPS410 instruction sheet for voltage/CAT ratings.	RS400
BNC Feedthrough 50 Ohm (1 Watt) terminator (set of two pieces, black)	TRM50
Li-ion battery (26 Wh, not recommended for models 190-xx4)	BP290
Li-ion battery (52 Wh)	BP291
Hangstrap	946769



Optional Accessories

Item		Ordering Code		
Voltage Probe Set, designed for use with the Fluke 190-50x test tool.		VPS510-R (red)		
The set includes the following items (not available separately):		VPS510-B (blue)		
10:1 Voltage Probe, 500 MHz (red or blue or gray or green)		VPS510-G (gray)		
 Hook Clip for Probe Tip (black) Ground Lead with Mini Alligator Clip (black) Ground Spring for Probe Tip (black) 		VPS510-V (green)		
Insulation Sleeve (black)				
Probe Tip to BNC Adapter				
Replacement Set for Voltage Probe VPS510	(hr)	RS500		
The set includes the following items (not available separately):				
1x Hook Clip for Probe Tip (black)				
1x Ground Lead with Mini Alligator Clip (black)				
2x Ground Spring for Probe Tip (black)				
2x Insulation Sleeve for Probe Tip (black)				
2x Probe Tip to BNC Adapter				

Optional accessories (continued)

Probe Accessory Extension Set – VPS410, VPS410-II The set includes the following items (not available separately): 1x Industrial Alligator for Probe Tip (black) 1x 2-mm Test Probe for Probe Tip (black) 1x 4-mm Test Probe for Probe Tip (black) 1x Industrial Alligator for 4 mm Banana Jack (black)	AS400
 1x Ground Lead with 4-mm Banana Jack (black) Software & Carrying Case Kit. Set contains the following parts: FlukeView Software activation key, to convert the FlukeView demo version into an operational version. Hard Shell Carrying Case C290 	SCC290
FlukeView [®] ScopeMeter [®] Software for Windows [®] (full version)	SW90W
Hard Shell Carrying Case	C290
External Battery Charger, charges BP290/BP291 externally using BC190	EBC290
High Working Voltage Ruggedized Probe, 100:1, (available in 4 colors), 150 MHz, category rating 1000V CAT III / 600V CAT IV, working voltage (between probe tip and reference lead) 2000V in a CAT III environment/ 1200V in a CAT IV environment.	VPS420-R (red) VPS420-B (blue) VPS420-G (gray) VPS420-V (green)



Optional accessories (continued)

Hanging Hook; allows the test tool to be hung on a cabinet door or HH290			
separation wall.			
50 Ohm Coaxial Cable Set; includes 3 cables (1 red, 1 gray, 1 black), 1.5 m length with safety designed insulated BNC connectors.	PM9091		
50 Ohm Coaxial Cable Set; includes 3 cables (1 red, 1 gray, 1 black), 0.5 m length with safety designed insulated BNC connectors.	PM9092		
Safety designed BNC T-piece, Male BNC to dual female BNC (fully isolated).	PM9093		
BNC Feedthrough 50 Ohm (1 W) terminator (set of two pieces, black)	TRM50		
10:1 200 MHz voltage probe, 2.5 m.	VPS212-R (red), VPS212-G (gray)		
1:1 30 MHz voltage probe, 1.2 m.	VPS101		
Dual Banana Plug male to female BNC	PM9081		
Dual Banana Jack female to male BNC	PM9082		
Automotive Troubleshooting Kit	SCC298		
Service Kit Meter and Drive Applications	SKMD001		

Troubleshooting

The Test Tool Shuts Down After a Short Time

- The batteries may be empty. Check the battery symbol at the top right of the screen. A Symbol indicates that the batteries are empty and must be charged. Connect the BC190 power adapter.
- The test tool is still on but the 'display auto off' timer is active, see Chapter 6 'Setting the Display AUTO-off Timer'. To turn the display on press any key (restarts the 'display AUTO-off' timer), or connect the BC190 power adapter.
- The power down timer is active, see Chapter 6 'Setting the Power Down timer'. Press (1) to turn the test tool on.

The Screen Remains Black

Make sure that the test tool is on (press



You might have a problem with the screen contrast. the arrow keys to adjust the contrast.

The display 'auto off' timer is active, see Chapter 6 'Setting the Display AUTO-off Timer'. To turn the display on press any key (restarts the 'display AUTO off' timer), or connect the BC190 power adapter.

The Test Tool Cannot Be Turned Off

If the test tool cannot be turned off due to a software hangup, do the following:

Keep the ON/OFF key pressed for at least 5 seconds.

FlukeView® Does Not Recognize The Test Tool

- Make sure that the test tool is turned on.
- Make sure that the interface cable is properly connected between the test tool and the PC. Use only the test tool mini USB port for communication with a computer!
- Make sure that no SAVE/RECAL/COPY/MOVE action from or to a USB-stick is being performed.
- Make sure that the USB drivers have been correctly installed, see Appendix A.

Battery Operated Fluke Accessories Do Not Function

 When using battery operated Fluke accessories, always first check the battery condition of the accessory with a Fluke multimeter or follow the procedure given for that particular accessory.

Chapter 8 Specifications

Introduction

Performance Characteristics

FLUKE guarantees the properties expressed in numerical values with the stated tolerance. Specified non-tolerance numerical values indicate those that could be nominally expected from the mean of a range of identical ScopeMeter[®] test tools.

The Test Tool meets the specified accuracy 30 minutes and two complete acquisitions after power on. Specifications are based on a 1-year calibration cycle.

Environmental Data

The environmental data mentioned in this manual are based on the results of the manufacturer's verification procedures.

Safety Characteristics

The test tool has been designed and tested in accordance with Standards EN/IEC 61010-1, EN/IEC 61010-2-030, EN/IEC 61010-31, Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use.

This manual contains information and warnings that must be followed by the user to ensure safe operation and to keep the instrument in a safe condition. Use of this equipment in a manner not specified by the manufacturer may impair protection provided by the equipment.



Users Manual

Osci	llosco	ne
00011	10000	\sim

Isolated Inputs A,B, C and D (Vertical)

2 (A D)
2 (A, B)
4 (A,B,C,D)
500 MHz (-3 dB) 200 MHz (-3 dB) 100 MHz (-3 dB) 60 MHz (-3 dB)
00 WII 12 (-3 db)
<2 Hz (-3 dB) <5 Hz (-3 dB)
.20 MHz and 10 kHz
AC, DC
Normal, Inverted
20 mV to 1000 V/div 2 mV to 100 V/div

Dynamic Range
Waveform Positioning Range±4 divisions
Input Impedance on BNC, DC Coupled 4-channel models1 M Ω (±1 %)//14 pF (±2.25 pF) 2-channel models1 M Ω (±1 %)//15 pF (±2.25 pF)
⚠Max. Input Voltage For detailed specifications, see "Safety" on page 126
Vertical Accuracy±(2.1 % + 0.04 range/div) 2 mV/div:±(2.9 % + 0.08 range/div) For voltage measurements with 10:1 probe, add probe accuracy, see section '10:1 Probe' on page 129
Digitizer Resolution8 bits, separate digitizer for each input
Horizontal
Minimum Time Base Speed (Scope Record) 2 min/div Real Time Sampling Rate FLUKE 190-50x
5 ns to 4 μs /div (3 or 4 channels) up to 1.25 GS/s 2 ns to 4 μs /div (2 channels) up to 2.5 GS/s 1 ns to 4 μs /div (1 channel) up to 5 GS/s 10 μs to 120 s/div125 MS/s
FLUKE190-202,-204: 2 ns to 4 μs /div (1 or 2 channels)up to 2.5 GS/s 5 ns to 4 μs /div (3 or 4 channels)up to 1.25 GS/s 10 μs to 120 s/div

FLUKE 190-102, -104: 5 ns to 4 μs /div (all channels)up to 1.25 GS/s	Glitch Detection 4 μs to 120 s/divdisplays glitches as fast as 8 ns
10 μs to 120 s/div	Waveform DisplayA, B, C, D, Math (+, -, x, X-Y mode, spectrum) Normal, Average, Persistence, Reference
10 μ5 to 120 5/010125 1015/5	Time Base Accuracy±(100 ppm + 0.04 div)

Record Length (all models): see table below.

Table 2. Record Length (all models, Samples/points per input)

Mode	Glitch Detect On	Glitch Detect Off	Max. Samplerate	
Scope - Normal	300 min/max pairs	3k true samples compressed	190-062:	625 MS/s
		into 1 screen (300 samples per	190-102/104:	1.25 GS/s
		screen)	190-202/204:	2.5 GS/s (1 or 2 channels
Scope - Fast	300 min/max pairs	-		on)
Scope - Full	300 min/max pairs	10k true samples, compressed	190-204:	1.25 GS/s (3 or 4
		into 1 screen.		channels on)
		Use Zoom and Scroll to see	190-50x:	5 GS/s (1 channel on)
		waveform details	190-50x:	2.5 GS/s (2 channels on)
			190-504:	1.25 GS/s (3 or 4
				channels on)
Scope Record Roll	_	30k samples	4x 125 MS/s	
Trend Plot		> 18k min/max/ average values	Up to 5 meas	urements per second
		per measurement		

Users Manual

Trigger and Delay

	Video, Pulse Width, N-Cycle, External (190-xx2)
	External (100 XXZ)
Trigger Delay	up to +1200 divisions
Pre Trigger View	one full screen length
Delay	12 div to +1200 div
Max. Delay	48 s at 4 s/div

Trigger Modes.....Automatic, Edge,

Automatic Connect-and-View Trigger

Source	A, B, C, D
	EXT (190-xx2)
Slope	Positive, Negative, Dual

Edge Trigger

Screen UpdateFree Run, On Trigger, Single Sho	
SourceA, B, C, D, EXT (190-xx2	2)
SlopePositive, Negative, Dua	al
Trigger Level Control Range ±4 division	าร
Trigger Sensitivity DC to 5 MHz at >5 mV/div	on on on on on on on

Isolated External Trigger (190-xx2)

Bandwidth	10 kHz
Modes	Automatic, Edge
Trigger Levels (DC to 10 kHz))120 mV, 1.2 V

Video Trigger

StandardsPA	AL, PAL+, NTSC, SECAM, Non-interlaced
Modes	Lines, Line Select, Field 1 or Field 2
Source	A
Polarity	Positive, Negative
Sensitivity	0.7 division sync level

Pulse Width Trigger

Screen UpdateOn Trigger, Single Sho
Trigger Conditions <t,>T, =T (±10 %), ≠T(±10 %)</t,>
Source
PolarityPositive or negative pulse
Pulse Time Adjustment Range0.01 div. to 655 div with a minimum of 300 ns (<t,>T) or 500 ns (=T, ≠T)</t,>
a maximum of 10 s and a resolution of 0.01 div. with a minimum of 50 ns

Continuous Auto Set

Autoranging attenuators and time base, automatic Connect-and-View $^{\rm TM}$ triggering with automatic source selection.

Modes	
Normal	. 15 Hz to max. bandwidth
Low Frequency	1 Hz to max. bandwidth
Minimum Amplitude A, B, C, D	
DC to 1 MHz	10 mV
1 MHz to max. bandwidth	20 mV

Automatic Capturing Scope Screens

Capacity	100 Scope Screens
For viewing screens, see Replay fund	tion.

Users Manual

Automatic Scope Measurements

The accuracy of all readings is within \pm (% of reading + number of counts) from 18 °C to 28 °C. Add 0.1x (specific accuracy) for each °C below 18 °C or above 28 °C. For voltage measurements with 10:1 probe, add probe accuracy, see section '10:1 Probe' on page 129. At least 1.5 waveform period must be visible on the screen.

General

InputsA, B,	C and D
DC Common Mode Rejection (CMRR)	>100 dB
AC Common Mode Rejection at 50, 60, or 400 Hz	>60 dB

DC Voltage (VDC)

0 ()	
Maximum Voltage with 10:1 probedirect (1:1)	
Maximum Resolution with 10:1 probe direct (1:1)	
Full Scale Reading	999 counts
Accuracy at 4 s to 10 μs/div, FLU 2 mV/div5 mV/div to 100 V/div	±(1.5 % + 10 counts)

Accuracy at 4 s to 10 μs/div, FL	UKE 190-xx4
2 mV/div	±(3 % + 10 counts)
5 mV/div to 100 V/div	±(3 % + 6 counts)
Normal Mode AC Rejection at 5	0 or 60 Hz>60 dB

AC Voltage (VAC)

for maximum accuracy.

710 75/tago (7710)	
Maximum Voltage with 10:1 probedirect (1:1)	
Maximum Resolution with 10:1 probe direct (1:1)	
Full Scale Reading	999 counts
Accuracy, FLUKE 190-xx2 DC coupled: DC to 60 Hz±(1.5 %	√ +10 counts)
AC coupled, low frequencies: 50 Hz direct (1:1)±(1.5 % + 10 constant for the formula for the formula for the formula for the formula form	ounts) - 0.4% Il off point wil AC accuracy

Automatic Scope Measurements

AC or DC coupled, high frequencies: 60 Hz to 20 kHz \pm (2.5 % + 15 counts) 20 kHz to 1 MHz \pm (5 % + 20 counts) 1 MHz to 25 MHz \pm (10 % + 20 counts) For higher frequencies the instrument's frequency roll off starts affecting accuracy.
Accuracy, FLUKE 190-xx4 DC coupled: DC to 60 Hz
AC coupled, low frequencies: 50 Hz direct (1:1)±(3 % + 10 counts) - 0.6% 60 Hz direct (1:1)±(3 % + 10 counts) - 0.4% With the 10:1 probe the low frequency roll off point will be lowered to 2 Hz, which improves the AC accuracy for low frequencies. When possible use DC coupling for maximum accuracy.
AC or DC coupled, high frequencies: 60 Hz to 20 kHz \pm (4 % + 15 counts) 20 kHz to 1 MHz \pm (6 % + 20 counts) 1 MHz to 25 MHz \pm (10 % + 20 counts) For higher frequencies the instrument's frequency roll off starts affecting accuracy.
Normal Mode DC Rejection>50 dB
All accuracies are valid if:

The waveform amplitude is larger than one division At least 1.5 waveform period is on the screen

AC+DC Voltage (True RMS)

starts affecting accuracy.

Maximum Voltage with 10:1 probedirect (1:1)	1000 V
Maximum Resolution with 10:1 probedirect (1:1)	
Full Scale Reading	1100 counts
Accuracy, FLUKE 190-xx2 DC to 60 Hz	±(2.5 % + 15 counts) ±(5 % + 20 counts)
Accuracy, FLUKE 190-xx4 DC to 60 Hz60 Hz to 20 kHz20 kHz to 1 MHz1 1 MHz to 25 MHz	±(4 % + 15 counts) ±(6 % + 20 counts)

For higher frequencies the instrument's frequency roll off

Users Manual

Amperes (AMP)

Amperes (Amr)
With Optional Current Probe or Current Shunt
Rangessame as VDC, VAC, VAC+DC
Probe Sensitivity 100 μ V/A, 1 mV/A, 10 mV/A, 100 mV/A, 400 mV/A, 1 V/A, 10 V/A, and 100 V/A
Accuracysame as VDC, VAC, VAC+DC (add current probe or current shunt accuracy)
Peak
ModesMax peak, Min peak, or peak-to-peak
Maximum Voltage with 10:1 probe
Maximum Resolution with 10:1 probe
Full Scale Reading800 counts
Accuracy Max peak or Min peak±0.2 division Peak-to-peak±0.4 division
Frequency (Hz)
Range1.000 Hz to full bandwidth

Full Scale Reading......999 counts

Accuracy 1 Hz to full bandwidth \pm (0.5 % +2 counts) (4 s/div to 10 ns/div and 10 periods on the screen).		
Duty Cycle (DUTY)		
Range4.0 % to 98.0 %		
Resolution0.1 % (when period > 2 div)		
Full Scale Reading999 counts (3-digit display)		
Accuracy (logic or pulse) \pm (0.5 % +2 counts)		
Pulse Width (PULSE)		
Resolution (with GLITCH off) 1/100 division		
Full Scale Reading999 counts		
Accuracy 1 Hz to full bandwidth $\pm (0.5 \% + 2 \text{ counts})$		
Vpwm		
Purposeto measure on pulse width modulated signals, like motor drive inverter outputs		
Principlereadings show the effective voltage based on the average value of samples over a whole number of periods of the fundamental frequency		
Accuracy as Vrms for sinewave signals		

V/Hz

Purposeto show the measured Vpwm value (see Vpwm) divided by the fundamental frequency on Variable AC Motor Speed drives. Accuracy %Vrms + %Hz

Note

AC motors are designed for use with a rotating magnetic field of constant strength. This strength depends on the applied vottage (Vpwm) divided by the fundamental frequency of the appied voltage (Hz). The nominal Volt and Hz value are shown on the motor type plate.

Power (A and B, C and D)

	ratio between Watts and VA 0.00 to 1.00
	RMS reading of multiplication amples of input A or C (volts) and Input B or D (amperes)
Full Scale Reading	999 counts
	Vrms x Arms 999 counts
	$\sqrt{((VA)^2-W^2)}$ 999 counts

Phase (A and B, C and D)

Range	180 to +180 degrees
Resolution	1 degree
Accuracy 0.1 Hz to 1 MHz 1 MHz to 10 MHz	•

Temperature (TEMP)

With Optional Temperature Probe (°F not for Japan) Ranges (°C or °F).....--40.0 to +100.0 °

-100 to +250 ° -100 to +500 $^{\circ}$

-100 to +1000 ° -100 to + 2500 °

Probe Sensitivity......1 mV/°C and 1 mV/°F Accuracy±(1.5 % + 5 counts)

(add temperature probe accuracy for overall accuracy)

Decibel (dB)

dBV	dB relative to one volt
dBm	dB relative to one mW in 50 Ω or 600 Ω
dB on	VDC, VAC, or VAC+DC
Accuracy	same as VDC, VAC, VAC+DC

Users Manual

Meter Measurements for Fluke 190-xx4

Four of the Automatic Scope Measurements as defined above may be displayed at the same time, using larger screen area for convenient reading, suppressing the scope waveform information. For specifications see Automatic scope Measurements above.

Meter Measurements for Fluke 190-xx2

The accuracy of all measurements is within \pm (% of reading + number of counts) from 18 °C to 28 °C. Add 0.1x (specific accuracy) for each °C below 18 °C or above 28 °C.

Meter Input (Banana Jacks)

Input Coupling	DC
Frequency Response	DC to 10 kHz (-3 dB)
Input Impedance1 MΩ ((±1 %)//14 pF (±1.5 pF)
Max. Input Voltage	1000 V CAT III 600 V CAT IV
(For detailed spec	ifications, see "Safety")
Meter Functions	
Danaina	Auta Manual

Ranging	Auto, Manual
Modes	Normal, Relative

General

DC Common Mode Rejection (CMRR)	>100 dB
AC Common Mode Rejection at 50, 60, or 400 Hz .	>60 dB

Ohms (Ω) Ranges500.0 Ω , 5.000 $k\Omega$, 50.00 $k\Omega$, $500.0 \text{ k}\Omega$, $5.000 \text{ M}\Omega$, $30.00 \text{ M}\Omega$ Full Scale Reading Accuracy ±(0.6 % +6 counts) Measurement Current0.5 mA to 50 nA, ± 20 % decreases with increasing ranges Open Circuit Voltage<4 V **Continuity (CONT)** Detection of shorts of≥1 ms **Diode** Maximum Voltage Reading2.8 V Open Circuit Voltage.....<4 V Accuracy ±(2 % +5 counts)

Temperature (TEMP)

With Optional Temperature Probe
Ranges (°C or °F)40.0 to +100.0 °
-100.0 to +250.0 °
-100.0 to +500.0 °
-100 to +1000 °
-100 to + 2500 °
Probe Sensitivity1 mV/°C and 1 mV/°F
DC Voltage (VDC)
Ranges500.0 mV, 5.000 V, 50.00 V, 500.0 V, 1100 V
Full Scale Reading5000 counts
Accuracy±(0.5 % +6 counts)
Normal Mode AC Rejection at 50 or 60 Hz $\pm 1~\%>60~dB$
AC Voltage (VAC)
Ranges500.0 mV, 5.000 V, 50.00 V, 500.0 V, 1100 V
Full Scale Reading5000 counts
Accuracy
15 Hz to 60 Hz±(1 % +10 counts)
60 Hz to 1 kHz±(2.5 % +15 counts)
For higher frequencies the frequency roll off of the
Meter input starts affecting accuracy.
Normal Mode DC Rejection>50 dB
riorman mode Do riojodiominiminiminimin od ub

Users Manual

AC+DC Voltage (True RMS)

All accuracies are valid if the waveform amplitude is larger than 5 % of full scale.

Amperes (AMP)

Recorder

TrendPlot (Meter or Scope)

Chart recorder that plots a graph of min and max values of Meter or Scope measurements over time.

Measurement Speed	>5 measurements/s
Time/Div	5 s/div to 30 min/div
Record Size (min, max, avera	age)19200 points
Recorded Time Span	64 min to 546 hours
Time Reference	.time from start, time of day

Scope Record

Records scope waveforms in deep memory while displaying the waveform in Roll mode.

Source	Input A, B, C, D
Max. Sample Speed (4 ms/div to	o 1 min/div)125 MS/s
Glitch capture (4 ms/div to 2 mir	n/div)8 ns
Time/Div in normal mode	4 ms/div to 2 min/div
Record Size	.30k points per waveform
Recorded Time Span	4.8 s to 40 hours

Specifications

Zoom, Replay and Cursors

Acquisition Modes	Single Sweep
·	Continuous Roll
	Start/Stop on Trigger
Time Reference	time from start, time of day

Zoom, Replay and Cursors

Zoom

Zoom ranges from full record overview to detailed view of individual samples

Replay

Displays a maximum of 100 captured quad input Scope screens.

Replay modes Step by Step, Replay as Animation

Cursor Measurements

Cursor Modessingle vertical curso dual vertical cursor dual vertical cursors dual horizontal cursors (Scope mode	s
Markersautomatic markers at cross points	s
Measurementsvalue at cursor value at cursor :	2
difference between values at cursor 1 and 2	
time between cursors	
RMS between cursor	
Time of Day (Recorder modes	•
Time from Start (Recorder modes	;)
Rise Time, fall time	е
A x s (current over time between cursors	3)
V x s (voltage over time between cursors	;)
W x s (power over time between cursors using	ģ
powerwaveform AxB or CxD	_



Users Manual

Miscellaneous

Display

View Area	126.8 x 88.4 mm (4.99 x 3.48 inches)
Resolution	320 x 240 pixels
Backlight	LED (Temperature compensated)
Brightness	Power Adapter: 200 cd/m ²
	Battery Power: 90 cd/ m ²

Display Auto-OFF time (battery saving).......30 seconds, 5 minutes or disabled



FLUKE 190-xx4, -50x: Rechargeable Li-ion Battery (model BP291):

Operating Time	. up to 7 hours (Low Intensity)
Charging Time	5 hours
Capacity/Voltage	52 Wh / 10.8 V
FLUKE 190-062, -102, -202	: Rechargeable Li-ion Battery
(model BP290):	

Operating Time	up to 4 hours (Low Intensity)
Charging Time	2.5 hours
Capacity/Voltage	26 Wh / 10.8 V

Rechargeable Li-ion Battery (model BP 290 and BP291): Life Time (> 80 % capacity).......300x charge/discharge

Allowable ambient

temperature during charging: 0 to 40 °C (32 to 104 °F)

Auto power down

time (battery saving):.....5 min, 30 min or disabled

Power Adapter BC190:

- BC190/801 European line plug 230 V ±10 %
- BC190/813 North American line plug 120 V ±10 %
- BC190/804 United Kingdom line plug 230 V ±10 %
- BC190/806 Japanese line plug 100 V ±10 %
- BC190/807 Australian line plug 230 V ±10 %
- BC190/808 Universal switchable adapter 115 V ±10 % or 230 V ±10 %, with plug EN60320-2.2G
- \bullet BC190/820 Universal adapter 100...240 V ± 10 %, with plug EN60320-2.2G

Line Frequency 50 and 60 Hz

Probe Calibration

Manual pulse adjustment and automatic DC adjustment with probe check

Internal Memory

Number of Scope Memories
Number of Recorder Memories
a 2/4 channel input TrendPlot
 a 2/4 channel input Scope Record
 100 2/4 channel input Scope screens (Replay)
Number of Screen Image memories9 Each memory can contain one screen image

External Memory

USB stick, 2GB max

Mechanical

Size	2	65 x 190	x 70 mm	(10.5 x 7.5	x 2.8 in)
Weigh	t				
FLUI	KE 190-xx4	2.2	kg (4.8 lb	s) includin	g battery
FLUI	KE 190-5xx	2.2	kg (4.8 lb	s) includin	g battery
FLUI	KE 190-xx2	2.1	kg (4.6 lb	s) including	g battery

Interface Ports

Two USB ports provided. Ports are fully insulated from instrument's floating measurement circuitry.

- A USB-host port directly connects to external flash memory drive ('USB-stick', ≤ 2 GB) for storage of waveform data, measurement results, instrument settings and screen copies.
- A mini-USB-B is provided which allows for interconnection to PC for remote control and data transfer using SW90W (FlukeView[®] software for Windows [®]).
- One port can be active at the same time, therefor remote control and data transfer via mini-USB is not possible when saving or recalling data to or from the USB-stick.

Users Manual

Environmental

EnvironmentalMIL-PRF-28800F, Class 2
Temperature Operating: battery installed
Humidity (Maximum Relative)
Operating: 0 to 10 °C (32 to 50 °F)noncondensing 10 to 30 °C (50 to 86 °F)
Altitude
Operating: CATIII 600V, CATII 1000V 3 km (10 000 feet) CATIV 600V, CATIII 1000V 2 km (6 600 feet) Storage
Vibration (Sinusoidal) max. 3 g
Vibration (Random) 0.03 g ² /Hz
Shock max. 30 q

Electromagnetic Environment	EN/IEC61326-1
•	(Portable Equipment)
Enclosure Protection	IP51_ref: IFC60529

Standards

Conforms to

Electromagnetic Compatibility.......Applies to use in Korea only.

Class A Equipment (Industrial

Broadcasting &

Communication Equipment) [1]

[1] This product meets requirements for industrial (Class A) electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and is not to be used in homes.

⚠ Safety

Designed for 1000 V Measurement Category III, 600 V Measurement Category IV (with supplied 10:1 probes) per:

- EN/IEC 61010-1, Pollution Degree 2
- EN/IEC61010-2-030
- IEC61010-031

⚠ Max. Input Voltages

BNC Input A, B, (C, D) directly	300 V CAT IV
Via VPS410	1000 V CAT III
	600 V CAT IV
METER/EXT banana input	1000 V CAT III
	600 V CAT IV

Max. Floating Voltage

FLUKE 190-xxx (test tool or test tool + VPS410)

From any terminal to earth ground	. 1000 V CAT III
	600 V CAT IV
Between any terminal	. 1000 V CAT III
	600 V CAT IV

FLUKE 190-xxx + VPS510

From any terminal to earth ground	300	V	CAT	Ш
Between any terminal	300	V	CAT	Ш

Voltage ratings are given as "working voltage". They should be read as Vac-rms (50-60 Hz) for AC sinewave applications and as Vdc for DC applications.



Users Manual




Figure 51. Max. Input Voltage vs. Frequency




Figure 52. Safe Handling: Max. Voltage Between Scope References, and Between Scope References and earth ground.

10:1 Probe VPS410

Accuracy

For further probe specifications see the instruction sheet supplied with the VPS410 probe set.

Users Manual

Electromagnetic Immunity

The Fluke 190 Series II test tools, including standard accessories are compliant to EN61326-1, with the addition of the following table

Scope Mode (10 ms/div: Waveform disturbance with VPS410 voltage probe shorted. (Table 3)

Table 3. (E = 3V/m)

Frequency	No Disturbance	Disturbance < 10% of full scale	Disturbance > 10% of full scale
80 MHz – 450 MHz	≥ 500 mV/d	100, 200 mV/div	2, 5, 10, 20, 50 mV/div
450 MHz – 1 GHz	All ranges		
1.4 GHz – 2 GHz	All ranges		
2 GHz – 2.7 GHz (1 V/m)	All Ranges		

Appendices

Appendix	Title	Page
Α	Installing USB Drivers	A-
В	Battery Pack MSDS	B-

Appendix A Installing USB Drivers

Introduction

The Fluke 190 Series II ScopeMeter® comes with a USB interface (connector: USB type "B mini") for communication with a computer. To be able to communicate with the instrument, drivers need to be loaded onto the computer. This document describes how to install the drivers on a Windows XP computer. Installing on other Windows versions will be similar.

Drivers for Windows XP, Vista and Win 7 are available from the Windows Driver Distribution Center, and can be downloaded automatically if your computer is connected to the internet.

The drivers have passed Windows Logo Verification and are signed by Microsoft Windows Hardware Compatibility Publisher. This is required for installation on Win 7.

Note

The Fluke 190 Series II instrument requires two drivers to be loaded in sequence.

- 1st it requires installation of the Fluke 190
 ScopeMeter[®] USB driver
- 2nd it requires installation of the Fluke USB Serial port

Both of these drivers need to be installed to be able to communicate with the ScopeMeter[®]!



Users Manual

Installing the USB Drivers

To install the USB drivers, do the following:

1 Connect the Fluke 190 Series II instrument to the PC. The USB cable can be plugged in and out (hot-swap) when both the computer and the instrument are on. It is not required to power off.

When there is no driver loaded for the Fluke 190 Series II instrument, Windows will show that there is New Hardware detected, and the Wizard for installing new hardware will open.

Depending on your PC settings, Windows may ask for permission to search the Windows Update Web site on the internet for the latest revision. When you have an internet connection it is advised to select "Yes" and click Next. To install drivers from the CD-ROM or from a location on the hard drive select "No, not this time".





2 In the following window click 'Next' to install the software automatically.

Windows will download the drivers automatically from the Windows Driver Distribution Center on the internet. If there is no connection to the internet, you need to load the CD-ROM, supplied with the ScopeMeter®, which contains the drivers.

3 Follow the instructions on screen.

When the driver has finished installation click 'Finish' to complete the first step of the driver installation.







Users Manual

4 After completing the first step the New Hardware Wizard will start again to install the USB Serial Port Driver.


Click 'Next' to install the software automatically.


Windows will download the drivers automatically from the Windows Driver Distribution Center on the internet. If there is no connection to the internet, you need to load the CD-ROM, supplied with the ScopeMeter[®], which contains the drivers.

5 Follow the instructions on screen.

When the driver finished installation click 'Finish' to complete the final step of the driver installation.

You are now ready to use the ScopeMeter[®] with FlukeView[®] Software SW90W from version V5.1 onwards.








Appendices Installing USB Drivers

6 To check if the drivers are loaded properly, connect the ScopeMeter® 190 Series II to your computer and open the Device Manager. (See the Help file of your computer how to open the device manager for your Windows version)

From the device manager click on the + sign to Expand the 'Universal Serial Bus controllers'. The 'Fluke 190 ScopeMeter®', should be listed here.

From the device manager click on the + sign to Expand the 'Ports (COM & LPT)' Universal Serial Bus controllers. The 'Fluke USB Serial Port COM(5)' should be listed here.

Note that the COM port number may differ and is automatically assigned by Windows.





Users Manual

Notes

- Sometimes application software may require a different port number. (for example in the range Com 1..4).
 In this situation the COM port number can be changed manually.
 To manually assign a different COM port number right click on 'Fluke USB Serial Port COM(5)' and select properties. From the Properties menu, select the Port Settings tab, and click 'Advanced...' to change the port number.
- 2) Sometimes other applications installed on the PC automatically occupy the newly created port. On most situations it is sufficient to unplug the Fluke 190 Series II ScopeMeter[®] USB cable shortly and then reconnect the cable.

