FLUKE®

753/754

Documenting Process Calibrator

Users Manual

July 2011 Rev. 1, 8/12 © 2011-2012 Fluke Corporation. All rights reserved. Specifications are subject to change without notice. All product names are trademarks of their respective companies.



LIMITED WARRANTY AND LIMITATION OF LIABILITY

This Fluke product will be free from defects in material and workmanship for three years from the date of purchase. This warranty does not cover fuses, disposable batteries, or damage from accident, neglect, misuse, alteration, contamination, or abnormal conditions of operation or handling. Resellers are not authorized to extend any other warranty on Fluke's behalf. To obtain service during the warranty period, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that Service Center with a description of the problem. THIS WARRANTY IS YOUR ONLY REMEDY. NO OTHER WARRANTIES, SUCH AS FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSED OR IMPLIED. FLUKE IS NOT LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, ARISING FROM ANY CAUSE OR THEORY. Since some states or countries do not allow the exclusion or limitation of an implied warranty or of incidental or consequential damages, this limitation of liability may not apply to you.

11/99



Table of Contents

Title	Page
Introduction	1
Safety Information	2
Standard Equipment	6
Functions	9
Get Started	11
Operation Features	13
Input and Output Jacks	13
Buttons	15
Display	18
Strap and Stand	21
The Battery	
Charge the Battery	22
Battery Charge Level	23
Battery Life	23

i



753/754Users Manual

Preserve Battery Life	25
The Battery Charger	25
Display Languages	26
Display Intensity	26
Date and Time	26
The Backlight2	28
Personalize the Product	28
Measure Mode	29
Measurement Ranges	29
Electrical Parameter Measurement	30
Continuity Test	32
Pressure Measurement	32
Temperature Measurement	36
Thermocouple Use	36
Resistance-Temperature Detectors (RTDs)	39
Measurement Scale	43
Linear-Output Transmitters	43
	43
	44
Using the 700-IV Current Shunt	44
Damping Measurements	45
Source Mode	45
Source Electrical Parameters	45
4 to 20 mA Transmitter Simulation	48
Supply Loop Power 5	50
Source Pressure	52
Thermocouple Simulation	55
RTD Simulation	56
	59

ii

Contents (continued)

Source Scale	
Linear-Responding Transmitters	61
Square-Root Process Variables	
Step and Ramp the Output Value	62
Manual Step Use	62
Auto Step Use	62
Ramp the Output	63
Simultaneous Measure/Source	66
Process Instrument Calibration	69
Generate "As Found" Test Data	69
Transmitter Adjustment	74
"As Left" Test Run	75
Test Comments	75
Calibrate a Delta-Pressure Flow Instrument	75
Switch Calibration	
Transmitter Mode	79
Memory Operations	
Save Results	80
Review the Memory	
Log Data	83
Record Min and Max Measurements	
Run a Preloaded Task	
Clear the Memory	87
The Calculator	
Save to and Recall from the Registers	88
Use the Calculator to Set the Source Value	
Quick Guide to Applications	
	101

iii



753/754 Users Manual

Battery Replacement	101
Clean the Product	101
Calibration Data	102
In Case of Difficulty	102
Service Center Calibration or Repair	102
User-Replaceable Parts	102
Accessories	104
Specifications	106
General Specifications	106
Environmental Specifications	106
Standards and Agency Approval Specifications	106
Detailed Specifications	107
DC mV Measurement	107
DC Voltage Measurement	108
AC Voltage Measurement	108
DC Current Measurement	109
Resistance Measurement	109
Continuity Testing	109
Frequency Measurement	110
±DC Voltage Output	110
+DC Current Source	111
+DC Current Simulate (External Loop Power)	111
Resistance Sourcing	111
Frequency Sourcing	112
Temperature, Thermocouples	113
Temperature, Resistance Temperature Detectors	116
Loop Power	117

iv

List of Tables

Table	Title P	Page
1.	Symbols	4
2.	Summary of Source and Measure Functions	
3.	Input/Output Jacks and Connectors	. 13
4.	Buttons	16
5.	Elements of a Typical Display	20
6.	Typical Battery Life	. 23
7.	Thermocouple Types Accepted	37
8.	RTD Types Accepted	. 39
9.	Simultaneous MEASURE/SOURCE Functions with Loop Power Disabled	. 67
10.	Simultaneous MEASURE/SOURCE Functions with Loop Power Enabled	. 68
11.	Duration Limits	. 84
12.	Replacement Parts	. 103

 ν



List of Figures

Figure	Title	Page
1.	Standard Equipment	
2.	Jumper Connections	12
3.	Measure/Source Example	12
4.	Input/Output Jacks and Connectors	
5.	Buttons	15
6.	Elements of a Typical Display	19
7.	Stand Use and Strap Attachment	21
8.	Battery Removal and Charger Use	24
9.	Time and Date Display	27
10.	Edit the Date Format	27
11.	Personalize the Product	28
12.	Electrical Measurement Connections	31
13.	Gage and Differential Pressure Modules	33
14.	Pressure Measurement Connections	
15.	Temperature Measurement with a Thermocouple	38

vii



753/754Users Manual

16.	Correct Jumper Use	41
17.	Temperature Measurement with an RTD	42
18.	Electrical Source Connections	47
19.	Connections fo Simulate a 4 to 20 mA Transmitter	49
20.	Connections to Supply Loop Power	
21.	Connections to Source Pressure	54
22.	Connections to Simulate a Thermocouple	57
23.	Connections to Simulate an RTD	58
24.	Source Temperature with Drywell	60
25.	Ramp Screen	64
26.	Check a Relay Output Trip Alarm	65
27.	Measure and Source Screen	66
28.	Process Instrument Calibration Screen	70
29.	Process Instrument Calibration Screen 2	70
30.	Calibrate a Thermocouple Temperature Transmitter	71
31.	Calibration Parameters Screen	72
32.	Measure and Source Screen for Calibration	73
33.	Error Summary Screen	73
34.	As Left Data Screen	75
35.	Switch Terminology	76
36.	Saved Data Screen	81
37.	Additional Data Input Screen	81
38.	Alphanumeric Entry Window	82
39.	Memory Review Screen	83
40.	Data Log Parameters Screen	83
41.	Start Logging Screen	85
42.	Min Max Screen	86
43.	Chart Recorder Calibration	89
44.	Voltage Drop Measurement	89

viii

Contents (continued)

45.	Monitor AC Line Voltage and Frequency	90
46.	Current-to-Pressure (I/P) Transmitter Calibration	91
47.	Output Current of a Transmitter Measurement	92
48.	Precision Resistor Measurement	93
49.	Resistance Source	93
50.	Checking a Switch	94
51.	Tachometer Examination	94
52.	Analog and HART Pressure Transmitter Connection	95
53.	mV to Current Transmitter Calibration	96
54.	Vortex Sheding Flowmeter Check	97
55.	HART and Analog RTD Transmitter Connections	98
56.	Analog and HART Thermocouple Transmitter Connections	99
57	Transmitter HART- Comm Only	100

ix



Introduction

The 753 and 754 Documenting Process Calibrators (the Product) are battery-powered, hand-held instruments that measure and source electrical and physical parameters. In addition, the 754 supplies basic HART® communicator functions when used with HART-capable transmitters. See the 754 HART Mode Users Guide for instructions on how to use the HART communication feature.

The Product helps troubleshoot, calibrate, verify, and document work performed on process instruments.

Note

All figures in this manual show the 754.



753/754

Users Manual

Safety Information

A **Warning** identifies conditions and actions that pose hazards to the user; a **Caution** identifies conditions and actions that may damage the Product or the equipment under test.

⚠ Marning

To prevent personal injury, use the Product only as specified, or the protection supplied by the Product can be compromised.

To prevent possible electrical shock, fire, or personal injury:

- Read all safety Information before you use the Product.
- Carefully read all instructions.
- Use only correct measurement category (CAT), voltage, and amperage rated probes, test leads, and adapters for the measurement.
- The battery must be locked in place before you operate the Product.
- Recharge the battery when the low battery indicator shows to prevent incorrect measurements.
- Do not apply more than the rated voltage, between the terminals or between each terminal and earth ground.

- Limit operation to the specified measurement category, voltage, or amperage ratings.
- Do not exceed the Measurement Category (CAT) rating of the lowest rated individual component of a Product, probe, or accessory.
- Measure a known voltage first to make sure that the Product operates correctly.
- Do not touch voltages > 30 V ac rms, 42 V ac peak, or 60 V dc.
- Do not use the Product around explosive gas, vapor, or in damp or wet environments.
- Do not use and disable the Product if it is damaged.
- Do not use the Product if it operates incorrectly.
- Keep fingers behind the finger guards on the probes.
- Remove all probes, test leads, and accessories that are not necessary for the measurement.
- Only use probes, test leads, and accessories that have the same measurement category, voltage, and amperage ratings as the Product.

Documenting Process Calibrators

Safety Information

- Connect the common test lead before the live test lead and remove the live test lead before the common test lead.
- Use only current probes, test leads, and adapters supplied with the Product.
- Do not touch the probes to a voltage source when the test leads are connected to the current terminals.
- Use only cables with correct voltage ratings.

- Do not use test leads if they are damaged. Examine the test leads for damaged insulation, exposed metal, or if the wear indicator shows. Check test lead continuity.
- Examine the case before you use the Product. Look for cracks or missing plastic. Carefully look at the insulation around the terminals.
- Always put the stackable end of the test lead into a terminal of the Product.



753/754 Users Manual

Symbols used on the Product and in this manual are explained in Table 1.

Table 1. Symbols

Symbol	Meaning	Symbol	Meaning
Ţ	Earth ground	4	Common (LO) Input equipotentiality
~	AC- alternating current	© ® US	Conforms to relevant North American Safety Standards.
	DC- direct current	CE	Conforms to European Union directives.
Λ	Risk of danger. Important information. See manual.	<u> </u>	Pressure
	Hazardous voltage. Risk of electrical shock.	<u>X</u>	This product complies with the WEEE Directive (2002/96/EC) marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste. Product Category: With reference to the equipment types in the WEEE Directive Annex I, this product is classed as category 9 "Monitoring and Control Instrumentation" product. Do not dispose of this product as unsorted municipal waste. Go to website for recycling information.

Documenting Process Calibrators Safety Information

Table 1. Symbols (cont.)

Symbol	Meaning	Symbol	Meaning
4	Application around and removal from HAZARDOUS LIVE conductors is permitted.	N10140	Conforms to relevant Australian standards.
	Double insulated	TLV	German certifying body.
CAT II	CAT II equipment is designed to protect against transients from energy-consuming equipment supplied from the fixed installation, such as TVs, PCs, portable tools, and other household appliances.		



753/754

Users Manual

Standard Equipment

Items included with the Product are listed below and shown in Figure 1. If the Product is damaged or something is missing, contact the place of purchase immediately.

- Battery with integrated charger/power supply and international adapters
- Printed multilingual 753/754 Getting Started Manual
- 753/754 Manual CD containing multilingual Users Manuals
- Three sets of TP220-1 test probes
- Three sets of 75X industrial test leads with stackable ends
- Three pairs of 754 Alligator Clip Set (extended tooth)
- Two sets of AC280 Suregrip Hook Clips (red and black)

- Adjustable quick-release strap
- Jumper for three-wire RTD measurement connections
- USB Cable: 6 ft. type A to type mini-B
- HART communications cable (754)
- Calibration Manual (available from website)
- Sample DPCTrack2 application software
- NIST-traceable Certificate of Calibration
- TC Input Cap



Documenting Process Calibrator Standard Equipment




Figure 1. Standard Equipment

JKSU1T.eps

753/754 Users Manual




Figure 1. Standard Equipment (cont)

gks02f.eps

Documenting Process CalibratorFunctions

Functions

A summary of functions supplied by the Product is shown in Table 2. More features include:

- Analog display for easy to read measurements when inputs are unstable.
- Localized display (5 languages). See "Display Languages".
- Thermocouple (TC) input/output jack and internal isothermal block with automatic reference-junction temperature compensation. Or manually record an external temperature reference.
- Test results storage.
- Data logging. Automatically log up to 8,000 data points.
- A USB computer interface to upload or download tasks, lists, and results.
- Automatic calibration procedures for transmitters and limit switches when you use split screen MEASURE/SOURCE mode.

- Transmitter mode in which the Product can be configured to emulate the functions of a process instrument.
- Calculator feature with square-root function, and accessible registers that contain measure and source values.
- Damp feature (smoothes the last several readings), with display indicator of damped status.
- Display of measurements in engineering units, percent of scale, square-law inputs, or custom units.
- Min/Max feature captures and shows minimum and maximum measured levels.
- Set source values to engineering units, percent of scale, square-law outputs, or custom units.
- Manual and automatic stepping and an output ramp feature for testing limit switches. Trip detect is either a 1 V change or a continuity status change (Open or Short) from one ramp increment to the next.

For performance testing and calibration instructions, download the *753/754 Calibration Manual* from Fluke's website.



Table 2. Summary of Source and Measure Functions

Function Measure Management of Source and Measure Functions		
Function	Measure	Source
VDC Volts dc	0 V to ±300 V 0 V to ±15 V (10 mA max)	
Vac Volts ac	0.27 V to 300 V rms, 40 Hz to 500 Hz	No sourcing
<u> </u>	0.1 V to 30 V p-p sine wave, or 15 V peak 1 Hz to 50 kHz sine wave, 0.01 Hz square wave	
n Resistance	0 Ω to 10 k Ω	0 Ω to 10 k Ω
ma dc Current	0 mA to 100 mA	0 to 22 mA sourcing or sinking
Continuity	Beep and the word Short indicates No sourcing continuity	
Tc Thermocouple	Types E, N, J, K, T,	B, R, S, C, L,U, BP, or XK
Types L, N, 3, N, 1, B, N, 3, C, L, 0, B1, Ol XN		
Pressure [1] 29 modules ranging from 0 to 1 inch H ₂ O (250 Pa) to 0 to 10,000 psi (69,000 kPa)		
SETUP Loop Power	26 V	
[1] Use an external hand pump or other pressure source as a pressure stimulus for the source pressure function.		

Documenting Process Calibrator Get Started

Get Started

∧ Marning

To prevent possible electrical shock, fire, or personal injury:

- Remove circuit power before you connect the Product in the circuit when you measure current. Connect the Product in series with the circuit.
- Do not touch exposed metal on banana plugs, they can have voltages that could cause death.
- Disconnect power and discharge all highvoltage capacitors before you measure resistance or continuity.

A brief getting started exercise follows:

 After you unpack the Product, charge the battery for 8 hours (if the battery is outside of the Product, charge for 5 hours). For more information, see "The Battery". The Battery will only charge if the Product is off.

- 2. Connect voltage output to the voltage input. To do this connect the left pair of jacks (V Ω RTD SOURCE) to the right pair of jacks (V MEASURE). See Figure 2.
- 4. Push to show the SOURCE screen. The Product still measures dc voltage and the active measurement is at the top of the display.
- 5. Push voc to select dc voltage sourcing. Push 5 on the keypad and ENTER to begin sourcing 5.0000 V dc.
- 6. Push seems to go to the split-screen, simultaneous MEASURE/SOURCE mode. The Product simultaneously sources dc volts and measures dc volts. The measurement readings are shown on the top display, and the active source value on the bottom display as shown in Figure 3.






Figure 2. Jumper Connections




Figure 3. Measure/Source Example

Operation Features

Input and Output Jacks

Figure 4 shows the input and output jacks and connectors. Table 3 explains their use.

Table 3. Input/Output Jacks and Connectors

No.	Name	Description
1)	HART jack (754 only)	Connects the Product to HART devices.
2	Pressure module connector	Connects the Product to a pressure module.
3	TC input/output	Jack to measure or simulate thermocouples. This jack accepts a miniature polarized thermocouple plug with flat, in-line blades spaced 7.9 mm (0.312 in) center to center.
4,5	<u></u> MEASURE V jacks	Input jacks to measure voltage, frequency, or three- or four-wire RTDs (Resistance Temperature Detectors).
6,7	$\underline{\Lambda}$ SOURCE mA, MEASURE mA Ω RTD jacks	Jacks to source or measure current, measure resistance and RTDs, and supply loop power.
8,9	$\underline{\Lambda}$ SOURCE V Ω RTD jacks	Output jacks to source voltage, resistance, frequency, and to simulate RTDs.
10	Battery Charger jack	Jack for the battery charger/universal power supply (referred to as the battery charger throughout this manual). Use the battery charger for bench-top applications where ac line power is available.
11)	USB port (Type 2)	Connects the Product to a USB port on a PC.






Figure 4. Input/Output Jacks and Connectors

gks05f.eps

Documenting Process CalibratorOperation Features

Buttons

Figure 5 shows the Product buttons and Table 4 tells their functions. The softkeys are the four (F1-F4) blue buttons below the display. Softkey functions are defined by the labels that show above the softkey during operation. Softkey labels and other display text are shown in this manual in bold type, for example, **Choices**.




Figure 5. Buttons



753/754 Users Manual

Table 4. Buttons

Item	Button	Description		
1)		Turns the Product on and off.		
2	mA	Selects mA (current) measure or source function. For loop power on/off, go to the Setup mode.		
3	VDC	Selects the dc voltage function in MEASURE mode, or selects dc voltage in SOURCE mode.		
4	TC	Selects TC (thermocouple) or RTD (resistance temperature detector) measurement or sourcing functions.		
(5)	<u> </u>	Selects the pressure measurement or source function.		
6	F1 F2 F3 F4	Softkeys. Does the function specified by the label above each softkey on the display.		
7	\$	Adjusts the backlight intensity (three levels).		
8	SETUP	Enters and exits Setup mode to change operating parameters.		
9	(754) RANGE (753)	(754) Toggles between HART communication mode and analog operation. In calculator mode, this key supplies the square root function.(753) Adjusts the Range of the Product.		



Documenting Process CalibratorOperation Features

Table 4. Buttons (cont)

Item	Button	Description	
10	♠, ♥, ∅, ₽	Push o or to increase display intensity. Push o or to decrease intensity (seven levels).	
		Make choices from lists on the display.	
		Increase or decrease the source level when using the step feature.	
		In calculator mode, provides arithmetic functions (+ - \div ×).	
11)	CLEAR (ZERO)	Clears a partial data entry, or prompts for output value when in the SOURCE mode. When you use a pressure module, zeros the pressure module indication.	
12	ENTER	Completes a numeric entry when a source value is set, or confirms a choice in a list. In calculator mode, acts as the equals arithmetic operator (=).	
13	Ω	Toggles between resistance and continuity functions in MEASURE mode, or selects the resistance function in SOURCE mode.	
14)	VAC Hz Л	Toggles between ac voltage and frequency functions in MEASURE mode, or selects frequency output in SOURCE mode.	
15	Numeric keypad	Used when a numeric entry is necessary.	
16	MEASURE SOURCE	Cycles the Product through MEASURE, SOURCE, and MEASURE/SOURCE modes.	



753/754

Users Manual

Display

Figure 6 and Table 5 show a typical display. The display shown is MEASURE mode. Near the top of the display is "Source Off." This display area shows what is happening in the other mode (SOURCE or MEASURE). The other parts of the display are:

- Status Bar: Shows the time and date, and the status of Loop Power, Auto Battery Save, and Backlight Timeout; all of which are set in Setup mode. The selected HART channel (if HART is active-754 only) and low-battery and backlight-on symbols are also show here.
- Mode Indicator: Shows if the Product is in MEASURE or SOURCE mode. In split screen MEASURE/SOURCE mode, there is a Mode Indicator for each window.

- Measured Value: Shows the measured value in a selection of engineering units or percent of scale.
- Range Status: Shows if Auto Range is on, and what range is currently in operation.
- Custom Units Indicator: Shows that the displayed units are custom. The initial engineering units of the measure or source function are not shown.
- Secondary Value: Shows the measure or source value in initial engineering units when scaling or custom units are on.



Documenting Process Calibrator Operation Features




Figure 6. Elements of a Typical Display

753/754Users Manual

Table 5. Elements of a Typical Display

Item	Description				
1	Time and Date Display				
2	HART Indicator				
3	Loop Power Indicator				
4	Battery Gauge				
5	Backlight Indicator				
6	Source Status				
7	Undamped (Unsettled) Indicator				
8	Custom Units Indicator				
9	Secondary Value				
10	Softkey Labels				
(1)	Measured Value				
(12)	Mode Indicator				
13	Status bar				



Strap and Stand

After you unpack the Product, attach its carrying strap as shown in Figure 7. The straps can be adjusted as necessary to hang the Product on any sturdy support. Figure 7 also shows how to open the Stand to put the Product at an optimal sight angle for bench top use.




Figure 7. Stand Use and Strap Attachment

The Battery

∆ Caution

For safe operation and maintenance of the product:

- Do not keep cells or batteries in a container where the terminals can be shorted.
- Repair the Product before use if the battery leaks.
- Remove battery to prevent battery leakage and damage to the Product if it is not used for an extended period.
- Connect the battery charger to the mains power outlet before the Product.
- Use only Fluke approved power adapters to charge the battery.
- Keep cells and battery packs clean and dry. Clean dirty connectors with a dry, clean cloth.
- Do not short the battery terminals together.

Marning

To prevent personal injury:

- Do not put battery cells and battery packs near heat or fire. Do not put in sunlight.
- Do not disassemble or crush battery cells and battery packs.
- . Do not disassemble the battery.
- Batteries contain hazardous chemicals that can cause burns or explode. If exposure to chemicals occurs, clean with water and get medical aid.

Charge the Battery

Before you use the Product for the first time, charge its battery.

To charge the battery while it is inside the Product:

- 1. Turn the Product OFF.
- Connect the battery charger to the Product and keep it OFF. The battery will not charge if the Product is on.

The battery fully charges in 8 hours while inside the Product. See Figure 8.

To charge the battery while it is outside of the Product:

- 1. Turn the Product face down.
- 2. Use a flat-head screwdriver and move the battery lock from ♠ (locked) to ♠ (unlocked).



Documenting Process Calibrator The Battery

- Remove the battery.
- 4. Connect the battery charger to the input. Outside of the Product, the battery will charge in 5 hours.

Note

An optional 12-Volt car charger is available. See "Accessories".

Battery Charge Level

Use these two methods to make sure the Battery is charged:

- See the Battery Gauge Bar Graph on the display.
- See the Battery Charge Indicator on the battery.

The Battery Charge Indicator can be seen while the battery is outside of the Product. With the battery removed and not connected to its charger, push the button below the Battery Charge Indicator. Solid Green LEDs show the level of charge on the battery. The Battery is fully charged when all LEDs are illuminated.

Connect the battery charger to the battery and push the button below the Battery Charge Indicator. LEDs flash to show the charge level but also show that the battery is being recharged. As the battery charges, the LED flashes and moves to the top of the charge indicator.

Battery Life

The battery gauge bar graph [is shown on the upper right of the display.

Table 6 shows the typical operation time for a new, fully-charged battery. Product performance is guaranteed to its specification until the battery gage reads empty (<code>[___]</code>).

To replace the battery, see "Battery Replacement".

Table 6. Typical Battery Life

Operation Modes	Backlight Low	Backlight High
Measure, continuous	13 Hours	12 Hours
Measure and source, with loop power on, continuous	7 Hours	6 Hours
Typical intermittent operation	>16 Hours	>16 Hours






Figure 8. Battery Removal and Charger Use

gks9f.eps

Documenting Process Calibrator The Battery

Preserve Battery Life

An optional Auto Battery Save feature turns the Product off after a selected set idle time. The default setting for Auto Battery Save is **Off**. The setting is kept after the Product power is off. Auto Battery Save operates the same when the battery charger is used.

To turn on the Auto Battery Save feature:

- 1. Push SETUP.
- 3. Push enter or the Choices softkey.
- 4. Push to A highlight On, then push [ENTER].
- To use the timeout period shown on the display, stop here. Push the **Done** softkey to exit Setup mode and do not go on to step 6.
- 7. Push or the **Choices** softkey.
- Record choice of timeout period in minutes (accepted range: 1 to 120 minutes).
- 9. Push the **Done** softkey.

10. Push the **Done** softkey or **SETUP** to exit Setup mode.

The Battery Charger

∧Caution

To avoid damage to the Product, use only the Battery that comes with the Product, Fluke model BP7240, part number 4022220.

Where ac power is available, the battery charger can be used to conserve battery power and energize the Product. When the battery is in the Product, the battery charges only when the Product is off. When you calibrate an instrument, best results come from battery power use.

An optional 12-V car adapter is available that can be used to charge the battery outside of the Product. See "Accessories".

Fluke-Direct.com

753/754

Users Manual

Display Languages

The Product shows information in five languages:

- English
- European French
- Italian
- German
- Spanish

To change the display language:

- 1. Push SETUP.
- Push F3 twice.
- 3. Push Three times.
- 4. Push ENTER.
- 6. Push [ENTER] to confirm the language choice. This language is the power-up default.
- 7. Push SETUP to exit Setup mode.

Display Intensity

There are two ways to increase display intensity:

- Push . There are three levels of intensity when using this button.

In calculator mode, all four direction keys are used for arithmetic functions.

Date and Time

The date and time can be shown at the top of the display during normal operation. The date and time can be turned on or off in Setup mode. Date and time formats can also be controlled. If you choose to not use the date and time display, the calendar and clock must be set since a timestamp is applied to all kept results.



To set the time and date displays:

- 1. Push SETUP.
- 2. Push the **Next Page** softkey. See Figure 9.




Figure 9. Time and Date Display

3. Push • and • to move the cursor to the necessary parameter, then push • or the **Choices** softkey to choose a setting for that parameter.

For example, the display in Figure 10 is shown after you select **Date Format**.




Figure 10. Edit the Date Format

- Push or to move the cursor to the necessary date format.
- 5. Push select the format and go back to Setup mode.
- 6. Choose a different selection or push the **Done** softkey or **SETUP** to save the settings and exit Setup mode.

The Backlight

Push to change the backlight intensity from dim to bright and back again. shows at the top of the display when the backlight is active. Set the Product to turn the backlight off automatically to keep battery use to minimum. When the backlight is on and Auto Backlight Off is in operation, is shown at the top of the display.

To automatically dim the backlight after a set time:

- 1. Push SETUP.
- Push to move the cursor to the same line as Auto Backlight Off.
- 3. Push enter or the Choices softkey.
- 4. Push to highlight **On**, then push ENTER.
- To use the timeout period shown on the display, stop here. Push the **Done** softkey to exit Setup mode and do not go on to step 6.
- 6. To change the timeout period, push

 to highlight the timeout period following Backlight Timeout.
- 7. Push or the Choices softkey.
- Record the choice of timeout period in minutes (accepted range: 1 to 120 minutes).
- 9. Push the **Done** softkey.
- 10. Push the **Done** softkey or **SETUP** to exit Setup mode.


28

When the backlight dims, the Product also beeps.

Personalize the Product

Alphanumeric identifiers can be put into the Product to be shown at power-up and in results that you keep. To install an identifier:

- 1. Push SETUP.
- 2. Push Next Page twice.
- 3. Push to move the cursor to the same line as ID.
- 4. Push or the **Choices** softkey. The screen in Figure 11 is shown.



gks40s.bmp

Figure 11. Personalize the Product

- 5. The ID string is shown at the bottom of the boxed area. To erase a character, push the Back Space softkey. To erase the complete string, push (CLEAR DECORDED INTERIOR). Information recorded in the ID string is recorded with all measurements stored in memory.
- 6. Push ♠, ♥, ♠, or ♠ to select a character, then push

 [BYTER]. Use the numeric keypad to record numbers.
- 7. Do step 6 until satisfied with the ID string.
- 8. Push the Done softkey.
- 9. Push the **Done** softkey or **SETUP** to exit Setup mode.

Measure Mode

Note

To get the best noise rejection and highest accuracy performance when you measure, use the battery; do not use the battery charger.

The operation mode (for example, MEASURE, SOURCE) is shown in the top left of the display. If the Product is not in MEASURE mode, push with MEASURE is shown. The Product must be in MEASURE mode to change the MEASURE parameters.

Measurement Ranges

The Product usually changes to the correct measurement range automatically. The lower left side of the display shows "Range" or "Auto" if on the range status. Auto Range switch points are shown in Specifications. When the **Range** softkey is pushed, the range is locked. Push it again to go to and lock on the next higher range. Auto Range is in operation when a different measurement function is selected.

If the range is locked, overrange inputs show on the display as -----. In Auto Range, out of range is shown as !!!!!!.



Users Manual

Electrical Parameter Measurement

When the Product is turned on, it is in the dc voltage measurement function. Figure 12 shows electrical measurement connections. To select an electrical measurement function from SOURCE or MEASURE/SOURCE mode, first push for MEASURE mode:

1. Push ma for current, voc for dc voltage, vac once for ac voltage or twice for frequency, or fine for resistance.

Note

When you measure frequency, the Product tells you to select a frequency range. If the measured frequency is expected to be below 20 Hz, push to select the lower frequency range, and then push [ENTER].

2. Connect the test leads for your measurement function as shown in Figure 12.






Figure 12. Electrical Measurement Connections

gks10f.eps

Users Manual

Continuity Test

When you do a continuity test, the beeper sounds and **Short** is shown on the display when the resistance between the Ω MEASURE jack and its common jack is less than 25 Ω . **Open** is shown when the resistance is larger than 400 Ω .

To do a continuity test:

- 1. De-energize the circuit under test.
- 2. If necessary, push source for MEASURE mode.
- 3. Push twice so that **Open** is shown.
- Connect the Product to the circuit under test. See Figure 12.

Pressure Measurement

Many ranges and types of pressure modules are available from Fluke. See "Accessories". Before you use a pressure module, read its instruction sheet. The modules are different in how they are used, zeroed, what types of process pressure media are allowed, and accuracy specifications.

Figure 13 shows gage and differential modules. Differential modules also operate in gage mode when you leave the low fitting open to atmosphere.

To measure pressure, attach the applicable pressure module for the process pressure you will test as described in the module's Instruction Sheet.

To measure pressure:

⚠ Warning

To prevent personal injury, shut off the valve and slowly bleed off the pressure before attaching the pressure module to the pressure line to avoid a violent release of pressure in a pressurized system.



Documenting Process Calibrator

Measure Mode




Figure 13. Gage and Differential Pressure Modules

∧Caution

To prevent possible damage to the Product or to equipment under test:

- Never apply more than 10 ft.-lb. of torque between the pressure module fittings, or between the fittings and the body of the module.
- Always apply correct torque between the pressure module fitting and connecting fittings or adapters.
- Never apply pressure above the rated maximum printed on the pressure module.
- Use the pressure module only with specified materials. See the printing on the pressure module or the pressure module instruction sheet for the acceptable material compatibility.



Users Manual

Connect a pressure module to the Product as shown in Figure 14. The threads on the pressure modules accept standard $\frac{1}{2}$ NPT pipe fittings. Use the supplied $\frac{1}{2}$ NPT to $\frac{1}{2}$ ISO adapter if necessary.

- 1. Push MEASURE mode.
- Push
 The Product automatically senses which pressure module is attached and sets its range accordingly.
- Zero the pressure. See the module's Instruction Sheet. Modules can have different zeroing procedures that depend on module type.

Note

Zeroing MUST be done before doing a task that sources or measures pressure.

- 4. If necessary, the pressure display units can be changed to psi, mHg, inHg, inH2O, ftH2O, mH2O, bar, Pa, g/cm2, or inH2O@60°F. Metric units (kPa, mmHg, etc.) are shown in Setup mode in their base units (Pa, mHg, etc.). To change pressure display units:
 - 1. Push SETUP
 - 2. Push Next Page twice.
 - Push ENTER or the Choices softkey with the cursor on Pressure Units.
 - 4. Set the pressure units with ♠ or ♥.
 - 5. Push ENTER.
 - 6. Push the **Done** softkey.

Fluke-Direct.com




Figure 14. Pressure Measurement Connections

gks12c.eps



Users Manual

Temperature Measurement

Thermocouple Use

The Product supports thirteen standard thermocouples, each identified with an alpha character: E, N, J, K, T, B, R, S, C, L, U, XK, or BP. Table 7 summarizes the ranges and qualities of the supported thermocouples.

To measure temperature using a thermocouple:

 Attach the thermocouple leads to the correct TC miniplug, then to the TC input/output. See Figure 15.

∆ Caution

To prevent possible damage to the Product, do not try to force a miniplug in the wrong polarization. One pin is wider than the other.

Note

If the Product and the thermocouple plug are at different temperatures, stop for one minute or more for the connector temperature to stabilize after you plug the miniplug into the TC input/output.

- 2. If necessary, push SOURCE for MEASURE mode.
- 3. Push 疆.
- Select TC.
- 5. The display tells you to select the thermocouple type.
- Select the necessary thermocouple type using the o or

 ▼ followed by [ENTER].

- If necessary, change between °C, °F, °R, and °K Temperature Units as follows:
 - 1. Push SETUP
 - 2. Push the Next Page softkey twice.

 - 4. Push with or the **Choices** softkey to choose a setting for that parameter.
 - Push or or to move the cursor to the necessary setting.
 - 6. Push ENTER to go back to the SETUP display.
 - 7. Push the **Done** softkey or **SETUP** to exit Setup mode.
- 3. If necessary, change between ITS-90 or IPTS-68

 Temperature Scale in Setup mode. The procedure is the same as steps 1-7 above.

Table 7. Thermocouple Types Accepted

Туре	Positive Lead Material	Positive Lead (H) Color		Negative Lead	Specified Range
		ANSI ^[1]	IEC ^[2]	Material	(°C)
E	Chromel	Purple	Violet	Constantan	-250 to 1000
N	Ni-Cr-Si	Orange	Pink	Ni-Si-Mg	-200 to 1300
J	Iron	White	Black	Constantan	-210 to 1200
K	Chromel	Yellow	Green	Alumel	-270 to 1372
Т	Copper	Blue	Brown	Constantan	-250 to 400
В	Platinum (30 % Rhodium)	Gray		Platinum (6 % Rhodium)	600 to 1820
R	Platinum (13 % Rhodium)	Black	Orange	Platinum	-20 to 1767
S	Platinum (10 % Rhodium)	Black	Orange	Platinum	-20 to 1767
C ^[3]	Tungsten (5 % Rhenium)	White		Tungsten (26 % Rhenium)	0 to 2316
L (DIN J)	Iron			Constantan	-200 to 900
U (DIN T)	Copper			Constantan	-200 to 600
		GOST			
BP	95 % W + 5 % Re	Red or Pink		80 % W + 20 % Re	0 to 2500
XK	90.5 % Ni = 9.5 % Cr	Violet or E	Black	56 % CU + 44 % Ni	-200 to 800

^[1] American National Standards Institute (ANSI) device negative lead (L) is always red.



^[2] International Electrotechnical Commission (IÉC) device negative lead (L) is always white.

^[3] Not an ANSI designation but a Hoskins Engineering Company designation.

753/754Users Manual




Figure 15. Temperature Measurement with a Thermocouple

gks12f.eps

Resistance-Temperature Detectors (RTDs)

The Product accepts RTD types shown in Table 8. RTDs are characterized by their resistance at 0 °C (32 °F), which is called the "ice point" or R_0 . The most common R_0 is 100 Ω . A large number of RTDs come in a three-terminal configuration. The Product accepts RTD measurement inputs in two-, three-, or four-wire connections. See Figure 17. A four-wire configuration gives the highest measurement precision, and two-wire gives the lowest measurement precision.

Table 8. RTD Types Accepted

RTD Type	Ice Point (R₀)	Material	α	Range (°C)			
Pt100 (3926)	100 Ω	Platinum	0.003926 Ω/Ω/°C	-200 to 630			
Pt100 (385) [1]	100 Ω	Platinum	0.00385 Ω/Ω/°C	-200 to 800			
Ni120 (672)	120 Ω	Nickel	0.00672 Ω/Ω/°C	-80 to 260			
Pt200 (385)	200 Ω	Platinum	0.00385 Ω/Ω/°C	-200 to 630			
Pt500 (385)	500 Ω	Platinum	0.00385 Ω/Ω/°C	-200 to 630			
Pt1000 (385)	1000 Ω	Platinum	0.00385 Ω/Ω/°C	-200 to 630			
Cu10 (427)	$9.035~\Omega^{[2]}$	Copper	0.00427 Ω/Ω/°C	-100 to 260			
Pt100 (3916)	100 Ω	Platinum	0.003916 Ω/Ω/°C	-200 to 630			

^[1] Per IEC 751-Standard



^{[2] 10} Ω @ 25 °C

Users Manual

To measure temperature where an RTD input is used:

- 1. If necessary, push SOURCE for MEASURE mode.
- 2. Push TC RTD.
- 3. Push **●** and **ENTER** then **Select RTD Type** is shown.
- 4. Push ● or ▼ to select the necessary RTD type.
- 5. Push ENTER.
- 6. Push ♠ or ♥ to select a 2-, 3-, or 4-wire connection. The connections are shown on the display.
- 7. Attach the RTD to input jacks as the display or Figure 14 shows. Use the supplied jumper between the mA Ω RTD MEASURE low jack and the V MEASURE low jack as shown if using a 3-wire connection.
- 8. Push ENTER.

Caution

To prevent possible damage to the Product, do not force a dual banana plug between any two jacks in the horizontal orientation. Doing so will damage the jacks. Use the supplied jumper wire when needed for RTD measurements. A dual banana plug may be used in the vertical orientation. See Figure 16.



Figure 16. Correct Jumper Use

- 8. If necessary, change between °C, °F, K, and °R temperature units in Setup:
 - 1. Push SETUP.
 - Push the Next Page softkey twice.
 - Push ● and ● to move the cursor to Temperature Units.
 - Push enter or the **Choices** softkey to choose a setting for that parameter.
 - 5. Push or to move the cursor to the necessary setting.
 - 6. Push [ENTER] to go back to the SETUP display.
 - 7. Push the **Done** softkey or **SETUP** to exit Setup mode.
- If necessary, change between ITS-90 or IPTS-68 Temperature Scale in Setup mode. The procedure is the same as steps 1-7 above.






Figure 17. Temperature Measurement with an RTD

Measurement Scale

This feature scales measurements in accordance with a applicable process instrument's response. Percent of scale works for linear-output transmitters or square-law transmitters such as differential pressure transmitters that report flow rate.

Linear-Output Transmitters

- 1. If necessary, push source for MEASURE mode.
- 3. Push the Scale softkey.
- 4. Select % from the list.
- 5. Use the numeric keypad to record the 0% of scale value (0% Value).
- 6. Push ENTER.
- Use the numeric keypad to record the 100% of scale value (100% Value).
- 8. Push ENTER.
- 9. Push the Done softkey.

Percent of scale stays in effect until you change to a different measurement function or until you push the **Scale** softkey and select a different scale mode.

Square-Law Process Variables

When you select √ within scaling, the Product takes the square root of its input and shows the measurement in percent. For example, when the Product is connected to the output of a delta-pressure transmitter, the Product indication is in proportion to flow rate.

- 1. If necessary, push source for MEASURE mode.
- 2. Select a measurement function (mA, voc, WAC, 1 (RTD), or as previously described.
- 3. Push the Scale softkey.
- Select √ from the list.
- Use the numeric keypad to record the 0% of scale value (0% Value).
- 6. Push ENTER.
- 7. Use the numeric keypad to record the 100% of scale value (100% Value).
- 8. Push the **Done** softkey.

Square root percent of scale stays in effect until you change to a different measurement function or the **Scale** softkey is pushed and you select a different scale mode.



Measure or Source with Custom Units

∧ ∧ Warning

To avoid possible electric shock, when using Custom Units for measurement, always see the secondary value displayed below and to the right of the main display for the actual value of the measurement in native engineering units.

The measurement or source display can be setup to show custom units. To do this, select a function, for example mV dc, scale it as necessary, then record an alphanumeric name for the custom units, for example, "PH."

To set up a custom unit:

- When you measure or source the necessary function, push the Scale softkey, and then select Custom Units from the list.
- Record the 0% and 100% scale points for the input of the transfer function.
- 3. Push the **Custom Units** softkey.
- 4. Record the 0% and 100% scale points for the output of the transfer function.
- 5. Record the name of the custom units (up to four characters), for example **PH** (for pH), using the alphanumeric entry window, then push [ENTER].

While **Custom Units** are active, \triangle shows on the display to the right of the custom unit. Once the custom measurement unit has been programmed, the unit is available for calibration procedures in split-screen MEASURE/SOURCE mode. To cancel **Custom Units**, push the **Custom Units** softkey again.

Using the 700-IV Current Shunt

To source and measure current simultaneously, a current shunt is necessary and uses the volts measure function. The Fluke 700-IV Current Shunt is designed specifically for use with the 700 Series Documenting Process Products.

To measure current with the current shunt:

- Connect the current shunt to the MEASURE V jacks.
- Connect the current signal to be measured to the current shunt.
- 3. Push voc to select the dc voltage measure function.
- Push the Scale softkey.
- 5. Select Current Shunt from the list.
- 6. Push ENTER.
- 7. The Product is automatically configured and uses the correct custom scaling factor for the current shunt.

Damping Measurements

The Product normally applies a software filter to dampen measurements in all functions except continuity. The specifications assume that damping is turned on. The damping method is a running average of the last eight measurements. Fluke recommends leaving damping on. Turning damping off may be useful when measurement response is more important than accuracy or noise reduction. To turn damping off, push the **More Choices** softkey twice, then push the **Dampen** softkey so that **Off** is shown. Push **Dampen** again to turn damping back on. The default state is **On**.

Note

If a measurement falls outside a random noise window, a new average is started. If damping is turned off, or until measurements are fully damped, the hypothesis displayed.

Source Mode

The operating mode (for example, MEASURE, SOURCE) is shown on the display. If the Product is not in SOURCE mode, push [55] until SOURCE is shown. The Product must be in SOURCE mode to change any of the SOURCE parameters.

Source Electrical Parameters

To select an electrical source function:

- 1. Connect the test leads as shown in Figure 18, depending on the source function.
- 2. Push for current, for dc voltage, for frequency, or for resistance.
- 3. Record the necessary output value, then push ENTER. For example, to source 5.5 V dc, push voc ⑤ ① ENTER.



Users Manual

Note

If sourcing frequency, respond when the Product asks you to select a zero-symmetric sine or positive square wave. The amplitude specified is p-p amplitude.

4. To change the output value, record a new value and push [ENTER].

Note

If sourcing current, wait for the www symbol to disappear before you use the output.

- 5. To set the output value in the present source function, push [CLEAR] then enter the desired value and push [ENTER].
- 6. To turn off sourcing completely, push (CLEAR ZERIO) twice.

Note

Use the source current function to drive a current loop. This is different than the loop power function in which the Product is powering a process instrument. To source loop power, use the Loop Power function accessible from Setup mode.




Figure 18. Electrical Source Connections

gks16f.eps



Users Manual

4 to 20 mA Transmitter Simulation

The Product can be configured as a load on a current loop through the SOURCE mA function. In SOURCE mode, when is pressed, the display prompts to select Source mA or Simulate Transmitter. When you Source mA the Product is sourcing current, and when you Simulate Transmitter the Product is sourcing a variable resistance to keep the current to the specified value. Connect an external loop supply to the positive (top) mA jack as shown in Figure 19.

Note

Also see "Transmitter Mode" in which the Product can be temporarily configured to replace a two-wire process transmitter.






Figure 19. Connections to Simulate a 4 to 20 mA Transmitter

gks17c.eps

Users Manual

Supply Loop Power

The Product supplies loop power at 26 V dc through an internal series resistance of 250 Ω . The setting supplies sufficient current for two or three 4-20 mA devices on the loop.

When you use loop power, the mA jacks are dedicated to measuring the current loop. This means that the SOURCE mA, measure RTD, and measure Ω functions are not available (see Table 10.)

Connect the Product in series with the instrument current loop as Figure 20 shows. To supply loop power:

1. Push SETUP for Setup mode.

Note

Loop Power, Disabled is highlighted.

- 2. Push **▼** and **♠** to select **Disabled** or **Enabled**.
- 3. Push ENTER.
- 4. Push the **Done** softkey. "**LOOP**" is shown on the display when Loop Power is in operation.






Figure 20. Connections to Supply Loop Power

gks18c.eps

Users Manual

Source Pressure

The Product has a source pressure display function where an external pressure hand pump is necessary. Use this function to calibrate instruments where a pressure source or differential pressure measurement is necessary. See Figures 21 and 36 for information about that application.

Many ranges and types of pressure modules are available from Fluke, see "Accessories". Before you use a pressure module, read its instruction sheet. The modules are different in how they are used, zeroed, what types of process pressure media are allowed, and accuracy specifications.

To use the source pressure display, see Figure 21:

∧ Warning

To avoid a violent release of pressure in a pressurized system, shut off the valve and slowly bleed off the pressure before attaching the pressure module to the pressure line.

∆ Caution

To avoid mechanically damaging the pressure module:

- Never apply more than 10 ft.-lb. of torque between the pressure module fittings or between the fittings and the body of the module.
- Always apply correct torque between the pressure module fitting and connecting fittings or adapters.
- To avoid damaging the pressure module from overpressure, never apply pressure above the rated maximum printed on the pressure module.
- To avoid damaging the pressure module from corrosion, use it only with specified materials. See the printing on the pressure module or the pressure module instruction sheet for the acceptable material compatibility.

- Connect a pressure module and pressure source to the Product as Figure 21 shows. The threads on the pressure modules accept ¼ NPT fittings. Use the supplied ¼ NPT to ¼ ISO adapter if necessary.
- 2. If necessary, push Source for SOURCE mode.
- Push ②. The Product automatically senses which
 pressure module is attached and sets its range
 accordingly.
- 4. Zero the pressure module as described in the module's instruction sheet. The module types are different in how they are zeroed. The pressure module MUST be zeroed before doing a task that sources or measures pressure.

- 5. Pressurize the pressure line with the pressure source to the necessary level as shown on the display.
- 6. If necessary, change the pressure display units to psi, mHg, inHg, inH₂O, ftH₂O, mH₂O, bar, Pa, g/cm², or inH₂O@60°F. Metric units (kPa, mmHg, etc.) are shown in Setup mode in their base units (Pa, mHg, etc.).

To change the pressure display units:

- 1. Push SETUP.
- 2. Push Next Page twice.
- 3. Push with the cursor on Pressure Units.
- 4. Select the pressure units with ♠ or ♥.
- 5. Push ENTER.
- 6. Push the **Done** softkey.






Figure 21. Connections to Source Pressure

gks19c.eps

Thermocouple Simulation

Note

See "Temperature Measurement" for a table of thermocouple types that are supported by the Product

Connect the Product TC input/output to the instrument under test with thermocouple wire and the correct thermocouple mini-connector (polarized thermocouple plug with flat, in-line blades spaced 7.9 mm (0.312 in) center to center).

▲ Caution

To prevent possible damage to the Product, do not try to force a miniplug in the wrong polarization. One pin is wider than the other.

Figure 19 shows this connection. To simulate a thermocouple:

- Attach the thermocouple leads to the correct TC miniplug, and then to the TC input/output. See Figure 15
- 2. If necessary, push Source for SOURCE mode.

- Push (m), and then push (exter) to select the TC sensor type. The display asks you to select the thermocouple type.
- Push ♠ or ♥ followed by ENTER to select the necessary thermocouple type.
- Push or followed by to select Linear T (default), or Linear mV, (to calibrate a temperature transmitter that responds linearly to millivolt inputs).
- Record the temperature to simulate as prompted by the display and push [sures].

Note

If you use copper wire instead of thermocouple wire, the reference junction is no longer inside the Product. The reference junction moves to the instrument (transmitter, indicator, controller, etc.) input terminals. The external reference temperature must be measured accurately and recorded into the Product. To do this, push setup and set Ref. Junc. Compensat. and Ref. Junc. Temp.. After you record the external reference temperature, the Product corrects all voltages to adjust for this new reference junction temperature.



Users Manual

RTD Simulation

Note

See Table 8 for data about RTD (Resistance-Temperature Detector) types compatible with the Product.

Connect the Product to the instrument under test as shown in Figure 23. The figure shows connections for two, three, or four-wire transmitters. For three or four-wire transmitters, use the 4-inch long stackable jumper cables to connect the third and fourth wires at the source V Ω RTD jacks.

To simulate an RTD (Resistance-Temperature Detector):

- 1. If necessary, push Source for SOURCE mode.
- 2. Push 疆.
- 3. Push o or to select RTD.
- 4. Push [ENTER]. The Select RTD Type display is shown.
- 5. Push ♠ or ♥ followed by ENTER to select the necessary RTD type.
- 6. The product tells you to use the keypad to enter the temperature to simulate. Input the temperature, and then push [ENTER].






Figure 22. Connections to Simulate a Thermocouple

gks20c.eps




Figure 23. Connections to Simulate an RTD

gks21f.eps

Source Temperature with a Hart Scientific Drywell

The Product can source temperature using a Hart Scientific Drywell. Many models are supported.

The drywell driver is able to talk to other drywells from Hart Scientific, provided that they respond to Hart Scientific's standard serial interface commands.

Connect the Product to the drywell by plugging the drywell interface cable into the pressure module connector as shown in Figure 24. If the drywell has a DB9 connector, plug the drywell interface cable directly into the drywell using the DB9 Null Modem adapter. Drywells with the 3.5 mm jack connector need to use the serial cable supplied with the drywell in addition to the Product drywell interface cable. Join the DB9 connectors of the two cables, and connect the 3.5 mm jack to the drywell.

Be sure the drywell is configured for serial communication at 2400, 4800, or 9600 bits per second. Other rates are not supported by the Product.

To source a temperature with a drywell:

- 1. If necessary, push source for SOURCE mode.
- 2. Push $\frac{TC}{RPD}$ to display the temperature mode menu.
- Select **Drywell** from the list of options, and press ENTER.
- 4. The Product will begin to search for a drywell. If the Product shows **Attempting connection** for more than

- 10 seconds, double check your cable connections and drywell configuration.
- 5. If a dual well is recognized, a menu will pop up that allows you to select a "hot" or "cold" side of the dual well. Only one side of the drywell may be controlled at a time. Switching sides requires the drywell to be reconnected, by disconnecting the serial cable or by leaving drywell source mode and selecting it again.
- 6. When the drywell is connected, the primary display will show the actual temperature of the drywell, as measured by the drywell internally. The drywell model number will appear above the primary reading. The setpoint for the drywell is displayed in the secondary display, at the bottom of the screen. Initially, the setpoint will be set to the value already stored in the drywell.
- 7. Enter the temperature you wish to source and press [ENTER].

The settled indicator will be cleared when the actual temperature is within one degree of the setpoint, and the actual temperature is not changing quickly. Refer to the drywell documentation for that model's recommendations for stabilization time.

The upper temperature limit is restricted by the "High Limit" setting stored in the drywell. If the Product will not set the drywell to temperatures within the drywell spec, refer to the drywell manual to check the "High Limit" setting.






Figure 24. Source Temperature with Drywell

gks99f.eps

Note

When the Product is set to display temperatures in Kelvin, the drywell readout will show Celsius, and when the Product shows Rankine, the drywell will show Fahrenheit.

Source Scale

This feature scales the output in accordance with the input requirements of an applicable process instrument's response. Percent of scale can be used for linear-responding transmitters, or square-root responding transmitters.

Linear-Responding Transmitters

- 1. If necessary, push source for SOURCE mode.
- 2. Select a source function (ma, voc, WAC, nd, rcc, or as previously described, and record a value.
- 3. Push the Scale softkey.
- 4. Select % from the list.
- 5. Push ENTER
- Use the numeric keypad to record the 0% of scale value (0% Value).
- 7. Push ENTER.
- Use the numeric keypad to record the 100% of scale value (100% Value).

9. Push the Done softkey.

Percent of scale stays in effect until you change to a different source function or until the **Scale** softkey is pushed and you select a different scale mode.

Square-Root Process Variables

When you select √ within scaling, the Product output value is the percent value recorded, squared, and converted to engineering units.

- 1. If necessary, push source for SOURCE mode.
- Select a source function (ma, voc, WAC, land, TC RETO, or
 a) as previously described, and record a value.
- 3. Push the **Scale** softkey.
- 4. Select √ from the list.
- Use the numeric keypad to record the 0% of scale value (0% Value).
- 6. Push ENTER.
- Use the numeric keypad to record the 100% of scale value (100% Value).
- 8. Push ENTER.
- 9. Push the **Done** softkey.



Users Manual

Square root percent of scale is in effect until the Product is changed to a different source function or the **Scale** softkey is pushed and you select a different scale mode.

Step and Ramp the Output Value

Two features are available that let you adjust the value of source functions, except pressure. For pressure, an external pressure source must be used:

- Ramp the output with optional continuity or V trip detect.

Manual Step Use

The manual **Step** feature selects a step size in engineering units (mV, V, mA, °C, etc.) or % of scale. Step the output in % of scale to quickly jump between 0 % and 100 % (set step size = 100 %) or 0-50-100 % (set step size = 50 %). Step works in SOURCE and in MEASURE/SOURCE modes.

To select a step size:

- See the applicable Source Mode subheading in this manual (for example, "Source Electrical Parameters") and connect the Product to the test circuit.
- 2. If necessary, push SOURCE mode.
- 3. Set the Product for the necessary source value.

- 4. To step the source value in % of scale, set the % of scale value as given before in "Measurement Scale".
- 5. Push the Step softkey.
- Use the numeric keypad to record the step size in the units shown on the display.
- 7. Push the **Done** softkey.

Auto Step Use

To configure the Product to make a sequence of steps automatically, either once through the sequence or repetitively:

- See the applicable Source Mode subheading in this manual (for example, "Source Electrical Parameters") and connect the Product to the test circuit.
- 2. If necessary, push source for SOURCE mode.
- 3. Set the Product for the necessary source value.
- 4. To step the source value in % of scale, set the % of scale value as given before in "Measurement Scale".
- 5. Push the Step softkey.
- 6. Push the **Auto Step** softkey.



Documenting Process CalibratorSource Mode

- 7. The display tells you to select values for these parameters:
 - Start point (in units or % of scale)
 - End point
 - Number of steps
 - Time per step
 - Repeat mode, single shot or continuous repetition
 - Step style, Sawtooth or Triangle pattern
 - Start delay

Push the **Start Step** softkey to automatically start the step function. The softkey label changes to **Stop Step**.

- 8. To Push the **Stop Step** softkey to stop the automatic step function.
- 9. Push the **Done** softkey to continue normal operation.

Ramp the Output

When ramped, the source sweeps up or down in value. Use the ramp feature to check a switch or alarm, or when a smooth increase or decrease of the output function is necessary. The Product can be set to ramp up or down in engineering units (mV, V, mA, °C, etc.) or % of scale.

While the signal ramps, the output is adjusted 4 times per second. The size of the steps is bound by the selection of endpoints and ramp time. For example, if you set the Product to ramp from 1 mV to 1 V over 10 seconds, the output is adjusted in approximately 25 mV steps.


The Ramp function continues until you get the selected limit, or until an optional trip condition is met. The optional trip detect works as follows: during ramping, the Product checks for either a 1 V change in dc voltage or a change in continuity status (**Open** or **Short**) from one ¼ second interval to the subsequent interval.

Fluke-Direct.com

753/754 Users Manual

To ramp (for example, sweep the source):

- See the applicable section earlier in this manual (for example, "Source Electrical Parameters") and connect the Product to the test circuit.
- To automatically stop the Ramp function if a trip condition is sensed, connect a voltage trip circuit to the V MEASURE jacks or a continuity trip circuit to the mA Ω RTD MEASURE jacks. (Continuity detection is not available when sourcing current.)
- 3. If necessary, push source for SOURCE mode.
- 4. Set the Product for the necessary source value as given before.
- 5. To Ramp the output in % of scale, set % of scale as given before under "Measurement Scale".
- 6. Push the More Choices softkey.
- 7. Push the **Ramp** softkey. The display changes to the screen shown Figure 25.
- 8. Record the parameters given. Record the **Start Value**, **End Value**, and **Ramp Time**.
- To automatically stop the Ramp function if a trip condition is sensed, set the Trip Detect to Enabled, and select Voltage or Continuity as the trip function.



gks41s.bmp

Figure 25. Ramp Screen

- Push the **Done** softkey. Note **RAMP** next to **SOURCE** at the top of the display.
- 11. Select a low-to-high ramp or a high-to-low ramp with the **Ramp Up/Down** softkey.
- To start the Ramp function, push the **Start Ramp** softkey.
- The Ramp function continues until a trip is sensed (if enabled), the ramp time expires, or the **Stop Ramp** softkey is pushed. See Figure 26.

Documenting Process CalibratorSource Mode




Figure 26. Check a Relay Output Trip Alarm

65

Fluke-Direct.com

Simultaneous Measure/Source

Use the MEASURE/SOURCE mode to calibrate or emulate a process instrument. Push so that a split screen display shows as in Figure 27.




Figure 27. Measure and Source Screen

Table 9 shows the functions that can be used at the same time when Loop Power is disabled. Table 10 shows the functions that can be used at the same time when Loop Power is enabled.

Step or **Auto Step** features can be used to adjust the output in MEASURE/SOURCE mode, or use the calibration routine given when the **As Found** softkey is pushed.

Use the two softkeys shown in MEASURE/SOURCE mode when you calibrate a process instrument:

- As Found, which can be used to set up a calibration routine to get and record as found data.
- Auto Step, which can be used to set up the Product for auto-stepping, as given before.

Table 9. Simultaneous MEASURE/SOURCE Functions with Loop Power Disabled

Massura Function	Source Function						
Measure Function	dc V	mA	Freq	Ω	TC	RTD	Pressure
dc V	•	•	•	•	•	•	•
mA	•		•	•	•	•	•
ac V	•	•	•	•	•	•	•
Frequency (≥20 Hz)	•	•	•	•	•	•	•
Low Frequency (<20 Hz)							
Ω	•		•	•	•	•	•
Continuity	•		•	•	•	•	•
TC	•	•	•	•		•	•
RTD	•		•	•	•	•	•
3W RTD	•		•	•	•	•	•
4W RTD	•		•	•	•	•	•
Pressure	•	•	•	•	•	•	



753/754Users Manual

Table 10. Simultaneous MEASURE/SOURCE Functions with Loop Power Enabled

Measure Function	Source Function						
	dc V	mA	Freq	Ω	TC	RTD	Pressure
dc V	•		•	•	•	•	•
mA	•		•	•	•	•	•
ac V	•		•	•	•	•	•
Frequency (≥20 Hz)	•		•	•	•	•	•
TC	•		•	•		•	•
Pressure	•		•	•	•	•	

Documenting Process CalibratorProcess Instrument Calibration

Process Instrument Calibration

Note

To calibrate a HART-capable transmitter using the built-in HART interface, see the 754 HART Mode Users Guide for instructions.

When the Product is in MEASURE/SOURCE, a built-in calibration routine can be configured when the **As Found** softkey is pushed. As Found data is the test results that show the condition of a transmitter before it is adjusted. The Product can run preloaded tasks that are developed with a host computer and *DPCTrack2* application software. See "Communication with a PC".

Generate "As Found" Test Data

The subsequent example shows how to supply as found data for a thermocouple temperature transmitter.

Here, the Product simulates the output of a thermocouple and measures the current regulated by the transmitter. Other transmitters use this same procedure. Go back to MEASUREMENT or SOURCE mode and change the operation parameters before you push **As Found**.

- Connect the test leads to the instrument under test as shown in Figure 30. The connections simulate a thermocouple and measure the corresponding output current.
- 2. If necessary, push source for MEASURE mode.
- 3. Push [ma].
- 4. Push MEASURE for SOURCE mode.
- 5. Push TC and ENTER to select TC sensor.
- 6. Push and to select the thermocouple type.
- Push ENTER to select then ENTER to select Linear T source mode.
- 8. Record a source value, for example 100 degrees, and then push [ENTER].



Users Manual

9. Push for MEASURE/SOURCE mode. The display changes to the screen shown in Figure 28.




Figure 28. Process Instrument Calibration Screen

10. Push the **As Found** softkey, followed by the **Instrument** selection ([ENTER]).

The display changes to the screen shown in Figure 29.




Figure 29. Process Instrument Calibration Screen 2

 Record values for 0% and 100% of 4.0 mA and 20.0 mA, in that sequence. Set Tolerance to 0.5% of span.

Documenting Process Calibrator Process Instrument Calibration




Figure 30. Calibrate a Thermocouple Temperature Transmitter

gks23c.eps

Users Manual


- 12. More delay time can be input for the process instrument to become stable than the Product's usual settling time (about 2 seconds). To change the delay time, input that time in seconds for **Delay**.
- 13. Push and to move the cursor down to record 0% and 100% values for SOURCE temperature. Our example uses 100 °C and 300 °C.
- 14. If the instrument calibration procedure requires you to manually record the measurement value or source, push the **User Value** softkey, for user-recorded values. **Custom Units** lets you specify user units such as PH.

Custom Units lets you specify user units such as PH. See "Creating Custom Measurement Units", given before in this manual for an example.

When you use custom units, $\underline{\Lambda}$ is shown next to the value on the display and in results.

Push the **Done** softkey after the custom unit has been programmed.

- 15. The **Test Strategy** is the number of test points and which test points are performed rising and falling in percent of scale. This example uses five points (0 %, 25 %, 50 %, 75 %, and 100 %), rising only. Rising is indicated by the up arrow on the display. Push ENTER to change to a different test strategy on this line. A list of strategies is shown from which to choose. Select one, and then push the **Done** softkey.
- 16. When you are done recording the calibration parameters, the display should change to the screen shown in Figure 31.



gks45s.bmp

Figure 31. Calibration Parameters Screen

 Push the **Done** softkey to accept the calibration parameters. The display changes to the screen shown in Figure 32.




Figure 32. Measure and Source Screen for Calibration

18. At this time you can do an automatic test or step through the test points manually. Push the **Auto Test** softkey to have the Product go through the tests automatically. If necessary, push **Abort** to exit from the calibration procedure. The tests start at the first test point, sources the correct temperature and measures the corresponding current from the transmitter.

- When a measurement is stable and recorded, the Product goes to the subsequent step. Because the Product waits until the measurement becomes stable, the Auto Test works as necessary for instruments with built-in damping. The error of the expected measured value is shown in the top left of the measure window.
- 19. The Product moves to the remaining set of points. For temperature and electrical parameter calibration, the points are done automatically. If your source pressure, the Product stops at each step to let you adjust the pressure source. When the tests are complete, an error summary table similar to Figure 33 is shown.

			(Ⅲ ※
SOURC	E №	1EASURE	ERROR %
100.0	°C	3.904 mA	-0.60
150.0	°C	7.965 mA	-0.22
200.0	°C	12.053mA	0.33
250.0	°C	16.094mA	0.59
300.0	°C	20.175mA	1.09
Abort	Prev.	Next	Done
	Page	Page	22.10

Figure 33. Error Summary Screen

gks47s.bmp



Users Manual

In the results summary test, failures are highlighted. An adjustment is necessary in this example because three tests show failures. The failures were outside the ±0.5 % tolerance that was selected.

20. Push the **Done** softkey to keep the data, or the **Abort** softkey to erase the data and start again.

See the data entry that was recorded and recall the table later with the **Review Memory** softkey during normal operation. This data can be uploaded to a host computer that runs compatible *DPCTrack2* application software. See "Communication with a PC".

Transmitter Adjustment

Note

Always read the transmitter manufacturer's instructions to find the adjustment controls and connection points for your transmitter.

To make calibration adjustments to the transmitter:

1. Push the **Done** softkey after you review the results summary.

- Push the Adjust softkey. The Product sources 0 % of span (100 °C in this example) and shows these softkeys:
 - Go to 100%/Go to 0%
 - Go to 50%
 - As Left
 - Done
- Adjust the transmitter output for 4 mA and then push the Go to 100% softkey.
- 4. Adjust the transmitter output for 20 mA. If HART adjustments (output Trim and Sensor trim) are necessary, please refer to the *754 HART Mode Users Guide*.
- 5. If the span was adjusted in step 4, do steps 3 and 4 until adjustment is no longer necessary.
- 6. Examine the transmitter at 50 %. If it is in specification, the adjustment is done. If not, adjust the linearity and start this procedure again at step 3.



"As Left" Test Run

Proceed as follows to generate and record *as left* data for the thermocouple temperature transmitter that was adjusted.

- 1. Push the **As Left** softkey to record as *left* data.
- 2. Push the **Auto Test** softkey to start an automatic sequence through all the test points, or step through the tests manually.
- 3. When the tests are complete, read the error summary table. See Figure 34.

SOURC	E N	MEASURE	₹IIII * ERROR %
100.0	°C	3.966 mA	-0.21
150.0	°C	7.991 mA	-0.06
200.0	_	12.029 mA	0.18
250.0	°C	16.023mA	0.14
300.0	°C	19.983mA	-0.11
Abort	Prev. Page	Next Page	Done

gks48s.bmp

Figure 34. As Left Data Screen

Unsettled measure or source values are highlighted. This means that there was an unsettled value (which annunciator) when the measurement was taken.

4. If all the results are in specification, as they are here, push the **Done** softkey. An entry in memory is made for as *left* data.

Test Comments

The Product does tasks (custom procedures) that are made with a host computer and *DPCTrack2* application software. See "Communication with a PC". A task can show a list of proposed comments as it operates. When the comment list is shown, push • and • and then • to select a comment to be kept with the test results.

Calibrate a Delta-Pressure Flow Instrument

The procedure to calibrate a $\sqrt{}$ instrument is the same as for other instruments, as given before, with these differences:

- Source square-root is automatically enabled after the As Found calibration template is complete.
- Measure/Source displays are in engineering units.
- The measurement percentage is automatically corrected for the transmitter's square-root response, and is used to calculate instrument errors.



Users Manual


Select the $\sqrt{ }$ instrument procedure in a menu after you push the **As Found** softkey.

Switch Calibration

The procedure to calibrate a switch also uses the As Found and As Left calibration templates. Select the 1 Pt. Switch or 2 Pt. Switch procedure in a menu after you push the As Found softkey. Figure 35 specifies the terminology used when you calibrate limit switches.

The template to set up the switch procedure uses these parameters:

- Switch sense (normally open or closed)
- For each setpoint:
 - Setpoint value
 - Setpoint tolerance
 - High limit or low limit
 - Minimum deadband
 - Maximum deadband



gj24f.eps

Figure 35. Switch Terminology

Documenting Process CalibratorProcess Instrument Calibration

To do a pressure switch test: The switch in this example sets at a high limit of 10 psi. The set condition is a closed switch contact. For pressure switches, use the **Manual Test** selection. For switches where sourcing pressure is not necessary, use the **Auto Test** selection to do the test.

- 1. Connect the test leads between the pressure switch contact output and the mA Ω RTD (center) jacks on the Product.
- Connect the pressure module to the Product, and connect a pressure line to the switch. Keep the pressure line vented to atmosphere.
- 3. If necessary, push source for MEASURE mode.
- 4. Push and for the continuity measure function.
- 5. Push for SOURCE mode.
- 6. Push a for the pressure source function.

- 7. Push CLEAR to zero the pressure module.
- 8. Push MEASURE SOURCE.
- 9. Push the As Found softkey.
- 10. Highlight 1 Pt. Switch Test from the menu and push [ENTER].
- 11. Push [ENTER] to modify the parameters for Setpoint 1.
- 12. Make these selections:

Setpoint 1 = 10.000 psi

Setpoint Type = High

Set State = Short

- 13. Push the Done softkey.
- 14. Set the **Tolerance** to 0.5 psi.
- 15. The next parameters, **Deadband Min** and **Deadband Max**, are optional. Do not set them in this example. These parameters would describe the minimum allowable size of the deadband.





Users Manual

- 16. Push with to move through the choices to Set **Trip** Function to **Trip Cont**.
- 17. Push the Done softkey.
- 18. Push the Manual Test softkey.
- 19. Close the pressure line vent and slowly move the pressure up to the trip point.
- When the switch sets, slowly decrease the pressure until the switch resets. If necessary, this cycle can be done again.
- 21. Push the **Done** softkey and see the results.
- Push the **Done** softkey and if necessary, record **Tag**, **S/N**, and/or **ID**.
- 23. Push the **Done** softkey.
- 24. Exercise the switch by varying the applied pressure. Adjust the switch until the set point is correct.
- 25. Use the softkeys to control the Product, and adjust the switch as necessary.

- 26. Push the Done softkey.
- 27. Push the As Left softkey to start the test again with the same parameters. Results from the As Found and As Left tests are kept in Product memory to view later or upload.

The procedure for switches that respond to other parameters work similarly. When you do a 2 Pt. Switch Test, follow the directions given on the display for the first switch test, change test leads, and do the second switch test.



Documenting Process Calibrator Transmitter Mode

Transmitter Mode

The Product can be set so that a varying input (MEASURE) controls the output (SOURCE), like a transmitter. This is "Transmitter mode". In Transmitter mode, you can use the Product temporarily as an alternative for a defective transmitter or for one that you think could be defective.

Marning

To avoid possible personal injury, do not use Transmitter mode in any environment that requires intrinsic safe equipment and practices.

∆ Caution

Transmitter mode is for diagnostic purposes only. Use a completely charged battery. Do not use the Product in place of a transmitter for extended periods.

To set up the Product to emulate a transmitter:

- Disconnect the control bus wires from the transmitter output (loop current or dc V control signal).
- Connect test leads from the appropriate Product SOURCE jacks to the control wires in place of the transmitter.
- 3. Disconnect the process input (for example, thermocouple) from the transmitter.
- 4. Connect the process input to the applicable Product MEASURE jacks or input connector.
- 5. If necessary, push [MEASURE mode.
- 6. Push the applicable function key for the process input.
- 7. Push MEASURE for SOURCE mode.





Users Manual

- 8. Push the applicable function key for the control output (for example, wc or m). If the transmitter is connected to a current loop that has a power supply, select Simulate Transmitter for the current output.
- 9. Select a source value, for example, 4 mA.
- 10. Push Source for MEASURE/SOURCE mode.
- 11. Push **More Choices** until the **Transmitter Mode** softkey is shown.
- 12. Push the Transmitter Mode softkey.
- 13. Set the 0 % and 100 % values for MEASURE and SOURCE on the display. **Linear** or √ can be selected for the transfer function.
- 14. Push the Done softkey.

The Product is now in Transmitter mode. It measures the process input and sources the control signal output proportional to the input.

- 15. To change the Transmitter mode parameters, push **Change Setup**, and do the procedure in step 13 again.
- 16. To exit Transmitter mode, push the **Abort** softkey.

Memory Operations

Save Results

As Found/As Left test results are automatically kept at the end of each test routine. Any other time during MEASURE, SOURCE, or MEASURE/SOURCE, if necessary, push the **Save** softkey to keep the data on the display for later inspection.

Documenting Process Calibrator Memory Operations

After you push **Save**, the Product keeps the information on the display and shows a kept result index number, the date and time, and the percentage of memory available, as in Figure 36.

Press Continue to Input Tag ID

Item Saved 20

05/11/11 08:00:02 am

Memory Available 98.0%

Abort Continue Done

Figure 36. Saved Data Screen

To add information to the kept data, push the **Continue** softkey, the display asks you to record the instrument tag identifier (**Tag**), instrument serial number (**S/N**), and operator name (**ID**), as shown in Figure 37.





Figure 37. Additional Data Input Screen

Users Manual

Record alphanumeric characters into the highlighted field with the optional bar code reader or the Product buttons.

To record alphanumeric characters using the Product buttons, push with the cursor on the necessary field to change (for example, Tag, above).

The display shows an alphanumeric entry window. See Figure 38.



gks51s.bmp

Figure 38. Alphanumeric Entry Window

- Record numbers using the numeric keypad, and letters by highlighting the necessary character with , , , , , and followed by FITER. Push the Space softkey, followed by followed by followed a space character.
- 2. When the entry is complete, push the **Done** softkey.

Review the Memory

Push the **More Choices** softkey until **Review Memory** is shown, then push the **Review Memory** softkey to recall and see results that you have kept.

When the **Review Memory** softkey is pressed, the display changes to the screen shown in Figure 39.

					(IIII
Results From (Results From 05/23/11 Lof18				
	Meas	ure	04:33:01	pm	
	Soul	rce	04:33:04	pm	
	TT-101-1	4A	04:33:24	pm	
	Measure Soul	rce	04:33:26	pm	
	Meas	ure	04:33:28	pm	
	PT-121-5			pm	
	Logged Data			pm	
	Min Max			pm	
	Min Max			pm	
Measure		04:34:00	pm		
Go To	Prev.		Next		Done
Result	Page		Page		Dolle
					gks52s.b

Figure 39. Memory Review Screen

Push ullet or ullet and ${}^{\hbox{\tiny ENTER}}$ or the **Go to Result** softkey to view a result that was kept.

Log Data

Users can record a series of measurements for later upload to a host computer that uses *DPCTrack2* application software. See "Communication with a PC". Up to 8000 readings can be recorded, depending on the reading rate, duration, and how much memory is being used for other things such as tasks or kept results. Record the reading rate and duration in minutes. See Figure 40.




Figure 40. Data Log Parameters Screen

Users Manual

To log data:

- 1. If necessary, push source for MEASURE mode.
- 2. Push the More Choices softkey twice.
- 3. Push the Log softkey.
- A list is shown; select a reading rate (1, 2, 5, 10, 20, 30, or 60 readings per minute). Push o or to select the reading rate.
- 5. Push ENTER.
- 6. Push to move the cursor to **Duration**.
- 7. Use the numeric keypad to record the duration in minutes, followed by ENTER. The maximum duration will depend on the reading rate and how much memory is available to log data.

Table 11 gives an estimate of the limits for duration, assuming that no memory is being used for other purposes.

Table 11. Duration Limits

Readings/Minute	Maximum Readings	Approximate Duration			
1	8000	133 hours			
2	8000	66 hours			
5	8000	26 hours			
10	8000	13 hours			
20	8000	6 hours			
30	7980	4 hours			
60	7980	2 hours			

Caution

To prevent possible damage to the Product, use a completely charged battery and the appropriate duration, or use the battery charger to avoid losing power during a logging session. If a low-battery condition occurs during a log session, the session is terminated and data collected to that point is kept. A long logging duration can exceed the life of a battery charge.

- After the Product records the duration selection, the display shows how much memory that duration will consume. See the **Memory Available** percentage on the display. **Memory Available** indicates the percentage of available memory that will be used by the specified log.
- Push the **Done** softkey. The display changes to the screen shown in Figure 41.




Figure 41. Start Logging Screen




Users Manual

- 10. Note the **LOG** annunciator next to **MEASURE**. Push the **Start Logging** softkey to record data.
- 11. The Product continues to keep data points until the duration has passed, or until the **Done** softkey is pushed. If logging is stopped by these procedures the Product keeps the data as a memory item that can be uploaded to a host computer that uses *DPCTrack2* application software. See "Communication with a PC".

Record Min and Max Measurements

You can set the display to record and show the maximum (max) and minimum (min) readings. Min and Max readings are always undamped, even if Dampen is On. Push the **More Choices** softkey twice, then push the **Min Max** softkey to energize this feature. Push CLEAN to reset the Min Max registers. Push the **Min Max** softkey again to revert to the normal display. Figure 42 shows the display with Min Max on.



gks55s.bmp

Figure 42. Min Max Screen

Documenting Process CalibratorThe Calculator

Run a Preloaded Task

Push the **More Choices** softkey until the **Tasks** softkey is shown, then push **Tasks** to see the list of tasks (procedures) downloaded from a host computer. Tasks are Product configurations, kept with a procedure name, for example the type and manufacturer of a specific transmitter. A task configures the Product for transmitter calibration with all the calibration parameters (source and measure functions, 0% and 100% levels, test strategy) predefined.

While the task controls the Product, the **Continue** softkey becomes **Continue Task**.

Clear the Memory

In Setup mode, highlight the **Clear Memory** choice and push $_{\hbox{\tiny ENTER}}$ to erase the memory:

- Results that have been kept
- Min Max data
- Log data sets

A confirmation message is shown so that the memory is not accidently erased.

The Calculator

For mathematical equations that involve the Product's source or measured value, use the Product's built-in calculator. The current measure and source values and units, are always available to be put into an equation with one keystroke. The Product measures and sources during calculator operation.

Push the **Calc** softkey to start the calculator from the SOURCE, MEASURE, or MEASURE/SOURCE mode. Push the **More Choices** softkey to see the **Calc** softkey if necessary.

After you push **Calc**, the display, number keys, and keys with calculator functions ((), (), (\bullet), (\bullet), (IMART) and (ENTER)) become an algebraic-entry calculator.

Push the **Done** softkey to start normal Product operation.

Fluke-Direct.com

Users Manual

Save to and Recall from the Registers

When the Product is in calculator mode, the top half of the display shows three register names and their contents:

- **MEASURE** (the present measured value)
- **SOURCE** (the present sourced value)
- REGISTER (temporary storage for your use)

Push the **Recall** softkey and then the softkey for the applicable register to insert the contents of any register into a calculation.

Push **Store** to copy the number from the calculator display (lower half) into **REGISTER** to temporarily save the number for later use, or into **SOURCE**.

Use the Calculator to Set the Source Value

When you store to **SOURCE**, the Product shows a selection of unit multipliers when necessary (for example, mV or V), then starts sourcing that value. The Product will not keep out-of-range values to **SOURCE**.

Quick Guide to Applications

The subsequent figures show test lead connections and which Product functions to use for many different applications.



Documenting Process CalibratorQuick Guide to Applications




Figure 43. Chart Recorder Calibration




Figure 44.Voltage Drop Measurement




Figure 45. Monitor AC Line Voltage and Frequency

Documenting Process CalibratorQuick Guide to Applications




Figure 46. Current-to-Pressure (I/P) Transmitter Calibration

gks28c.eps




Figure 47. Output Current of a Transmitter Measurement

gks29c.eps

Documenting Process CalibratorQuick Guide to Applications




Figure 48. Precision Resistor Measurement




Figure 49. Resistance Source

gks31c.eps




Figure 50. Checking a Switch




Figure 51. Tachometer Examination

Documenting Process CalibratorQuick Guide to Applications




Figure 52. Analog and HART Pressure Transmitter Connection

gks34c.eps




Figure 53. mV to Current Transmitter Calibration

gks35c.eps

Documenting Process CalibratorQuick Guide to Applications




Figure 54. Vortex Shedding Flowmeter Check

gks36c.eps




Figure 55. HART and Analog RTD Transmitter Connections

gks60.eps

Documenting Process CalibratorQuick Guide to Applications




Figure 56. Analog and HART Thermocouple Transmitter Connections

gks61.eps




Figure 57. Transmitter HART- Comm Only

gks43.eps

Documenting Process Calibrator

Communication with a PC

Communication with a PC

Procedures and results that you have kept can be uploaded from and downloaded to a PC. A PC, Microsoft Windows, USB cable (supplied), and Fluke *DPCTrack2*[™] application software, or a qualified Fluke partner's software are required. See the *DPCTrack2 Users Manual* for further instructions.

Maintenance

∧∧Warning

To prevent possible electrical shock, fire, or personal injury:

- Have an approved technician repair the Product.
- Do not operate the Product with covers removed or the case open. Hazardous voltage exposure is possible.
- Remove the input signals before you clean the Product.
- Use only specified replacement parts.

Note

Additional maintenance instructions, including a calibration procedure and a list of replaceable parts is available in the 75X Series Calibration Manual

Battery Replacement

Replace the battery when it no longer holds a charge for the rated interval. The battery normally lasts for up to 300 charge/discharge cycles. To order a replacement battery, see "User-Replaceable Parts".

Note

Spent batteries should be disposed of by a qualified recycler or hazardous materials handler. Contact an authorized Fluke Service Center for recycling information.

Clean the Product

Clean the Product and pressure modules with a soft cloth dampened with water or water and mild soap.

∆ Caution

To prevent possible damage to the Product, do not use solvents or abrasive cleansers.



Users Manual

Calibration Data

The date of the last calibration and verification shows on the calibration sticker and on the calibration screen in Setup mode. The CAL. STATUS number on the sticker should always match the Calibration Status number in the calibration screen. Calibration of the Product is to be done by qualified personnel. See the 75X Series Calibration Manual.

In Case of Difficulty

∧ Marning

To avoid possible electric shock or personal injury, do not use the Product if it operates abnormally. Protection may be impaired. When in doubt, have the Product serviced.

If the display is blank or unreadable, but the beeper works when the Product is turned on, make sure the brightness is correctly adjusted. To adjust the Intensity, see "Display Intensity".

If the Product will not turn on, make sure the battery is not dead or disconnected from the battery charger. If the Product receives power, the power button should be lit. If the button is lit, but the Product does not power up, have the Product serviced. .

Service Center Calibration or Repair

Calibration, repairs, or servicing not included in this manual must be done only by qualified service personnel. If the Product fails, examine the battery pack first, and replace it if necessary.

Make sure that you operate the Product in accordance with the instructions in this manual. If the Product is faulty, send a description of the failure with the Product. Pressure modules do not need to accompany the Product unless the module is faulty also. Be sure to pack the Product securely, using the original shipping container if it is available. See the Warranty Statement.

User-Replaceable Parts

Table 12 lists the Fluke part number of each userreplaceable part for the Product. See "Standard Equipment" and "Accessories" for model or part numbers of standard and optional equipment.



Documenting Process Calibrator User-Replaceable Parts

Table 12. Replacement Parts

Item	Fluke Part Number
Adjustable Quick-Release Strap	3889532
Input/Output Jack Decal	3405856
Tilt Stand	3404790
BP7240 Battery	4022220
USB Cable	1671807
BC7240 Power Supply/Battery Charger	4022655
Lens Cover	3609579
Alligator Clip Set-Extended Tooth	3765923
754HCC HART Communication Cable Assembly	3829410
AC280 Suregrip Hook Clip Set	1610115
ГС Сар	4073631
Note: See "Standard Equipment" and "Accessories" for mode	l or part numbers for most replaceable equipment.



Users Manual

Accessories

The Fluke accessories listed below are compatible with the Product. For more information about these accessories and their prices, contact a Fluke representative.

- 700-IV Current Shunt
- DPCTrack2 software
- C799 Soft Carry Case
- BC7240 Replacement Battery Charger/Universal Power Supply
- HART Drywell Cable Accessory (PN 2111088)
- 12-V Car Battery Charger
- Fluke-700PCK Pressure Module Calibration Kit (requires pressure calibration equipment and a PC compatible computer)
- 700PTP-1 Pneumatic test pump
- 700HTP-1 Hydraulic test pump
- Fluke-700TC1 TC miniplug kit
- Fluke-700TC2 TC miniplug kit
- C781 Soft Carrying Case

- C700 Hard Carrying Case
- BP7240 Li-Ion Battery
- · TL series test leads
- AC series test lead clips
- TP series test lead probes
- 80PK series thermocouples
- Pressure Modules Fluke model numbers listed below. (Differential models also operate in gage mode.) Contact a Fluke representative about pressure modules not listed here.
 - FLUKE-700P00 1 in. H2O/0.001
 - FLUKE-700P01 10 in. H2O/0.01
 - FLUKE-700P02 1 psi/0.0001
 - FLUKE-700P22 1 psi/0.0001
 - FLUKE-700P03 5 psi/0.0001
 - FLUKE-700P23 5 psi/0.0001
 - FLUKE-700P04 15 psi/0.001
 - FLUKE-700P24 15 psi/0.001
 - FLUKE-700P05 30 psi/0.001
 - FLUKE-700P06 100 psi/0.01



Documenting Process Calibrator Accessories

- FLUKE-700P27 300 psi / 0.01
- FLUKE-700P07 500 psi/0.01
- FLUKE-700P08 1000 psi/0.1
- FLUKE-700P09 1500 psi/0.1
- FLUKE-700PA3 5 psi/0.0001
- FLUKE-700PA4 15 psi/0.001
- FLUKE-700PA5 30 psi/0.001
- FLUKE-700PA6 100 psi/0.01
- FLUKE-700PV3 -5 psi/0.0001
- FLUKE-700PV4 -15 psi/0.001
- FLUKE-700PD2 ±1 psi/0.0001
- FLUKE-700PD3 ±5 psi/0.0001
- FLUKE-700PD4 ±15 psi/0.001
- FLUKE-700PD5 -15/30 psi/0.001
- FLUKE-700PD6 -15/100 psi/0.01
- FLUKE-700PD7 -15/200 psi/0.01
- FLUKE-700P29 3000 psi/0.1
- FLUKE-700P30 5000 psi/0.1
- FLUKE-700P31 10000 psi/1



Users Manual

Specifications

General Specifications

All specifications apply from +18 °C to +28 °C unless stated otherwise.

All specifications assume a 5-minute warmup period.

Measurement specifications are valid only when Damping is turned on. When damping is turned off, or when the Applications are shown, floor specifications are multiplied by 3. Floor specifications are the second part of the specifications. The measure pressure, temperature, and frequency functions are specified only with damping on.

Specifications are valid to 110 % of range. The following exceptions are valid to 100 % of range: 300 V dc, 300 V ac, 22 mA source and simulate, 15 V dc source, and temperature measure and source.

To achieve the best noise rejection, use battery power.

	. Height = 63.35 mm (2.49 inches) x Width = 136.37 mm (5.37 inches) x Length = 244.96 mm (9.65 inches)
Weight	. 1.23 kg (2.71 lb) (Batteries included)
Display	. 480 by 272 pixel graphic LCD, 95 x 54 mm
Power	Internal battery pack: Lithium Ion, 7.2 V dc, 30 Wh

Environmental Specifications

Environmental Specifications	
Operating Altitude	3000 m (9842 ft)
Storage Altitude	13000 m (42650 ft)
Operating Temperature	10 to 50 °C
Storage Temperature	20 to 60 °C
Relative Humidity (Maximum, non-condensing) .	90 % to 35 °C
	75 % to 40 °C
	45 % to 50 °C

Standards and Agency Approval Specifications



Detailed Specifications

Specifications valid after a 5-minute warmup.

Specifications are valid to 110 % of Range with the following exceptions: 300 V dc measure, 300 V ac measure, 50 kHz measure and source, 22 mA source and simulate, 15 V dc source, and temperature measure and source which are valid to 100 % of range.

DC mV Measurement

Donne Becelution		% of Reading + Floor	
Range Resolution	1 Year	2 Year	
±100.000 mV	0.001 mV	0.02 % + 0.005 mV	0.03 % + 0.005 mV

Input Impedance: >5 $M\Omega$

Maximum Input Voltage: 300 V, IEC 61010 300 V CAT II

Temperature coefficient: (0.001 % of reading + 0.001% of range) / °C (<18 °C or >28 °C)

Normal mode rejection: >100 dB at 50 or 60 Hz nominal



Users Manual

DC Voltage Measurement

Donata Donatation	% of Reading + Floor			
Range Resolution		1 Year	2 Year	
±3.00000 V	0.00001 V	0.02 % + 0.00005 V	0.03 % + 0.00005 V	
±30.0000 V	0.0001 V	0.02 % + 0.0005 V	0.03 % + 0.0005 V	
±300.00 V	0.01 V	0.05 % + 0.05 V	0.07 % + 0.05 V	

Input Impedance: >4 $M\Omega$

Maximum Input Voltage: 300 V, IEC 61010 300V CAT II

Temperature coefficient: (0.001 % of reading + 0.0002 % of range) / $^{\circ}$ C (<18 $^{\circ}$ C or >28 $^{\circ}$ C)

Normal mode rejection: >100 dB at 50 or 60 Hz nominal

AC Voltage Measurement

Range	Decelution	% of Reading + Floor	
40 Hz – 500 Hz	40 Hz – 500 Hz	1 Year	2 Year
3.000 V	0.001 V	0.5 % + 0.002 V	1.0 % + 0.004 V
30.00 V	0.01 V	0.5 % + 0.02 V	1.0 % + 0.04 V
300.0 V	0.1 V	0.5 % + 0.2 V	1.0 % + 0.2 V

Input Impedance: >4 M Ω and <100 pF

Input Coupling: AC

Maximum Input Voltage: 300 V, IEC 61010 300V CAT II

Temperature coefficient: 5 % of specified accuracy / °C (<18 °C or >28 °C)

Specifications apply for 9 % to 100 % of voltage range.



DC Current Measurement

Donas	Resolution	% of Reading + Floor	
Range	Resolution	1 Year	2 Year
±30.000 mA	1 μΑ	0.01 % + 5 μA	0.015 % + 7 μA
±100.00 mA	10 μΑ	0.01 % + 20 μA	0.015 % + 30 μA

Maximum Input: 110 mA

Maximum Burden Voltage: 420 mV at 22 mA

Temperature coefficient: 3 % of specified accuracy / $^{\circ}$ C (<18 $^{\circ}$ C or >28 $^{\circ}$ C)

No Fuse

Normal mode rejection: 90 dB at 50 or 60 Hz nominal, and 60 dB at 1200 Hz and 2200 Hz nominal (HART signals)

Resistance Measurement

Panera Panelutian		% of Read	Source	
Range Resolution	1 Year	2 Year	Current	
10.000 Ω	0.001 Ω	$0.05~\% + 0.050~\Omega$	$0.07~\% + 0.070~\Omega$	3 mA
100. 00 Ω	0.01 Ω	$0.05~\% + 0.05~\Omega$	$0.07~\% + 0.07~\Omega$	1 mA
1.0000 kΩ	0.1 Ω	$0.05~\% + 0.0005~\mathrm{k}\Omega$	$0.07~\% + 0.0007~\mathrm{k}\Omega$	500 μΑ
10.000 kΩ	1 Ω	0.10 % + 0.010 kΩ	$0.15~\% + 0.015~\mathrm{k}\Omega$	50 μΑ

Open-circuit voltage: 5 V nominal

Temperature coefficient: 3 % of specified accuracy / °C (<18 °C or >28 °C)

Continuity Testing

Tone	Resistance
Continuous tone	<25 Ω
May or may not get tone	25 to 400 Ω
No tone	>400 Ω



Users Manual

Frequency Measurement

Ranges	Resolution	2 Year
1.00 Hz to 110.00 Hz [1]	0.01 Hz	0.05 Hz
110.1 Hz to 1100.0 Hz	0.1 Hz	0.5 Hz
1.101 kHz to 11.000 kHz	0.001 kHz	0.005 kHz
11.01 kHz to 50.00 kHz	0.01 kHz	0.05 kHz

Coupling: AC

Minimum Amplitude for Frequency Measurement (square wave):

<1 kHz: 300 mV p-p 1 kHz to 30 kHz: 1.4 V p-p >30 kHz: 2.8 V p-p

Maximum input: <1 kHz: 300 V rms >1 kHz: 30 V rms Input Impedance: >4 M Ω

[1] For frequency measurement less than 110.00 Hz, specifications apply for signals with a slew rate >5 volt/millisecond.

±DC Voltage Output

Danas	Resolution	% of Output + Floor	
Range		1 Year	2 Year
±100.000 mV	1 μV	0.01 % + 0.005 mV	0.015 % + 0.005 mV
±1.00000 V	10 μV	0.01 % + 0.00005 V	0.015 % + 0.00005 V
±15.0000 V	100 μV	0.01 % + 0.0005 V	0.015 % + 0.0005 V

Maximum Output Current: 10 mA, In the 100 mV range add 0.010 mV to specification when sourcing >1 mA. For sourcing dc voltages <110.000 mV, accuracy is not specified in RF fields >1 V/m, 80 MHz to 700 MHz. Temperature Coefficient: 0.001 % of output + 0.001 % of range / $^{\circ}$ C (<18 $^{\circ}$ C or >28 $^{\circ}$ C)

+DC Current Source

Posolution	% of Output + Floor	
Vesolation	1 Year	2 Year
1 μΑ	0.01 % + 3 μΑ	0.02 % + 3 μΑ
	Resolution	Resolution 1 Year

Temperature Coefficient: 3 % of specified accuracy / °C (<18 °C or >28 °C)

Source mA Compliance Voltage: 18 V maximum Source mA Open Circuit Voltage: 30 V maximum

+DC Current Simulate (External Loop Power)

Range/Mode	Resolution	% of Output + Floor		
Kange/wode	Resolution	1 Year	2 Year	
0.100 to 22.000 mA (Current Sink)	1 μΑ	0.02 % + 7 μA	0.04 % + 7 μΑ	

Simulate mA Input Voltage: 15 to 50 V dc, add 300 μ A to floor when >25 V is present on the loop

Temperature Coefficient: 3 % of specified accuracy / °C (<18 °C or >28 °C)

Resistance Sourcing

Range	Resolution	% of Outp	% of Output + Floor		
	Resolution	1 Year	2 Year	Current	
10.000 Ω	0.001 Ω	0.01 % + 0.010 Ω	0.015 % + 0.015 Ω	0.1 mA to 10 mA	
100.00 Ω ^[1]	0.01 Ω	0.01 % + 0.02 Ω	$0.015~\% + 0.03~\Omega$	0.1 mA to 10 mA	
1.0000 kΩ ^[2]	0.1 Ω	0.02 % + 0.0002 kΩ	$0.03~\% + 0.0003~\mathrm{k}\Omega$	0.01 mA to 1.0 mA	
10.000 kΩ	1 Ω	0.02 % + 0.003 kΩ	0.03 % + 0.005 kΩ	0.01 mA to 1.0 mA	

Temperature Coefficient: (0.01 % of output +0.02 % of range / $^{\circ}$ C (<18 $^{\circ}$ C or >28 $^{\circ}$ C).

When connected to mains, accuracy is not specified with conducted RF >1V, 8 to 15 MHz.

- [1] Add 0.01 Ω when the excitation current is <1 mA.
- [2] Add 0.0015 k Ω when the excitation current is <0.1 mA.



Users Manual

Frequency Sourcing

Dan an	Specification
Range	2 Year
Sine Wave: 0.1 Hz to 10.99 Hz	0.01 Hz
Square Wave: 0.01 Hz to 10.99 Hz	0.01 Hz
Sine and Square Wave: 11.00 Hz to 109.99 Hz	0.1 Hz
Sine and Square Wave: 110.0 Hz to 1099.9 Hz	0.1 Hz
Sine and Square Wave: 1.100 kHz to 21.999 kHz	0.002 kHz
Sine and Square Wave: 22.000 kHz to 50.000 kHz	0.005 kHz

Waveform Choices: Zero-symmetric sine wave or positive 50 % duty-cycle square wave

Square Wave Amplitude: 0.1 to 15 V p-p

Square Wave Amplitude Accuracy, 0.01 to 1 kHz: 3 % p-p output + 75 mV, 1 kHz to 50 kHz: 10 % p-p output + 75 mV typical.

Sine Wave Amplitude: 0.1 to 30 V p-p

Sine Wave Amplitude Accuracy, 0.1 to 1 kHz: 3% p-p output + 75 mV, 1 kHz to 50 kHz: 10% p-p output + 75 mV typical.

Frequency specifications are valid when averaged ≥100 ms



Temperature, Thermocouples

Time	Dames 90	Meas	sure °C	Sou	rce °C
Туре	Range °C	1 Year	2 Year	1 Year	2 Year
E	-250 to -200	1.3	2.0	0.6	0.9
	-200 to -100	0.5	0.8	0.3	0.4
	-100 to 600	0.3	0.4	0.3	0.4
	600 to 1000	0.4	0.6	0.2	0.3
N	-200 to -100	1.0	1.5	0.6	0.9
	-100 to 900	0.5	0.8	0.5	0.8
	900 to 1300	0.6	0.9	0.3	0.4
J	-210 to -100	0.6	0.9	0.3	0.4
	-100 to 800	0.3	0.4	0.2	0.3
	800 to 1200	0.5	0.8	0.3	0.3
K	-200 to -100	0.7	1.0	0.4	0.6
	-100 to 400	0.3	0.4	0.3	0.4
	400 to 1200	0.5	0.8	0.3	0.4
	1200 to 1372	0.7	1.0	0.3	0.4
Т	-250 to -200	1.7	2.5	0.9	1.4
	-200 to 0	0.6	0.9	0.4	0.6
	0 to 400	0.3	0.4	0.3	0.4
В	600 to 800	1.3	2.0	1.0	1.5
	800 to 1000	1.0	1.5	0.8	1.2
	1000 to 1820	0.9	1.3	0.8	1.2



753/754 Users Manual

T	Danna 00	Meas	sure °C	Sou	rce °C
Туре	Range °C	1 Year	2 Year	1 Year	2 Year
R	-20 to 0	2.3	2.8	1.2	1.8
	0 to 100	1.5	2.2	1.1	1.7
	100 to 1767	1.0	1.5	0.9	1.4
S	-20 to 0	2.3	2.8	1.2	1.8
	0 to 200	1.5	2.1	1.1	1.7
	200 to 1400	0.9	1.4	0.9	1.4
	1400 to 1767	1.1	1.7	1.0	1.5
С	0 to 800	0.6	0.9	0.6	0.9
(W5Re/W26Re)	800 to 1200	0.8	1.2	0.7	1.0
	1200 to 1800	1.1	1.6	0.9	1.4
	1800 to 2316	2.0	3.0	1.3	2.0
L	-200 to -100	0.6	0.9	0.3	0.4
	-100 to 800	0.3	0.4	0.2	0.3
	800 to 900	0.5	0.8	0.2	0.3
U	-200 to 0	0.6	0.9	0.4	0.6
	0 to 600	0.3	0.4	0.3	0.4
BP	0 to 1000	1.0	1.5	0.4	0.6
	1000 to 2000	1.6	2.4	0.6	0.9
	2000 to 2500	2.0	3.0	0.8	1.2

Ī	Type Range °C		Meas	sure °C	Source °C	
	туре	Range °C	1 Year	2 Year	1 Year	2 Year
ſ	XK	-200 to 300	0.2	0.3	0.2	0.5
		300 to 800	0.4	0.6	0.3	0.6

Sensor inaccuracies not included.

Accuracy with external cold junction; for internal junction add 0.2 °C

Resolution: 0.1 °C

Temperature Scale: ITS-90 or IPTS-68, selectable (90 is default)

Compensation: ITS-90 per NIST Monograph 175 for B,R,S,E,J,K,N,T; IPTS-68 per IEC 584-1 for B,R,S,E,J,K,T; IPTS-68 per DIN 43710 for L,U. GOST P 8.585-2001 (Russia) for BP and XK, ASTM E988-96 for C (W5Re/W26Re)

Temperature Coefficient: 0.05 °C/ °C (<18 °C or >28 °C)

0.07 °C/ °C for C type >1800 °C and for BP type >2000 °C

Instrument Operating Temperature: 0 to 50 $^{\circ}$ C for C and BP type thermocouples / -10 to 50 $^{\circ}$ C for all other types

Normal Mode Rejection: 65 dB at 50 Hz or 60 Hz nominal

For sourcing thermocouple voltages, accuracy is not specified in RF fields >1 V/m, 80 MHz to 700 MHz.



753/754 Users Manual

Temperature, Resistance Temperature Detectors

	Temperature, RTDs Degrees or % of Reading ^[1]						
		Measure °C [2]			Sourc	e °C	Allowable
Type (α)	Range °C	1 Year	2 Year	Source Current	1 Year	2 Year	Excitation Current [3]
100 Ω	-200 to 100	0.07 °C	0.14 °C	1 mA	0.05 °C	0.10 °C	0.1 to 10 m A
Pt(385)	100 to 800	0.02 % + 0.05 °C	0.04 % + 0.10 °C	TIMA	0.0125 % + 0.04 °C	0.025 % + 0.08 °C	0.1 to 10 mA
200 Ω	-200 to 100	0.07 °C	0.14 °C	500 μΑ	0.10 °C	0.20 °C	0.1 to 1 mA
Pt(385)	100 to 630	0.02 % + 0.05 °C	0.04 % + 0.10 °C		0.017 % + 0.09 °C	0.034 % + 0.18 °C	
500 Ω	-200 to 100	0.07 °C	0.14 °C	050 4	0.08 °C	0.16 °C	0.1 to 1 mA
Pt(385)	100 to 630	0.02 % + 0.05 °C	0.04 % + 0.10 °C	250 μΑ	0.017 % + 0.06 °C	0.034 % + 0.12 °C	
1000 Ω	-200 to 100	0.07 °C	0.14 °C	150 μΑ	0.06 °C	0.12 °C	0.1 to 1 m/
Pt(385)	100 to 630	0.02 % + 0.05 °C	0.04 % + 0.10 °C		0.017 % + 0.05 °C	0.034 % + 0.10 °C	0.1 to 1 mA
100 Ω	-200 to 100	0.07 °C	0.14 °C	4 4	0.05 °C	0.10 °C	0.4 to 40 == 1
Pt(3916)	100 to 630	0.02 % + 0.05 °C	0.04 % + 0.10 °C	1 mA	0.0125 % + 0.04 °C	0.025 % + 0.08 °C	0.1 to 10 mA
100 Ω	-200 to 100	0.08 °C	0.16 °C	1 m A	0.05 °C	0.10 °C	0.1 to 10 m ^
Pt(3926)	100 to 630	0.02 % + 0.06 °C	0.04 % + 0.12 °C	1 mA	0.0125 % + 0.04 °C	0.025 % + 0.08 °C	0.1 to 10 mA



	Temperature, RTDs Degrees or % of Reading [1]							
	Measure °C [2]				Source °C		Allowable	
Type (α) Range °C		1 Year	2 Year	Source Current	1 Year	2 Year	Excitation Current [3]	
10 Ω Cu(427)	-100 to 260	0.2 °C	0.4 °C	3 mA	0.2 °C	0.4 °C	1 to 10 mA	
120 Ω Ni(672)	-80 to 260	0.1 °C	0.2 °C	1 mA	0.04 °C	0.08 °C	0.1 to 10 mA	

- [1] Specifications are valid to k=3
 Sensor inaccuracies not included
- [2] For two and three-wire RTD measurements, add 0.4 $^{\circ}\text{C}$ to the specifications.

Resolution: 0.01 °C except 0.1 °C for 10 Ω Cu(427)

Temperature Coefficient: 0.01 °C/°C for measure, 0.02 °C/°C (<18 °C or >28 °C) for source

[3] Supports pulsed transmitters and PLCs with pulse times as short as 1 $\ensuremath{\mathsf{ms}}$

RTD Reference:

Pt(385): IEC 60751, 2008 Pt(3916): JIS C 1604, 1981

Pt(3926), Cu(427), Ni(672): Minco Application Aid #18

Loop Power

Open Circuit	Loaded Circuit
26 V ±10 %	18 V minimum at 22 mA
Short circuit protected to 25 mA	
Output Resistance: 250 Ω nominal	

